

P:\26\26963002\GIS\26963002_Project\26963002_Project.aprx\2696300200_F01_Site_Figure Date Exported: 03/18/24 by maugust

Source(s): Whatcom County Aerial Imagery, 2019. Impact Design, 2023.
Coordinate System: NAD 1983 StatePlane Washington North FIPS 4601 Feet


Disclaimer: This figure was created for a specific purpose and project. Any use of this figure for any other project or purpose shall be at the user's sole risk and without liability to GeoEngineers. The locations of features shown may be approximate. GeoEngineers makes no warranty or representation as to the accuracy, completeness, or suitability of the figure, or data contained therein. The file containing this figure is a copy of a master document, the original of which is retained by GeoEngineers and is the official document of record.

Legend

- Approximate Marine Drive Property Boundary
- Boring Location
- Boring Location with Grab Groundwater Sample
- Test Pit Location
- Test Pit Location - Soil Samples not Collected or Analyzed

- Proposed Exploration Type**
- Proposed Boring
 - Proposed Grab Sample
 - Proposed Temporary Groundwater Monitoring Well

- Approximate Extent of Observed Fill
- Proposed Building
- Proposed Concrete Area
- Proposed Pavement Area
- Proposed Stormwater Detention Pond
- Proposed Pond Access Road



Site Figure	
ABC Recycling Realty Corporation Marine Drive Property, Bellingham, Washington	
	Figure 1

Soil Sample Locations

location	Sample ID	depth bgs (ft)	COCs	Reasoning	Hold
Property Wide	Grab-1 through Grab-19	Eastern/Western/Central areas of Property	As/Cd/Pb	determine COPC concentration in fill	
		Eastern/Western areas of Property		back up sample to be run if vertical delineation is needed.	X
		Central area of Property		back up sample to be run if vertical delineation is needed.	X
TP-5	GP-7 through GP-11	0.5	As/Cd/Pb, cPAHs, Dioxin/Furans	determine COPC concentration in fill	
		2.5 or middle of fill		determine COPC concentration in fill (vertical delineation)	X
		5 or native		determine COPC concentration in native soil	
TP-6	GP-12 through GP-16	0.5	As/Cd/Pb, cPAHs, naphthalene	determine COPC concentration in fill	
		2.5 or middle of fill		determine COPC concentration in fill (vertical delineation)	X
		5 or native		determine COPC concentration in native soil	
North Central	GP-17	0.5	As/Cd/Pb/Sb, cPAHs, naphthalene	determine COPC concentration in fill	
		2.5 or middle of fill		determine COPC concentration in fill (vertical delineation)	X
		5 or native		determine COPC concentration in native soil	
South Central	GP-18	0.5	As/Cd/Pb/Sb, cPAHs, naphthalene	determine COPC concentration in fill	
		2.5 or middle of fill		determine COPC concentration in fill (vertical delineation)	X
		5 or native		determine COPC concentration in native soil	

Temporary Monitoring Wells

location	Sample ID	Screened Interval bgs (ft)	COCs	Construction
TP-5	GP-10	5-15	As/Cd/Sb, cPAHs, Dioxin/Furans	advance boring to 15' bgs, install temp pvc well
TP-6	GP-14		As/Cd, cPAHs, Naphthalene	advance boring to 15' bgs, install temp pvc well
North Central	GP-17		As/Cd/Pb/Sb, cPAHs, Naphthalene	advance boring to 15' bgs, install temp pvc well
TP-9	GP-18		As/Cd/Pb/Sb, cPAHs, Naphthalene	advance boring to 15' bgs, install temp pvc well