

Technical Memorandum

TO: Matthew Morris, PE, Washington State Department of Ecology
CC: Amy Sikora, Washington State Department of Natural Resources
FROM: Sierra Mott and Eric Weber, LHG, CWRE
DATE: August 11, 2020
RE: **Compliance Monitoring Plan**
Webster Nursery Site, Site ID 3380
Tumwater, Washington
Project No. 0774006.040.046

Introduction

This technical memorandum presents the Compliance Monitoring Plan (CMP) for the Washington State Department of Natural Resources (DNR) Webster Nursery Site, a former pesticide-storage warehouse in Tumwater, Washington (Site; Figure 1). The Site is associated with past releases of organochlorine pesticides and consists of an area of contaminated soil and groundwater at the nursery that has been locally affected by a release of organochlorine pesticides from an underground storage tank (UST) formerly located south of the pesticide storage warehouse. Constituents of concern include the organochlorine pesticides heptachlor, heptachlor epoxide (HE; breakdown product of heptachlor), and technical chlordane.

Remedial action excavation and disposal of HE-contaminated soil was completed in August 2018. A summary of the remedial action is provided in a Cleanup Action Completion Report (CACR; LAI 2020a). As of February 2020, DNR has completed the seventh quarterly groundwater performance monitoring event following the remedial action (LAI 2020b); a minimum of four events were required per the Cleanup Action Plan (LAI 2016) and as described in the CACR. However, additional performance monitoring is warranted. A summary of the current groundwater monitoring plan, a review of groundwater and soil compliance requirements, DNR's understanding of how to obtain Site closure, and a compliance schedule are presented in this memorandum.

Summary of Groundwater Monitoring

Since completion of the remedial action, groundwater performance monitoring has been conducted in accordance with the framework established by Washington State Department of Ecology (Ecology) Agreed Order (AO) No. DE 00TCP-SR295, the Remedial Action Work Plan (RAWP; LAI 2017), and the CACR (LAI 2020a). Revisions to the monitoring plan were approved by Ecology in August 2019 (Morris 2019):

- Continue quarterly groundwater monitoring at SW-10R and SW-11R until at least 4 consecutive quarters of data are below cleanup levels (CULs)

- Suspend groundwater monitoring at SW-9R, SW-14, SW-15, and SW-16 (HE has never been detected at a concentration exceeding the CUL at any of these wells)
- Discontinue collecting groundwater elevation measurements at all wells (except for SW-10R and SW-11R per low-flow sampling requirements) and presenting quarterly groundwater elevation contours.

The groundwater monitoring network is shown on Figure 2. A concentration time series plot for SW-10R and SW-11R is shown on Figure 3. Results indicate that concentration of HE continue to consistently exceed cleanup levels (CULs) at one well, SW-10R.

Compliance Monitoring

There are three types of compliance monitoring required per the Model Toxics Control Act (MTCA) (Washington Administrative Code [WAC] 173-340-410), which are listed below:

- **Protection monitoring:** protection of human health and the environment during construction, operation, and maintenance of the remedial action period (WAC 173-340-410[1][a])
- **Performance monitoring:** confirm through monitoring that cleanup standards have been met following the remedial action (WAC 173-340-410[1][b])
- **Confirmational monitoring:** confirm the long-term effectiveness of the remedial action once cleanup standards have been met (WAC 173-340-410[1][c]).

A description of the monitoring plan for Site groundwater and soil is described in the sections below.

Protection Monitoring

Protection monitoring will be conducted during maintenance of the remedial action via quarterly groundwater monitoring in accordance with the Site health and safety plan, which is included as Attachment 1. In addition, an environmental covenant will be put in place to limit ground disturbing activities at the Site.

An environmental covenant will be required for the Site until groundwater achieves CULs and the Site is closed. The environmental covenant will include considerations for potential future ground-disturbing work at the Site, including the following:

- Notification to Ecology prior to any ground-disturbing activities at the Site
- Identification of potentially contaminated soil
- Health and safety protocols
- Soil handling and disposal
- Record-keeping.

A copy of this Compliance Monitoring Plan will be attached to the covenant.

Performance Monitoring

Performance monitoring sampling data will be evaluated for soil and groundwater.

Soil Monitoring

Soil performance samples were collected from the 2018 remedial excavation and compared to MTCA Method B CULs for protection of groundwater (LAI 2020a). Results indicated that soil with concentrations of technical chlordane, heptachlor, and HE above the groundwater protection CULs remain in place. However, if concentrations of HE in groundwater at SW-10R and SW-11R achieve compliance (i.e. four consecutive quarters of data showing results below CULs), it will be empirically demonstrated that soil concentrations are protective of groundwater (WAC 173-340-747[9]). Once it has been empirically demonstrated that soil concentrations are protective of groundwater, the soil cleanup level will revert to the Method B level for direct contact. Soil results compared to both protection of groundwater and direct contact CULs are presented in Table 1. As shown in Table 1, no performance monitoring soil sample results exceed the direct contact CULs for any analyte in any sample, indicating that human health and the environment are adequately protected. As stated above, this may be sufficient to empirically demonstrate that concentrations of pesticides remaining in soil are protective of groundwater. No confirmational soil monitoring will be required.

Groundwater Monitoring

As mentioned above, groundwater monitoring will be conducted at SW-10R and SW-11R in accordance with the Site sampling and analysis plan, which is included as Attachment 2. Groundwater performance monitoring data will be evaluated in order to determine compliance. One of two evaluation methods may be used:

- Direct comparison (e.g. four consecutive quarters below the cleanup levels) or,
- Statistical approach, where
 - The upper 95th percentile confidence limit on the true mean of the test results from the monitoring point must be less than the CUL (WAC 173-340-740[7][d][i][A])
 - Less than 10 percent of the samples exceed the CUL (WAC 173-340-740[7][e][ii])
 - No single sample is greater than two times the CUL (WAC 173-340-740[7][e][i]).

A direct comparison evaluation will be conducted quarterly, and a statistical evaluation will be conducted at least once per year (annually).

Confirmation Monitoring

Confirmation monitoring will be completed once it has been confirmed that cleanup standards have been met (in both groundwater and soil). Confirmational groundwater monitoring will consist of quarterly monitoring at SW-9R, SW-10R, SW-11R, SW-14, SW-15, and SW-16. Four quarters of

monitoring results will be sufficient to confirm the long-term effectiveness of the remedial action and achievement of CULs.

Compliance Schedule

Quarterly groundwater performance monitoring is ongoing. A total of seven groundwater monitoring events have occurred since completion of the remedial action; most recent results indicate that SW-11R has met CULs, however concentrations of HE at SW-10R continue to show variability (LAI 2020a). Additional quarterly performance monitoring will be required to demonstrate concentrations at SW-10R have met CULs. Quarterly monitoring will be completed at the end of August, November, February, and May until data from four consecutive quarters are below CULs. If additional quarterly performance monitoring shows consistent, yet elevated, results at SW-10R, DNR may request a modification to semiannual or annual monitoring in future years.

Due to the requirement for ongoing performance monitoring, the quarterly events were renamed using the following convention beginning with the August 2019 event (3Q19). DNR will continue to submit quarterly groundwater monitoring data to Ecology within 30 days of receipt of validated data, and no later than 90 days from the groundwater sampling date. Environmental Information Management submittals are required, and will also be completed quarterly.

Conclusions and Next Steps

DNR proposes to continue performance monitoring for a maximum of five years from the completion of the remedial action (i.e. through May 2023). If groundwater has not met CULs at that time, DNR will review potential supplemental cleanup options, such as additional soil excavation or in-situ soil or groundwater treatment, placing a conditional point of compliance at the property boundary, or evaluating MTCA Method C CULs. Once the cleanup is complete, DNR will request that Ecology initiate actions for termination of the environmental covenant. As such, DNR anticipates requesting Ecology evaluate the overall success of the cleanup and, at its discretion, issue a letter indicating AO requirements are satisfied and that the cleanup is complete. All groundwater monitoring wells associated with the remedial action would be decommissioned at that time.

LANDAU ASSOCIATES, INC.



Sierra Mott
Senior Project Scientist



Eric Weber, LHG, CWRE
Principal

SMM/SEF/EFW/kjg



[Y:\774\006\R\COMPLIANCE MONITORING PLAN\WEBSTER NURSERY COMP MON PLAN TECHNICAL MEMORANDUM.DOCX]

Attachments: Figure 1. Vicinity Map
Figure 2. Groundwater Monitoring Network
Figure 3. Heptachlor Epoxide Time Series Concentrations for SW-10(R) and SW-11(R)
Table 1. Performance Monitoring Soil Sample Analytical Results
Attachment 1: Health and Safety Plan
Attachment 2: Sampling and Analysis Plan

References

- LAI. 2016. *2016 Draft Cleanup Action Plan*, Webster Nursery, Site ID 3380, Tumwater, Washington. Landau Associates, Inc. June.
- LAI. 2017. *Remedial Action Work Plan*, Webster Nursery, 9805 Blomberg Street SW, Tumwater, Washington. Landau Associates, Inc. October 31.
- LAI. 2020a. *Cleanup Action Completion Report*, Washington State Department of Natural Resources Webster Nursery, Tumwater, Washington. Landau Associates, Inc. May 29.
- LAI. 2020b. Technical Memorandum: *First Quarter 2020 Groundwater Monitoring Results*, Washington State Department of Natural Resources Webster Nursery Site ID 3380, Tumwater, Washington. Landau Associates, Inc. April 29.
- Morris, Matthew. 2019. Email message from Matthew Morris, Cleanup Project Manager, Washington State Department of Ecology Toxics Cleanup Program, to Sierra Mott and Eric Weber, Landau Associates, Inc. and Amy Sikora, Washington Department of Natural Resources, Re: *Webster Nursery Compliance Plan*. August 23.

G:\Projects\774\006\020\026\FIS\F01_VicinityMap.mxd 5/16/2016 NAD 1983 StatePlane Washington North FIPS 4601 Feet



Data Source: Esri 2012




Webster Nursery Site
Tumwater, Washington

Vicinity Map


Figure
1

G:\Projects\7741006\0401045\F02MonitoringWellNetwork.mxd 1/9/2020 NAD 1983 StatePlane Washington South FIPS 4602 Feet



Legend

- Pesticide Monitoring Well
- ▲ Other Monitoring Well
- Tax Parcels




Notes

1. SW-9R, SW-10R, and SW-11R are new (replacement) wells.
2. Black and white reproduction of this color original may reduce its effectiveness and lead to incorrect interpretation.

Data Sources: Thurston County GIS; WA DNR Survey, 2018.



Webster Nursery Site Tumwater, Washington	Monitoring Well Network	Figure 2
--	--------------------------------	--------------------



Webster Nursery Site
Tumwater, Washington

**Heptachlor Epoxide and Groundwater
Elevation Time Series
SW-10(R) and SW-11(R)**

Figure
3

Table 1
Excavation Soil Sample Analytical Results
Webster Nursery – Tumwater, Washington

Analyte	Soil Direct Contact MTCA Method B Cancer	Soil Protective of Groundwater Saturated	Sample Location, Sample Depth (bgs), Laboratory SDG, Sample Date									
			B1-E 15 ft 580-79307-1 8/2/2018	B2-A 10.5 ft 580-79307-1 8/2/2018	B3-F 10.5 ft 580-79307-1 8/2/2018	B4-A 10.5 ft 580-79307-1 8/2/2018	SW1-E 8 ft 580-79307-1 8/2/2018	SW2-S 8 ft 580-79307-1 8/2/2018	SW3-N 6.5 ft 580-79307-1 8/2/2018	SW4-S 5.5 ft 580-79508-1 8/8/2018	SW5-W 6.5 ft 580-79307-1 8/2/2018	SW9-S 5.5 ft 580-79508-1 8/8/2018
Pesticides (µg/kg; SW-846 8081B)												
4,4'-DDD	--	--	2.7 U	2.8 U	2.9 U	2.4 U	2.8 U	2.7 U	2.6 U	2.4 U	2.4 U	2.4 U
4,4'-DDE	--	--	2.7 U	2.8 U	2.9 U	2.4 U	2.8 U	2.7 U	2.6 U	2.4 U	2.4 U	2.4 U
4,4'-DDT	--	--	2.7 U	2.8 U	2.9 U	2.4 U	2.8 U	2.7 U	2.6 U	2.4 UJ	2.4 U	2.4 UJ
Aldrin	--	--	4.1 U	4.1 U	4.3 U	3.6 U	4.3 U	4.1 U	4.0 U	3.6 U	3.5 U	3.6 U
alpha-BHC	--	--	2.7 U	2.8 U	2.9 U	2.4 U	2.8 U	2.7 U	2.6 U	2.4 U	2.4 U	2.4 U
beta-BHC	--	--	6.8 U	6.9 U	7.2 U	6.1 U	7.1 U	6.8 U	6.6 U	6.0 U	5.9 U	6.1 U
Chlordane, Technical	2,860	103	14 U	330	2300	12 U	14 U	14 U	13 U	12 U	12 U	12 U
cis-Chlordane	--	--	2.7 U	26	140	2.4 U	2.8 U	2.7 U	2.6 U	2.4 U	2.4 U	2.4 U
delta-BHC	--	--	4.1 U	4.1 U	4.3 U	3.6 U	4.3 U	4.1 U	4.0 U	3.6 U	3.5 U	3.6 U
Dieldrin	--	--	2.7 U	2.8 U	2.9 U	2.4 U	2.8 U	2.7 U	2.6 U	2.4 U	2.4 U	2.4 U
Endosulfan I	--	--	2.7 U	2.8 U	2.9 U	2.4 U	2.8 U	2.7 U	2.6 U	2.4 U	2.4 U	2.4 U
Endosulfan II	--	--	2.7 U	2.8 U	2.9 U	2.4 U	2.8 U	2.7 U	2.6 U	2.4 U	2.4 U	2.4 U
Endosulfan Sulfate	--	--	2.7 U	2.8 U	2.9 U	2.4 U	2.8 U	2.7 U	2.6 U	2.4 UJ	2.4 U	2.4 U
Endrin	--	--	2.7 U	2.8 U	2.9 U	2.4 U	2.8 U	2.7 U	2.6 U	2.4 U	2.4 U	2.4 U
Endrin Aldehyde	--	--	2.7 UJ	2.8 UJ	2.9 UJ	2.4 UJ	2.8 UJ	2.7 UJ	2.6 UJ	2.4 U	2.4 UJ	2.4 U
Endrin Ketone	--	--	2.7 U	2.8 U	2.9 U	2.4 U	2.8 U	2.7 U	2.6 U	2.4 U	2.4 U	2.4 U
gamma-BHC	--	--	2.7 U	2.8 U	2.9 U	2.4 U	2.8 U	2.7 U	2.6 U	2.4 U	2.4 U	2.4 U
Heptachlor	222	1.9	4.1 U	4.1 U	4.9	3.6 U	4.3 U	4.1 U	4.0 U	3.6 UJ	3.5 U	3.6 U
Heptachlor Epoxide	110	4.02	11	16	49	3.6 U	4.3 U	11	4.0 U	3.6 U	3.5 U	3.6 U
Methoxychlor	--	--	14 U	14 U	14 U	12 U	14 U	14 U	13 U	12 U	12 U	12 U
Toxaphene	--	--	140 U	140 U	140 U	120 U	140 U	140 U	130 U	120 U	120 U	120 U
trans-Chlordane	--	--	15	130	730	3.6 U	4.3 U	4.1 U	4.0 U	3.6 U	3.5 U	3.6 U

Notes:

- U = The analyte was analyzed for, but was not detected above the level of the reported sample quantitation limit.
- UJ = The analyte was analyzed for, but was not detected. The reported quantitation limit is approximate and may be inaccurate or imprecise.
- Box** = detected compound
- Green Box = detected concentration is greater than the cleanup level for protection of groundwater
- Green Box = detected concentration is greater than the cleanup level for direct contact
- = not available

Abbreviations and Acronyms:

- µg/kg = micrograms per kilogram
- bgs = below ground surface
- ft = feet
- MTCA = Model Toxics Control Act
- SDG = sample delivery group

ATTACHMENT 1

Health and Safety Plan



Work Location Personnel Protection and Safety Evaluation Form

Project Number: 0774006.020.024
 Prepared by: Sierra Mott
 Date: July 21, 2016

Reviewed by: Ken Reid
 Date: August 4, 2016

A. Work Location Description

1. **Project Name:** Washington State Department of Natural Resources (DNR) Webster Nursery Cleanup Action
2. **Location:** Tumwater, Washington
3. **Anticipated Activities** Excavation and disposal of approximately 145 cubic yards of soil contaminated with heptachlor epoxide (HE); confirmation soil sampling; decommissioning two groundwater monitoring wells; installation of two replacement monitoring wells using direct-push drilling method; collection of groundwater samples.
4. **Size:** Property is 4 acres; project area is less than 1 acre
5. **Surrounding Population:** Residential/Agricultural
6. **Buildings/Homes/Industry:** Current DNR tree seedling nursery; equipment storage, warehouse
7. **Topography:** Flat
8. **Anticipated Weather:** Sun or rain; 30 to 80 degrees Fahrenheit
9. **Unusual Features:** None.
10. **Site History:** From 1978 until the mid-1990s, organochlorine pesticides were stored in an underground storage tank (UST) located south of the nursery's pesticide storage warehouse. Pesticide containers were rinsed in this building and diluted pesticide wash water leaked over time from the UST. Upon final removal of the UST in 1996, pesticide residues were found in surrounding subsurface soil adjacent to the UST. Contaminated soil was removed and disposed of, but field screening indicated that soil contamination was left in place. Monitoring wells were installed immediately surrounding the former UST location. Subsequently, Ecology issued an Agreed Order to DNR. Additional wells were installed for long-term groundwater monitoring. Recent groundwater and subsurface soil sampling results indicate that HE exceeds applicable MTCA Method B soil and groundwater cleanup levels near the zone of seasonal water table fluctuation in the immediate vicinity of the former UST. Other contaminants at the Site (below cleanup levels) include parent compound heptachlor and alpha- and gamma-chlordane (chlordanes). The proposed cleanup action consists of decommissioning two monitoring wells located inside the excavation area, removal and offsite disposal of contaminated soil located

between 3 ft bgs and 10.5 ft bgs, Site restoration, and installation of two replacement monitoring wells. Periodic groundwater sampling will be performed subsequent to the cleanup action.

B. Hazard Description

1. **Background Review:** Complete Partial
If partial, why? [Click here to enter text.](#)

2. **Hazardous Level:** B C D (Modified) Unknown
Justification: Existing data regarding site conditions and limited exposure based on field activities and equipment to be used.
3. **Types of Hazards: (Attach additional sheets as necessary)**
 - A. Chemical Inhalation Explosive
 Biological Ingestion O₂ Def. Skin Contact
Describe: Contact with soil or groundwater impact by HE.

 - B. Physical Cold Stress Noise Heat Stress Other
Describe: Physical hazards associated with drilling, excavations and confirmation soil sampling, and groundwater sampling.

 - C. Radiation
Describe: [Click here to enter text.](#)

4. **Nature of Hazards:**
 - Air Describe: Potential for airborne dust and contamination.

 - Soil Describe: Potential for contact with or ingestion of contaminated sediment during drilling and sampling.
 - Surface Water Describe: [Click here to enter text.](#)

 - Groundwater Describe: Potential for contact with or ingestion of contaminated groundwater during drilling and sampling.
 - Other Describe: [Click here to enter text.](#)

5. Chemical Contaminants of Concern N/A

Contaminant	PEL (ppm)	IDLH (ppm)	Source/Quantity Characteristics	Route of Exposure	Symptoms of Acute Exposure	Instruments Used to Monitor Contaminant
Heptachlor	0.5 mg/m ³	35 mg/m ³	May be present in soil.	Inhalation, absorption, ingestion, dermal contact.	Tremors, convulsion, liver damage (carcinogen).	Dust Control
Heptachlor Epoxide (HE)	0.5 mg/m ³	Not available	Present in groundwater and soil.	Inhalation, absorption, ingestion, dermal contact.	Tremors, convulsion, liver damage (carcinogen)	Dust Control
Chlordane	0.5 mg/m ³	100 mg/m ³	Present in groundwater.	Inhalation, absorption, ingestion, dermal contact.	Blurred vision, delirium, cough, abdominal pain, nausea, vomiting, diarrhea (carcinogen).	Dust Control

Notes: Heptachlor changes to HE once mixed with water (including in the body).

PEL is the Permissible Exposure Limit for an 8 hour day.

mg/m³ = milligrams per cubic meter

6. Physical Hazards of Concern N/A

Hazard	Description	Location	Procedures Used to Minimize Hazard
Drill rig, fork lift, and support vehicles	Moving parts of drill rig, forklift, and the support vehicles can be locations of falling and flying objects and pinch/crush points	Near drill rig for drilling and installation of two monitoring wells	Alert observation of surroundings; minimize time spent near drill rig and get driller's attention before approaching drill rig, forklift, or any vehicle; no loose clothing.
Open excavation	Excavations greater than 4 ft deep pose a hazard of falls and sidewall collapse	Around excavations	Personnel will not be allowed to enter excavations greater than 4 ft deep without shoring. Confirmation soil samples will be collected using an excavator bucket. While in an excavation less than 4 ft deep, workers' heads must not be allowed to break the plane of the top of the excavation so that in the case of a sidewall collapse, the worker's head and upper body are not buried.
Weather stress	Exposure to hot or cold temperatures, wind, and or rain	All areas of the site	Have drinking water accessible, wear appropriate clothing (light for heat, warm for cold), wear sunscreen protection, avoid caffeine, work in the shade when possible, and take short breaks in the shade as needed.
Slips, trips, and falls	Uneven terrain and drilling equipment	All areas of the site	Visual observations of terrain and hazards. Keep work area clear of debris.
Overhead and underground utilities	Damage to utilities through drilling and excavations	Around work area	Client to provide utility maps and a public utility locating service will be utilized. No raised drill rig towers within 20 ft of overhead power lines.
Travel to and from site	Operating motor vehicle in traffic on highways and rural roads.	Route to and from site from Landau Associates office	Operate motor vehicle while well rested and physically able to drive safely. Conduct pre-trip vehicle inspection, all vehicles to be maintained and in good working order. Obey all traffic laws including no cell phone use while driving. Secure all cargo properly to avoid shifting. Allow sufficient time for travel to site at safe speeds. Engage emergency brake when parking vehicles. Establish a planned route prior to departure. Be observant of unsafe road conditions and erratic/dangerous drivers.

7. Work Location Instrument Readings N/A

Location:	
Percent O ₂ :	Percent LEL:
Radioactivity:	PID:
FID:	Other:
Other:	Other:
Other:	Other:

Location:	
Percent O ₂ :	Percent LEL:
Radioactivity:	PID:
FID:	Other:
Other:	Other:
Other:	Other:

Location:	
Percent O ₂ :	Percent LEL:
Radioactivity:	PID:
FID:	Other:
Other:	Other:
Other:	Other:

Location:	
Percent O ₂ :	Percent LEL:
Radioactivity:	PID:
FID:	Other:
Other:	Other:
Other:	Other:

8. Hazards Expected in Preparation for Work Assignment N/A

Describe: [Click here to enter text.](#)

C. Personal Protective Equipment

1. Level of Protection

A B C D (Modified)

Location/Activity: All

A B C D

Location/Activity: If action levels (Attachment A) are exceeded.

2. Protective Equipment (specify probable quantity required)

Respirator N/A

SCBA, Airline

Full-Face Respirator

Half-Face Respirator (Cart. organic vapor) (Only if upgrade to Level C)

Escape mask

None

Other:

Other:

Clothing N/A

Fully Encapsulating Suit

Chemically Resistant Splash Suit

Apron, Specify:

Tyvek Coverall

Saranex Coverall

Coverall, Specify

Other: Dedicated field clothing, highly visible safety vest

Head & Eye N/A

Hard Hat

Goggles

Face Shield

Safety Eyeglasses

Other: Hearing protection

Hand Protection N/A

Undergloves; Type: Nitrile

Gloves; Type:

Overgloves; Type:

None

Other:

Foot Protection N/A

Neoprene Safety Boots with Steel Toe/Shank

Disposable Overboots

Other: Chemical Resistant Steel-Toe

Work Boots

3. Monitoring Equipment N/A

0 CGI

0 O₂ Meter

0 Rad Survey

0 Detector Tubes (optional)

Type:

0 PID

0 FID

0 Other

D. Decontamination

Personal Decontamination Required Not Required

If required, describe: Decontaminate exposed skin before each break in the work shift and before eating or drinking using hot water and soap. Use disposable PPE and discard as solid waste. Avoid hand to mouth contact.

Equipment Decontamination Required Not Required

If required, describe: Decontamination of non-dedicated sampling equipment soil and groundwater sampling equipment with dry methods (brushing, scrubbing) and/or Alconox/tap water solution followed by tap water rinse. Field staff will be prepared to set up a wash sink on site. All contaminated water will be stored onsite.

E. Activities Covered Under This Plan

Task No.	Description	Preliminary Schedule
1	Monitoring well decommissioning and replacement; well development; initial sampling	September through October 2018
2	Excavation and disposal of contaminated soil; confirmation soil sampling	September through October 2018
3	Groundwater sampling	October 2018

Emergency Facilities and Numbers

Hospital: Capital Medical Center, 3900 Capital Mall Drive SW, Olympia, Washington 98502
 Telephone: 360-754-5858
 Directions: Attachment B

Urgent Care Clinic: Urgent Care South, 6981 Littlerock Road SW #101, Olympia Washington ,
 Telephone: 360-943-3633
 Directions: Attachment C

Emergency Transportation Systems (Fire, Police, Ambulance) -- 911

Emergency Routes – Maps (Attachment B and C)

Emergency Contacts:

Name	Offsite	Onsite
Toni Smith	253-926-2493	208-275-9785
Eric Weber	253-926-2493	206-940-2406
Christine Kimmel	425-778-0907	206-786-3801

In the event of an emergency, do the following:





1. Call for help as soon as possible. Call 911. Give the following information:
 - a. WHERE the emergency is – use cross streets or landmarks
 - b. PHONE NUMBER you are calling from
 - c. WHAT HAPPENED – type of injury
 - d. WHAT is being done for the victim(s)
 - e. YOU HANG UP LAST – let the person you called hang up first.
2. If the victim can be moved, paramedics will transport to the hospital. If the injury or exposure is not life-threatening, decontaminate the individual first. If decontamination is not feasible, wrap the individual in a blanket or sheet of plastic (avoiding the head and face) prior to transport.

In the event of a non-emergency injury, do the following:

1. Ask the injured person if you can help them.
2. Administer first aid to the skill level for which you have been trained and feel comfortable performing. If you are unsure if the emergency is life threatening or not, immediately call 911 and follow the steps above.
3. If the injury is minor, but some medical attention beyond the skills of site workers is required after administering first aid, the victim can be transported to the hospital following decontamination, if necessary. The directions to the nearest *Urgent Care Clinic* is provided in Attachment C.

Health and Safety Plan Approval/Sign Off Form

I have read, understood, and agreed with the information set forth in this Health and Safety Plan (and attachments) and discussed in the Personnel Health and Safety briefing.

Click here to enter text.		Click here to enter text.
Name	Signature	Date
Click here to enter text.		Click here to enter text.
Name	Signature	Date
Click here to enter text.		Click here to enter text.
Name	Signature	Date
Click here to enter text.		Click here to enter text.
Name	Signature	Date
Toni Smith		January 19, 2017
Task Manager	Signature	Date
Sierra Mott		January 19, 2017
Site Safety Coordinator	Signature	Date
Christine Kimmel		January 19, 2017
LAI Health and Safety Manager	Signature	Date
Eric Weber		January 19, 2017
Project Manager	Signature	Date


Personnel Health and Safety Briefing Conducted by:

Sierra Mott		Click here to enter text.
Name	Signature	Date

Attachment A
Action Levels for Respiratory Protection

Monitoring Parameter	Reading	Level of Protection
Dust	Visible Dust	Apply moisture to soil, if dust persists then upgrade to Modified Level D PPE and monitor dust level at work perimeter

Attachment B Directions to Hospital




A 9805 Blomberg St SW, Olympia, WA 98512

- | | | |
|----|---|---------------------------|
| 1. | Head north on Blomberg St SW toward 93rd Ave SW
About 54 secs | go 0.4 mi
total 0.4 mi |
| | 2. Take the 1st right onto 93rd Ave SW
About 2 mins | go 0.7 mi
total 1.1 mi |
| | 3. Turn left to merge onto I-5 N
About 5 mins | go 4.8 mi
total 5.8 mi |
| | 4. Take exit 104 to merge onto US-101 N toward Aberdeen/Port Angeles
About 2 mins | go 1.7 mi
total 7.6 mi |
| | 5. Take the Black Lake Blvd exit toward W Olympia | go 0.4 mi
total 8.0 mi |
| | 6. Keep right at the fork, follow signs for West Olympia and merge onto Black Lake Blvd SW | go 0.2 mi
total 8.1 mi |
| | 7. Turn left onto Cooper Point Rd SW
About 52 secs | go 0.4 mi
total 8.5 mi |
| | 8. Turn left onto Capital Mall Dr SW
About 2 mins | go 0.6 mi
total 9.1 mi |
| | 9. Turn right | go 312 ft
total 9.2 mi |
| | 10. Turn left
Destination will be on the right | go 75 ft
total 9.2 mi |

B **Capital Medical Center**
3900 Capitol Mall Dr SW, Olympia, WA 98502

Attachment C Directions to Urgent Care Center



9805 Blomberg Street Southwest

Olympia, WA 98512

- ↑ 1. Head north on Jones Rd SW toward 93rd Ave SW
- ↶ 2. Turn left onto 93rd Ave SW
- ↷ 3. Turn right onto Littlerock Rd SW
- 📍 4. At the traffic circle, take the 2nd exit and stay on Littlerock Rd SW
- 📍 5. At the traffic circle, take the 3rd exit onto 70th Ave SW
[i](#) Destination will be on the right

6981 Littlerock Road Southwest

Tumwater, WA 98512

Sampling and Analysis Plan

**Sampling and Analysis Plan/
Quality Assurance Project Plan
Webster Nursery
Tumwater, Washington**

October 31, 2017

Prepared for


Washington State Department of Natural Resources
Olympia, Washington




2107 South C Street
Tacoma, WA 98402
(253) 926-2493

**Sampling and Analysis Plan/Quality Assurance Project Plan
Webster Nursery
9805 Blomberg Street SW
Tumwater, Washington**

This document was prepared by, or under the direct supervision of, the technical professionals noted below.

Document prepared by: 
Danille Jorgensen, Environmental Data Manager

Document reviewed by: 
Toni Smith, Senior Project Hydrogeologist/Project Manager

Date: October 31, 2017
Project No.: 0774006.020.024
File path: Y:\774\006\R\RAWP\RAWP_Final_Oct2017\Final\Appendices\App C\sig page.docx
Project Coordinator: Juliann Cooley

TABLE OF CONTENTS

	<u>Page</u>
1.0 INTRODUCTION	1-1
2.0 PROJECT ORGANIZATION AND RESPONSIBILITY	2-1
2.1 Management Responsibilities	2-1
2.2 Quality Assurance Responsibilities	2-1
2.3 Laboratory Responsibilities	2-1
2.4 Field Responsibilities	2-2
3.0 QUALITY ASSURANCE	3-1
3.1 Data Quality Objectives	3-1
3.2 Data Quality Indicators	3-1
3.2.1 Precision	3-1
3.2.2 Accuracy	3-1
3.2.3 Representativeness	3-2
3.2.4 Comparability	3-2
3.2.5 Completeness	3-2
3.3 Quality Control Procedures	3-2
3.3.1 Field Quality Control Procedures	3-2
3.3.1.1 Preventative Maintenance/Calibration Procedures	3-3
3.3.1.2 Sampling, Documentation, and Custody Procedures	3-3
3.3.2 Laboratory Quality Control Procedures	3-3
3.3.2.1 Analytical Methods and Reporting Limits	3-3
3.3.2.2 Instrument Calibration and Maintenance	3-4
3.3.2.3 Documentation	3-4
4.0 SAMPLE HANDLING, DOCUMENTATION, AND CUSTODY PROCEDURES	4-1
4.1 Sample Handling and Transport	4-1
4.1.1 Sample Packaging and Shipping	4-1
4.2 Sample Custody and Documentation	4-1
4.2.1 Documentation	4-1
4.2.1.1 Field Notebook	4-2
4.2.1.2 Field Sampling Forms	4-2
4.2.1.3 Photographs	4-2
4.2.2 Sample Custody	4-2
4.2.2.1 Field Custody Procedures	4-3
4.2.2.2 Sample Shipment Custody Procedures	4-3
4.2.2.3 Transfer of Custody	4-3
4.2.2.4 Laboratory Custody Procedures	4-3
5.0 DATA REDUCTION, VALIDATION, AND REPORTING	5-1

6.0	CORRECTIVE ACTIONS.....	6-1
7.0	FIELD INVESTIGATION PROCEDURES	7-1
7.1	Monitoring Wells.....	7-1
7.1.1	Well Decommissioning	7-1
7.1.2	Well Drilling Methods.....	7-1
7.1.3	Well Installation	7-1
7.1.4	Pre-Packed Well Screens	7-1
7.1.5	Well Riser.....	7-2
7.1.6	Well Seal	7-2
7.1.7	Surface Completion	7-2
7.1.8	Well Development.....	7-2
7.1.9	Well Construction Logs.....	7-3
7.1.10	Well Development Logs	7-3
7.1.11	Well Surveying	7-4
7.2	Sampling	7-4
7.2.1	Confirmation Soil Sampling.....	7-4
7.2.2	Confirmation Soil Sampling Procedures.....	7-4
7.2.2.1	Stockpile Sampling.....	7-5
7.2.2.2	Wastewater Sampling	7-6
7.2.2.3	Groundwater Monitoring.....	7-6
7.2.3	Sampling Designation and Labeling.....	7-7
7.2.3.1	Groundwater Sample Designation	7-7
7.2.3.2	Soil Sample Designations	7-7
7.2.3.3	Sample Container Labels.....	7-7
7.3	Decontamination Procedures.....	7-8
7.3.1	Heavy Equipment	7-8
7.3.2	Sampling Equipment.....	7-8
7.3.3	Personnel.....	7-8
8.0	REFERENCES.....	8-1

FIGURES

<u>Figure</u>	<u>Title</u>
1	SW-10 Well Log
2	SW-11 Well Log

TABLES

<u>Table</u>	<u>Title</u>
1	Measurement Quality Objectives
2	Sample Containers, Preservatives, and Holding Times
3	Reporting Limit Goals

LIST OF ABBREVIATIONS AND ACRONYMS

ARI.....	Analytical Resources, Incorporated
CAP.....	Cleanup Action Plan
CLP.....	Contract Laboratory Program
COC.....	chain-of-custody
CUL.....	cleanup level
DQI.....	data quality indicator
DQO.....	data quality objective
DP.....	direct-push
Ecology.....	Washington State Department of Ecology
EDD.....	electronic data deliverable
ELAP.....	Environmental Laboratory Accredited Program
EPA.....	US Environmental Protection Agency
HASP.....	Health and Safety Plan
HE.....	heptachlor epoxide
ID.....	identification
LAI.....	Landau Associates, Inc.
LCS.....	laboratory control sample
LCS D.....	laboratory control sample duplicate
LL.....	low-level
µg/L.....	micrograms per liter
MQO.....	measurement quality objective
MS.....	matrix spike
MSD.....	matrix spike duplicate
MTCA.....	Model Toxics Control Act
QA.....	quality assurance
QAPP.....	quality assurance project plan
QC.....	quality control
RAWP.....	remedial action work plan
RPD.....	relative percent difference
SAP.....	sampling and analysis plan
SOP.....	standard operating procedure
TA.....	TestAmerica Laboratories, Inc.
WAC.....	Washington Administration Code

This page intentionally left blank.

1.0 INTRODUCTION

This Sample and Analysis Plan/Quality Assurance Project Plan (SAP/QAPP) describes field sampling and laboratory analytical procedures that will be followed during completion of cleanup activities at the Webster Nursery site (Site) located south of Tumwater, Washington. Soil and groundwater at the Site is affected by a historical release of organochlorine pesticides from an underground storage tank. The proposed cleanup consists of soil removal, confirmation soil sampling, decommissioning wells, and replacing two groundwater monitoring wells located in the area proposed for excavation, sampling of stockpiled clean soil, and groundwater sampling. A detailed description of the Site and cleanup objectives is provided in the Feasibility Study (LAI 2016), Cleanup Action Plan (CAP; Ecology 2016), and Remedial Action Work Plan (RAWP; to which this SAP/QAPP is appended).

The purpose of this plan is to provide sampling and analysis methodologies consistent with accepted procedures that will maintain accuracy, reproducibility, and comparability of data during sampling events. This SAP/QAPP has been prepared in accordance with the requirements of Washington Administrative Code (WAC) 173-340-820 to support the tasks specified in the Washington State Department of Ecology (Ecology) Webster Nursery CAP (Ecology 2016). This SAP/QAPP also references the Site Health and Safety Plan (HASP) presented in Appendix B of the RAWP.

2.0 PROJECT ORGANIZATION AND RESPONSIBILITY

The responsibilities of key project personnel are defined below.

2.1 Management Responsibilities

Toni Smith, Landau Associates, Inc. (LAI) Project Manager

The project manager will have overall responsibility for project implementation consistent with the approved RAWP, and will be responsible for maintaining quality assurance (QA). Tasks include:

- Prepare and review the RAWP, HASP, SAP/QAPP and other key project plans
- Coordinate permitting and pre-construction activities
- Coordinate field activities
- Monitor project activity and quality
- Provide regulatory and technical consulting
- Coordinate proper handling and disposal of excavated soil.

2.2 Quality Assurance Responsibilities

Danille Jorgensen and Kristi Schultz, LAI Data Specialists

The data specialist will be responsible for the management and integrity of analytical and field data generated for this project. Tasks include the following:

- Laboratory coordination and oversight
- Verification and validation of analytical data in accordance with this SAP/QAPP, LAI standard operating procedures (SOPs,) and US Environmental Protection Agency (EPA) Contract Laboratory Program (CLP) guidelines as applicable
- Management and maintenance of the project's structure query language (SQL) server database, which uses the EarthSoft EQulS™ data management system
- Data queries and reporting from the EQulS database
- Submittals to Ecology's Environmental Information Management (EIM) database
- Advising on data corrective action procedures.

2.3 Laboratory Responsibilities

TestAmerica Laboratories, Inc. (TA) located in Tacoma, Washington, is an Ecology-accredited laboratory and will perform soil analyses and related analytical services in support of cleanup activities described in the RAWP. In order to identify detections above the groundwater cleanup level (CUL; 0.0048 micrograms per liter [$\mu\text{g/L}$]), groundwater monitoring analyses are anticipated to be performed by the Analytical Resources, Inc. (ARI) laboratory in Tukwila, Washington, also an Ecology-accredited laboratory, using the EPA 8081B low-level (LL) method.

2.4 Field Responsibilities

Sierra Mott, LAI Field Lead

The field lead will be responsible for leading and coordinating field activities including documentation, sampling, and sample handling. The field lead will report directly to the LAI project manager. Tasks include the following:

- Coordinating with the LAI project manager
- Coordinating and managing field and laboratory activities, including sampling
- Documenting and reviewing field data including field measurements and monitoring
- Following the schedule of work
- Coordinating and overseeing subcontractors
- Drafting the cleanup action completion report.

3.0 QUALITY ASSURANCE

This section presents the QA and quality control (QC) objectives and processes including data quality objectives (DQOs), measurement quality objectives (MQOs), data quality indicators (DQI), and QC procedures for field and laboratory work.

3.1 Data Quality Objectives

DQOs specify the environmental decisions that the data will support and the corresponding level of datum quality required to ensure decisions are based on sound scientific data. The DQOs for this project are to collect data in support of the selected remedial action as detailed in the 2016 CAP, which is being implemented to remove heptachlor epoxide (HE) concentrations in shallow water through excavation of HE-affected soil near the seasonal water table. Data will also be collected in support of documenting the performance of the remedial excavation. While HE is the primary chemical of concern at the Site, soil and groundwater samples will be analyzed for organochlorine pesticides by EPA Method 8081B. Data will be compared to the Model Toxics Control Act (MTCA) Method B soil CULs protective of groundwater, as listed in Table 1 of this plan.

3.2 Data Quality Indicators

DQIs are used to establish quality objectives and are discussed in detail below. A summary of DQIs and their associated MQOs is presented in Table 2.

3.2.1 Precision

Precision is a measure of variability in the results of replicate measurements due to random error (Ecology 2004). Precision is best expressed in terms of the standard deviation or relative percent difference (RPD). QC sample types that can be used to evaluate precision include field and laboratory duplicates, matrix spike duplicates (MSD), and laboratory control sample duplicates (LCSD). The precision of duplicate measurements will be expressed as an RPD, which is calculated by dividing the absolute value of the difference of the two measurements by the average of the two measurements, and expressing as a percentage. The formula for RPD calculation is shown below:

$$RPD = \left[\frac{|D1 - D2|}{[(D1 + D2) \div 2]} \right] \times 100\%$$

Where:

D1 = first measurement value and

D2 = second measurement value (duplicate)

3.2.2 Accuracy

Accuracy is a combination of precision and bias, in that it represents the degree to which a measured value represents the known value (Ecology 2004). Accuracy is expressed as the percent recovery of spiked samples (matrix spike [MS], laboratory control sample [LCS], and surrogate spike). The general

formula used to calculate percent recovery is shown below, for MS/MSD percent recovery the result from the unspiked sample is taken into account in the formula:

$$\%R = \left[\frac{SSR}{C_s} \right] \times 100\%$$

Where:

%R = Percent Recovery

SSR = Spiked Sample Result

C_s = Concentration of the Spike Added

3.2.3 Representativeness

Representativeness is an indicator of how accurately a result reflects the desired characteristic(s) of a defined population, accounting for both temporal and spatial variability (Ecology 2004).

Representativeness qualitatively describes how well the analytical data characterize an area of concern. Representativeness is largely determined by the sampling design; analytical parameters for use in its evaluation include method-specified holding times and preservation requirements, and matrix heterogeneity. The sampling design for this project is discussed in Section 7.2.

3.2.4 Comparability

Comparability is the “degree of confidence with which one data set can be compared to another” (EPA 2004). QC procedures and MQOs as stated in this plan will provide for measurements that are consistent and representative of the media and conditions measured.

3.2.5 Completeness

Completeness is a measure of “the amount of valid data obtained from a measurement system compared to the amount that could be expected to be obtained under normal conditions” (EPA 1988). Field completeness is calculated as the number of actual samples collected divided by the number of planned samples. Analytical completeness is calculated as the number of valid data points divided by the total number of data points requested. Data points are considered invalid if they are rejected during data validation. The data validation approach for this project is provided in Section 5.0.

3.3 Quality Control Procedures

This section describes QC procedures which will be implemented in the field and in the laboratory.

3.3.1 Field Quality Control Procedures

QC procedures to be implemented in the field include preventative maintenance/calibration of field instruments, sampling, documentation, and custody procedures.

3.3.1.1 Preventative Maintenance/Calibration Procedures

Field instruments will be properly operated, calibrated, and maintained by qualified personnel according to the manufacturer's guidelines and recommendations. Periodic schedules for preventive maintenance of any field instruments used during the project, including equipment testing, parts replacement, and general cleaning will be followed according to the manufacturer's instructions. Field equipment performance will be evaluated against check standards and calibration blanks, as appropriate, for each parameter before use and at least once during a sampling day or when meter drift is suspected.

Documentation of routine and special preventive maintenance and calibration information will be maintained in a field or laboratory logbook or reference file and will be available upon request. Each maintenance and calibration logbook entry will include the date and initials of the individual performing the activity.

3.3.1.2 Sampling, Documentation, and Custody Procedures

Soil and groundwater samples submitted to the analytical laboratory for analysis will be collected in the appropriate sample containers provided by the laboratory. The samples will be preserved by cooling to a temperature of less than 6 degrees Celsius and, as required, by the analytical method. Sample extraction and analysis will be performed by the analytical laboratory within the recommended holding times. Sample containers, preservatives, and holding times for each chemical analysis are presented in Table 3.

3.3.2 Laboratory Quality Control Procedures

Laboratory analyses for all constituents will be conducted by a laboratory that is certified through the Environmental Laboratory Accreditation Program (ELAP). The laboratory is required to maintain current certification through the duration of time they are performing analytical work for this project. This section describes the QC procedures to be implemented by TA located in Tacoma, Washington and ARI, which are the selected and anticipated analytical laboratories, respectively.

3.3.2.1 Analytical Methods and Reporting Limits

Groundwater and soil samples collected during the excavation, confirmation, and compliance monitoring sampling events will be analyzed for organochlorine pesticides by EPA Method 8081B LL and EPA Method 8081B, respectively. The laboratories shall be qualified to perform the analyses using standard, documented laboratory analytical procedures. All analytical work shall be performed in accordance with this plan, TA's Quality Systems Manual, and ARI's Quality System Manual.

To confirm that soil containing concentrations of contaminants above the cleanup standards is removed and that soil remaining on-site following cleanup meets the cleanup standards to the extent practicable, MTCA Method B CULs protective of groundwater will be achieved by the laboratory's reporting limits, as opposed to the method detection limits. Reporting limit goals and CULs for each

constituent are identified for each analysis. These are only goals because instances may arise where high sample concentrations, non-homogeneity of samples, dry weight reporting, or matrix interferences preclude achieving the desired reporting limits and associated QC criteria. If this occurs, the laboratory will report the reason(s) for deviations from these reporting limits or non-compliance with QC criteria.

3.3.2.2 Instrument Calibration and Maintenance

The analytical laboratory project manager is responsible for maintaining laboratory instruments in proper working order, including routine maintenance and calibration, and training of personnel in maintenance and calibration procedures. Laboratory instruments will be properly calibrated with appropriate check standards and calibration blanks for each parameter before beginning each analysis. Instrument performance check standards, where required, and calibration blank results will be recorded in a laboratory logbook dedicated to each instrument. At a minimum, the preventive maintenance schedules contained in the EPA methods and in the equipment manufacturer's instructions will be followed.

3.3.2.3 Documentation

Analytical data will be provided by the laboratory in an electronic (pdf) report format and an electronic data deliverable (EDD). Both laboratory deliverables will be saved in the project folder, which is on a secure server that is routinely backed up. LAI uses EQuIS environmental data management software for querying and reporting analytical data. Project EDDs will be reviewed to the laboratory report for QA/QC and completeness and then loaded to the project's EQuIS database. Laboratory data reports for this project will be an EPA Tier II equivalent and at a minimum, will include the following:

- Both field and laboratory sample identification number
- Case narrative, including adherence to prescribed protocols, non-conformity events, corrective measures, and/or data deficiencies
- Sample analytical results
- The sample date, the date it was received at the laboratory, and the date that it was extracted and/or analyzed
- The quantified concentration
- The method reporting limit
- Units for reporting
- Laboratory QC sample results (including date and time of analysis, method, and acceptability criteria), such as:
 - Data qualifiers assigned by the laboratory, with definitions presented in each report
 - Surrogate recoveries
 - MS/MSD results

- LCS/LCSD results
- Laboratory duplicate results
- Blank results
- Sample custody (including signed, original chain-of-custody [COC] records, and documentation of condition of custody seals)
- ELAP certification number and method listing.

Upon receipt of laboratory data, the LAI data specialist and project manager will review the data for completeness and format. If any error is noted in the laboratory report, the laboratory will be informed and appropriate corrective action will be performed, including review of raw data, assigning a data qualifier to the sample result, and/or reanalysis of the sample. For minor corrections (such as misspelled sample names), the individual making the correction shall cross a line through the error, enter the correct information, and initial and date the correction.

4.0 SAMPLE HANDLING, DOCUMENTATION, AND CUSTODY PROCEDURES

Sample handling and documentation procedures are summarized in this section. These procedures and protocols for sampling activities were developed to meet the DQOs of the CAP, and are based on proven and acceptable sampling methods as established by EPA guidance documents, Washington State regulations, and professional judgment. Sample preservation and storage requirements are provided in Table 2.

4.1 Sample Handling and Transport

Sample collection procedures and protocols for each sampling activity are described in detail in Section 7.2 of this SAP/QAPP. Sample containers, preservatives, and holding times (Table 3) will vary according to the type of sample collected and the analytical method to be used. Strict precautions will be taken to adhere to maximum sample holding times. Each sample will be documented, labeled, and identified as noted below.

4.1.1 Sample Packaging and Shipping

The following procedures will be followed:

- Samples will be packaged and transported in a manner that protects the integrity of the sample and prevents detrimental effects due to the possible hazardous nature of samples.
- Samples will be placed on sealed, reusable ice packs or ice that is double-bagged using Ziploc® bags in coolers immediately after collection. At the end of each day, samples will be inventoried and sent to the analytical laboratory in a lined cooler containing ice.
- Samples will be packaged carefully to avoid breakage or cross contamination using sufficient packing material. The COC forms accompanying the samples to the laboratory will be placed inside a separate plastic Ziploc bag and taped inside the cooler lid.
- The samples will generally will be delivered to the laboratory in person or shipped by a commercial overnight carrier. If shipped using an overnight carrier, the shipping container will be taped shut with strapping tape and custody seals.

4.2 Sample Custody and Documentation

Sample documentation includes field notes, field sampling forms, field photographs, and container labels. Sample custody procedures include field, shipment, transfer, and laboratory custody procedures.

4.2.1 Documentation

Documentation necessary to meet the field QA objectives for this project includes:

- Field notebooks (logbooks) in which general field observations and activities are recorded
- Field sampling forms specific to sampling (COC, etc.)

- Sample container labels.

If an error is made on any field documentation, corrections will be made by drawing a single line through the error and entering the correct information. Whenever possible, errors will be corrected by the person who made the entry. Corrections will be initialed, dated, and, if necessary, a footnote explaining the correction will be included. The erroneous information will not be discarded. All field documentation and project records will be filed to prevent loss, damage, or alteration. Access to any archived project files or laboratory data will be controlled to maintain integrity of the documentation

4.2.1.1 Field Notebook

Daily field documentation of individual field tasks will be recorded to provide sufficient data and observations to enable participants to reconstruct events that occurred during the project and to refresh the memory of the field personnel if called upon to give testimony during legal proceedings. Corrections will be made as explained above. Information documented on field sampling forms need not be repeated in the field notes; however, reference must be made in the field notes to the field forms.

4.2.1.2 Field Sampling Forms

To aid in achieving complete data, field-sampling forms (e.g., COC record, sample collection form, etc.) will be used to document sampling activities.

4.2.1.3 Photographs

Photographs may be taken in the field to document sampling locations and conditions. When taken, time and date of photographs will be recorded in field notes and the photograph archived as an electronic file for future use.

4.2.2 Sample Custody

The primary objective of sample custody is to create an accurate record that can be used to trace the possession and handling of samples so their quality and integrity can be documented and maintained from collection until completion of all required analyses. Adequate documentation of sample custody will be achieved by means of the COC record initially completed by the sampler, and thereafter signed by each individual who accepts custody of the sample. A sample will be considered to be in custody under the following conditions:

- A handler has the sample in physical possession
- The handler has the sample in view
- The sample is locked or secured in a locked container or otherwise sealed so that tampering will be evident
- The sample is kept in a secured area, restricted to authorized personnel only.

Sample control and COC in the field and during transport to the laboratory will be conducted in general conformance with the procedures described below.

4.2.2.1 Field Custody Procedures

The following field custody procedures will be followed:

- As few persons as possible will handle samples
- Sample bottles will be obtained new or pre-cleaned from the laboratory performing the analyses
- The person collecting the sample will be responsible for completing the COC record and for the care and custody of collected samples until they are transferred to another person under standard COC procedures
- The LAI field representative will oversee field custody procedures during the fieldwork and in the event of non-compliance, will determine if corrective action is required.

4.2.2.2 Sample Shipment Custody Procedures

The following custody sample shipment procedures will be followed:

- The coolers in which the samples are shipped will be accompanied by the COC record identifying their contents. The original record and laboratory copy will accompany the shipment (sealed inside the shipping container). The other copy will be distributed, as appropriate, to the LAI project manager.
- If the samples are to be shipped via a commercial carrier, shipping containers will be sealed with custody seals for shipment to the laboratory. The method of shipment, name of courier, and other pertinent information will be entered in the remarks section of the COC record.

4.2.2.3 Transfer of Custody

When samples are transferred, the individual(s) relinquishing and receiving the samples will sign the COC record and document the date and time of transfer. The person who collected the sample(s) will sign the form in the first signature space. If the samples are shipped via commercial carriers, the COC records will be sealed inside the sample container before delivery and the custody signature will be from the person who receives the samples from the carrier at its final destination. Each person taking custody will evaluate the integrity of the shipping container seal and note any observations on the COC record. Project documentation of sample custody will be verified during regular review of the laboratory data package(s).

4.2.2.4 Laboratory Custody Procedures

A designated sample custodian at the laboratory will accept custody of the shipped samples and certify that the sample identification numbers match those on the COC record. The custodian will log the sample identification numbers and requested analyses in accordance with laboratory QA/QC protocols. The laboratory will maintain sample security and custody throughout the analytical process.

5.0 DATA REDUCTION, VALIDATION, AND REPORTING

Analytical reports from the laboratory for this project will be accompanied by QC results and any other necessary analytical information to enable reviewers to determine the quality of the data. The LAI quality reviewer for this project is responsible to the LAI project manager for conducting checks for internal consistency, transmittal errors, laboratory protocols, and for complete adherence to the QC elements in this SAP/QAPP. The LAI data specialist will be responsible for conducting checks for adherence to the QC elements specified in this SAP/QAPP and for performing an EPA-equivalent Level IIA validation, the components of which are listed below. Level IIA validation is performed primarily from information contained on sample result forms and sample related QC summary forms; raw data is not reviewed during this process:

- Case Narrative
- COC documentation
- Sample receipt and condition documentation
- Sample summary or equivalent
- Method summary or equivalent
- Sample results with date, units, and reporting limits
- Laboratory data qualifier definitions
- Contract Laboratory Program (CLP) equivalent forms
- Method/laboratory blank results
- Sample surrogate results
- Field QC results
- LCS/LCSD results
- MS/MSD results
- Lab duplicate results.

Data validation will be performed in accordance with applicable sections of the EPA CLP National Functional Guidelines for Organic Data Review (EPA 2014), analytical methods, LAI data validation SOPs, and this SAP/QAPP. If significant non-conformities are found, additional laboratory data may be evaluated. Corrective action, as described in Section 6.0, will be determined by the LAI project manager and may include any of the following responses:

- Rejection of the data and resampling
- Qualification of the data
- Modification of field and/or laboratory procedures.

Data qualification arising from data validation activities will be described in the reports summarizing the results of the supplemental investigation and compliance monitoring.

6.0 CORRECTIVE ACTIONS

Corrective action will be required if there are deviations from the methods or QA requirements established in this SAP/QAPP or if there are equipment or analytical malfunctions. Corrective action procedures will be implemented based on the type of unacceptable data and will be developed on a case-by-case basis. The following corrective actions may be included:

- Altering procedures in the field
- Using a different batch of sample containers
- Performing an audit of field or laboratory procedures
- Reanalyzing samples (if holding times allow)
- Resampling
- Evaluating sampling and analytical procedures to determine possible causes of the discrepancies
- Accepting the data with no action, acknowledging the level of uncertainty
- Qualification of the data
- Rejecting the data as unusable.

During field operations and sampling procedures, the field personnel will be responsible for conducting and reporting required corrective action. A description of any corrective action taken will be entered in the daily field notebook. If field conditions do not allow for conformance with this SAP/QAPP, the LAI project manager will be consulted immediately. For any corrective action or field condition resulting in a revision of this SAP/QAPP, the LAI project manager will authorize changes or exceptions to the SAP/QAPP, as necessary and appropriate.

During laboratory analysis, the laboratory QA officer will be responsible for taking required corrective actions in response to equipment malfunctions. If an analysis does not meet data quality goals outlined in this SAP/QAPP, corrective action generally will follow the guidelines in the EPA analytical methods noted in this SAP/QAPP and the EPA guidelines for data validation (EPA 1999, 2004, respectively). If analytical conditions are such that non-conformance with this SAP/QAPP is indicated, the LAI project manager will be notified as soon as possible so that any additional corrective actions can be taken.

The LAI project manager ultimately is responsible for implementation of appropriate corrective action and maintenance of a complete record of QC issues and corrective actions.

7.0 FIELD INVESTIGATION PROCEDURES

Field activities are expected to include monitoring well drilling, installation and decommissioning, soil sampling, and groundwater sampling. Procedures for sampling, sample handling, and documentation are described below.

7.1 Monitoring Wells

Existing monitoring wells SW-10 and SW-11 will be replaced by new monitoring wells SW-17 and SW-18, respectively (see Figure 4 of the RAWP). Well and boring logs for SW-10 and SW-11 are shown on Figures 1 and 2, respectively and should be referenced for consistency. The drilling subcontractor will drill and install monitoring wells under the oversight of an LAI field representative. The drilling contractor will be responsible for obtaining and submitting all well drilling permits, logs, and well identification (ID) tags as required by the State of Washington. Drilling and construction details are provided below.

7.1.1 Well Decommissioning

Wells SW-10 and SW-11 will be decommissioned according to regulation (WAC 173-160-460) prior to excavation. Wells will be decommissioned by pressure grouting or filling with bentonite chips. All piping and associated monuments can be left in place and removed during excavation.

7.1.2 Well Drilling Methods

New wells will be installed using direct-push (DP) drilling technology. DP is accomplished using a truck-mounted, track-mounted, or hand-portable DP rig. Depending on the manufacturer, make, and model, DP drill tooling is advanced by static push, pneumatic impact, or vibratory methods, or a combination thereof. In its standard configuration, DP drilling collects a continuous soil core in a 2.25-inch diameter core barrel with a removable polyethylene liner. Once the desired depth is reached, the core is extracted from the ground and the liner and soil core are removed from the core barrel.

7.1.3 Well Installation

All wells will be constructed in accordance with the state's Minimum Standards for Construction and Maintenance of Wells (WAC 173-360) or in accordance with a variance obtained from Ecology.

7.1.4 Pre-Packed Well Screens

The purpose of the well screen is to allow groundwater to easily enter the well while preventing entry of filter pack sand. Well screens will be constructed from pre-packed PVC well screens. Pre-packed screens help to assure that the sand pack is well distributed along the length of the screen, which can be difficult to achieve using DP drilling methods due the small diameter of the borehole. Well screens will be 10-ft long and factory-slotted with a slot size of 0.010 inch.

Filter pack is intended to minimize transport of fine-grained sediment into the well without restricting the flow of groundwater. The filter pack will consist of size 20-40 sand in a pre-packed screen (or equivalent). Additional equivalent sand will be poured slowly (to prevent bridging) into the annulus to approximately 1 ft above the screen as the drill casing is retracted. This 1 ft of filter pack sand above the top of the well screen will prevent migration of the overlying bentonite seal material into the screened intake zone. The volume of sand emplaced will be recorded on the well construction log.

7.1.5 Well Riser

A new, clean, flush-threaded, 2-inch-diameter PVC well riser will be installed from the top of the screen to the ground surface. The riser will be cut flat at the top. A small, V-shaped notch or other permanent mark will be made in the lip as a mark from which all future water level readings will be made. By convention, the notch will be located on the north side of the well riser pipe.

7.1.6 Well Seal

Granular bentonite will be used to construct the annular seal above the filter pack. Bentonite will be added slowly to minimize the potential for bridging.

7.1.7 Surface Completion

A concrete surface seal and well monument will constitute the surface completion. The concrete surface seal will be placed in the upper 2 ft of the boring.

Flush-mounted monuments (minimum of 6 inches in diameter) will be used. The top of the flush monument will be at least 1 inch, but not more than 2 inches above the surrounding surface grade to allow for drainage away from the well location. A concrete pad will be installed around monuments. No protective metal posts will be required.

7.1.8 Well Development

Well development will be performed 24 or more hours after well installation using the following procedures:

1. The depth to the bottom of the well shall be measured prior to beginning development.
2. Use a weighted 1.5-inch-diameter PVC or stainless steel bailer with a ceramic-ball check valve (or equivalent) to remove sand and fines from the bottom of the well casing. Carefully lower the bailer to the bottom of the well and gently raise and lower it to suspend the fines in the water column. Withdraw the bailer from the well and pour out (rinse if necessary) the fines and purged water. Repeat until no more sediment is retrieved from the bottom of the well.
3. Surge the well screen interval with the bailer or a surge block several times.
4. Pump water from the well using a centrifugal pump or airlift. Raise the pump intake incrementally to remove turbidity through the entire screened interval. Periodically record the pumping rate and the turbidity of discharged water. Continue pumping water from the well until the turbidity is significantly reduced.

5. Again, surge the well with the bailer or a surge block.
6. Measure and record the total depth of the well. Evaluate whether fines are present in the bottom of the casing.
7. Pump again and continue pumping until the well yields water with a turbidity of 10 nephelometric turbidity units (NTUs) or less, unless Ecology agrees that it is not practical to continue development to reach this criteria. If water was added to the well during drilling, a minimum of 200 percent of the volume of water added to the well must be purged during development. Record the final turbidity on the well development log.

Purge water shall be contained on-site and handled as described in Section 3.2.1.7 of the RAWP.

7.1.9 Well Construction Logs

A graphic log showing well construction details will accompany each boring log. Construction logs will include the following:

- Well location and designation
- Date completed
- Boring dimensions
- Ecology Well Tag ID Number
- Well screen and riser pipe material descriptions and lengths
- Composition and depths of filter pack materials, bentonite well seal, and surface concrete
- A description of the surface monument and protective mechanisms.

7.1.10 Well Development Logs

Well development logs will contain the following information:

- Well location and designation
- Screened interval and casing diameter
- Date and time of development
- Weather conditions
- Static water levels measured before and after development
- Total depth of well before and after development
- Volume of water in the well casing
- Descriptions of development equipment (pumps, surge blocks, hose/tubing diameter, etc.)
- Equipment calibration data
- A record showing water volumes purged from the well, purge rates, water quality parameter measurements (turbidity), and presence of fines in the bottom of the well.

7.1.11 Well Surveying

A licensed land surveying subcontractor will survey the horizontal and vertical coordinates of new monitoring well locations, as well as the vertical coordinates of existing monitoring wells. The vertical coordinates will be measured at the lip of the PVC well casing at the marked point that will be used for future groundwater measurements. Horizontal coordinates (x, y) will be measured to the nearest 0.1 ft and vertical (z) elevations will be measured to the nearest 0.01 ft. Horizontal coordinates will be measured in feet using Washington State Plane south zone coordinates referencing the North American Datum 1983. Vertical elevations will be measured referencing the North American Vertical Datum of 1988 (NAVD88).

7.2 Sampling

This section documents field procedures that will be used to collect confirmation soil samples and groundwater samples. Any variation or modification to these procedures that may become necessary will be coordinated with Ecology and documented in field records.

7.2.1 Confirmation Soil Sampling

Confirmation soil sampling will be performed during excavation. Four confirmation samples will be collected from the base of the excavation. Base samples will be collected approximately near the center of each slot. Additionally, one confirmation sample will be collected from each of the north, west, and east exterior sidewalls, and two confirmation samples will be collected from the south exterior sidewall, of the total proposed excavation. Sidewall samples will be collected at a depth corresponding to the depth of the maximum HE detection near the sample (see Figure 6 of the RAWP). Because trench boxes will block the walls of each slot, sidewall samples will be collected with the excavator bucket while the trench box is being advanced downward. The excavator bucket will be used to collect soil from below the exterior trench box wall at the selected location. Soil sample locations will be measured from fixed Site features (e.g., structures and monitoring wells) and plotted on a Site map in the field.

Confirmation soil samples will be submitted to the analytical laboratory for analysis on a standard turnaround time. Expedited turnaround times will not be employed in confirmation sample analyses as the extent of excavation will be limited by physical constraints rather than the extent of contamination. The excavation will be completed to the vertical and horizontal extents presented in the RAWP as practicable at the time of work, and open trenches will be backfilled at the completion of excavation and confirmation sampling as described in the RAWP.

7.2.2 Confirmation Soil Sampling Procedures

Discrete soil samples will be collected from the base and sidewalls of the excavated areas using decontaminated sampling utensils. Samples collected from the base of the excavation will be collected from the top 6 inches of undisturbed soil; samples collected from the excavation sidewalls

will be collected from a discrete depth corresponding to the depth of the maximum HE detection near the sample. The total depth of the excavation is anticipated to be 10 to 15 ft deep; therefore, to adequately protect workers, soil samples will be collected from the base and sidewalls of the excavation using the excavator bucket. Samples will be taken from a location within the bucket that is most representative of intact (least disturbed) soil and where soil is not in contact with the walls of the bucket.

Each soil sample will be placed directly into a clean laboratory-provided sample container and stored in a cooler with ice until delivery to the analytical laboratory. The location and soil conditions for each sample will be recorded on field notes. All sampling equipment will be cleaned in accordance with the decontamination procedures outlined in Section 7.3.2. Soil samples may be collected from depths below the groundwater table using the excavator bucket. One blind field duplicate soil sample will be collected during excavation.

Soil data is screened using the current MTCA Method B groundwater CUL for applicable constituents. The primary constituent of concern at the Site is HE. Confirmation soil samples will be analyzed for organochlorine pesticides by EPA Method 8081B at TA.

7.2.2.1 Stockpile Sampling

Clean soil will be stockpiled on site for use as backfill. Stockpiled soil will include imported clean fill and excavated soil that is expected to be clean. The contractor is required to obtain confirmation of the non-contaminated nature of imported clean fill from the supplier, including laboratory results from three discrete samples of the imported fill material, as specified in Section 3.3 of Appendix A. Additionally, the Owner's representative will confirm the non-contaminated nature of imported clean fill by collecting two, six-point composite soil samples from the imported clean fill stockpile to be analyzed for pesticides using EPA Method 8081B. Soil originating from the following sources and/or sites will not be acceptable (Ecology 2016b):

- a. Sites undergoing an environmental cleanup
- b. Agricultural sites where soils contain pesticides, herbicides or metals.
- c. Industrial and/or commercial sites where hazardous materials were used, handled or stored.
- d. Sites where petroleum hydrocarbons could have spilled or leaked into the soil.
- e. Street sweepings.
- f. Commercial sites including former gasoline service stations.

-
- g. Retail areas that contained dry cleaning facilities or photographic processing facilities, paint stores, auto repair and/or painting facilities.
 - h. Agricultural supply stores.
 - i. Industrial facilities including metal processing shops, manufacturing facilities, aerospace facilities, oil refineries, waste treatment plants, or other similar facilities.
 - j. Soil from a thermal desorption remediation or treatment process.
 - k. Soil from a biological remediation or treatment process.

To confirm the non-contaminated nature of excavated soil that is expected to be clean, two, six-point composite soil samples collected from the excavated clean soil stockpile will be analyzed for pesticides using EPA Method 8081B on an expedited (72-hour) turnaround time. If contaminants of concern are detected above applicable CULs in the excavated clean soil stockpile sample, the excavated clean soil stockpile will be handled and disposed of in the same manner as contaminated soil, and additional clean backfill material will be imported to compensate for the lost volume. If the soil sample does not exceed applicable CULs, the excavated clean soil stockpile will be used to backfill the excavation. Laboratory results will be provided in the Cleanup Action Completion Report.

7.2.2.2 Wastewater Sampling

Wastewater will be sampled for waste disposal profiling. Wastewater samples will be analyzed for pesticides by EPA Method 8081B and metals by Resource Conservation and Recovery Act (RCRA) 8 metals with mercury on an expedited (72-hour) turnaround time.

7.2.2.3 Groundwater Monitoring

The existing Site groundwater monitoring well network includes nine wells. Of the nine wells, six (SW-9, SW-14, SW-15, SW-16, SW-17 and SW-18) will be sampled as part of a long-term groundwater quality monitoring program for pesticides. Groundwater quality samples are collected using a peristaltic pump with dedicated tubing stationed at each well. Field parameters are collected while the well is being purged using a YSI multi-parameter probe. Purge water from sampling is collected in a 5-gallon bucket and is transported to and contained in onsite drums provided by Washington State Department of Natural Resources.

Groundwater data are screened using the current MTCA Method B groundwater CUL for applicable constituents. The primary constituent of concern at the Site is HE. Groundwater samples will be analyzed for organochlorine pesticides by EPA Method 8081B LL in order to achieve reporting limits at the HE CUL of 0.0048 µg/L. It is anticipated that groundwater monitoring samples will be analyzed by ARI in order to achieve the desired reporting limits.

7.2.3 Sampling Designation and Labeling

7.2.3.1 Groundwater Sample Designation

Each groundwater sample collected during groundwater monitoring will be identified by a unique sample designation, which will include the well name followed by the date of collection. For example, sample designation SW17-20170607 identifies a groundwater sample collected from well SW-17 on June 7, 2017.

7.2.3.2 Soil Sample Designations

Each confirmation soil sample will be identified by a unique sample designation. The sample designation will be included on the soil sample container and on the corresponding sample collection form. The designation system will include the sequential sample number of each sidewall or base sample and spatial information about the sample, as described below.

Excavation sidewall sample SW1-N-6, where:

- “SW” indicates sample was collected from the excavation sidewall
- “1” is the sequential sidewall sample number
- “N” indicates compass direction of the excavation sidewall
- “6” is the approximate depth in feet below original grade.

Thus, sample SW1-N-6 identifies the first sidewall sample and indicates the sample was collected from the north sidewall at a depth of approximately 6 ft below the original grade.

Excavation base sample B1-A-10.5, where:

- “B” indicates sample was collected from the excavation base
- “1” is the sequential base sample number
- “A” is the slot identifier or location
- “10.5” is the approximate depth in feet below original grade.

Thus, sample B1-A-10.5 identifies the first base sample and indicates the sample was collected from Slot A (or location A) at a depth of approximately 10.5 ft below the original grade.

7.2.3.3 Sample Container Labels

Each sample container will be labeled and sealed immediately after the sample is placed in the container. Sample container labels will be filled out using waterproof ink and will be firmly affixed to the sample containers. The sample container label will contain the following information:

- Soil Sample Designation
- Project name
- Date and time of collection
- Name of sampler(s)

- Preservation (if applicable).

Additional identifiers may be added, as necessary, based on the specific sampling activity. Actual sample locations and other identification information will be recorded in the field notes and on appropriate sample collection forms. Field QC samples (blind duplicates) will be coded as individual samples and identified in the field notes and on sample collection forms.

7.3 Decontamination Procedures

Decontamination procedures are designed to remove trace-level contaminants from sampling equipment and prevent cross-contamination between samples. Sampling equipment will be decontaminated before collecting each sample to avoid cross-contamination. Decontaminated sampling equipment will be handled in a manner that minimizes contact with potentially contaminated surfaces. Nitrile gloves will be worn when handling soil and groundwater samples. New disposable gloves will be used for collection of each sample.

7.3.1 Heavy Equipment

Before leaving the site, heavy equipment will be decontaminated until visually clean using dry methods (e.g., broom) on areas in contact with contaminated soil. If water is necessary for decontamination of large equipment, clean potable water will be used. This decontamination will be performed over a containment area (e.g., bermed area covered with plastic sheeting). Decontamination materials will be contained and managed along with investigation-derived wastes (RAWP Section 3.2.1.7).

7.3.2 Sampling Equipment

Decontamination procedures for sampling equipment will be used to minimize the possibility of cross-contamination. Sampling equipment that comes in contact with potentially contaminated material will be decontaminated before and after each use. Decontamination of sampling equipment will consist of the following steps and will be documented on the sample collection form:

1. Initial tap water rinse to remove large soil particles, if applicable
2. Alconox[®] and tap water wash
3. Tap water rinse
4. Deionized or distilled water rinse.

7.3.3 Personnel

Personnel decontamination procedures depend on the level of protection specified for a given activity. The HASP (Appendix B of the RAWP) identifies the appropriate level of protection for each type of fieldwork involved in the project, as well as appropriate decontamination procedures.

DRJ/TJS/EFW/jrc

[Y:\774\006\R\RAWP\RAWP_FINAL_OCT2017\FINAL\APP C\APPC_SAPQAPP.DOCX]

8.0 REFERENCES

- Ecology. 2004. Guidelines for Preparing Quality Assurance Project Plans for Environmental Studies. Publication No. 04-03-030. Washington State Department of Ecology. July.
- Ecology. 2016. Agreed Order No. DE 13181 In the Matter of Remedial Action by Washington State Department of Natural Resources. Washington State Department of Ecology. August 9.
- EPA. 1988. Interim Final: Guidance for Conducting Remedial Investigations and Feasibility Studies Under CERCLA. EPA/540/G-89/004. US Environmental Protection Agency. October.
- EPA. 1999. USEPA Contract Laboratory Program National Functional Guidelines for Organic Data Review. EPA 540/R-99/008. US Environmental Protection Agency. October.
- EPA. 2004. Final: USEPA Contract Laboratory Program National Functional Guidelines for Inorganic Data Review. US Environmental Protection Agency. October.
- EPA. 2014. National Functional Guidelines for Superfund Organic Methods Data Review, EPA-540-R-014-002. US Environmental Protection Agency. August.
- LAI. 2016. 2016 Feasibility Study Report Webster Nursery Site, Site ID 3380, Tumwater, Washington. Landau Associates, Inc. June.

Figure 1
SW-10 Well Log



TETRA TECH

GEOLOGIC LOG AND MONITORING
WELL CONSTRUCTION DIAGRAM

CLIENT DNR

SITE Webster Nursery

LOCATION SW-10

Contractor Cascade Drilling

Rig Type CME-55/HSA

Ground Surface Elevation 8/1/96

Bit Diameter 9" OD, 4" ID

Hole Diameter 9"

Logged By B. Carpenter

AS BUILT


PID Record (ppm)

Blow Count per 6-in Sampling Interval (ft)

Depth (feet)

Geology (USCS)

Geologic Log



ND

5/5/8

5

SM

Brown, loose, poorly graded silty SAND, grading to gray, medium SAND to gray-brown silty SAND, dry

ND

4/5/8

10

SP
SM

Water @ - 10.5'
Gray-brown, loose, poorly graded medium SAND, dry, grading to gray-brown silty-SAND, wet

ND

8/10/7

15

SP
ML

Gray-brown, loose, poorly graded, medium SAND, grading to gray-brown, medium stiff, poorly graded sandy SILT, wet (2" lense of sandy SILT in sand)

Total Depth - 16.5 feet

20

Figure 2
SW-11 Well Log



TETRA TECH

**GEOLOGIC LOG AND MONITORING
WELL CONSTRUCTION DIAGRAM**

CLIENT DNR
SITE Webster Nursery
LOCATION SW-11




Table C-1
Measurement Quality Objectives
Sampling and Analysis Plan/Quality Assurance Project Plan
Webster Nursery
Tumwater, Washington

DQI	QC Sample or Activity Used to Assess MQO	MQO	Sampling or Analytical DQI
Groundwater Samples Analyzed for Organochlorine Pesticides by EPA Method 8081B Low Level (ARI)			
Representativeness	Cooler Temperature	< 6°C	S
Bias	Surrogates	Recoveries within laboratory-specified control limits	A
Accuracy	LCS/LCSD	Recoveries within laboratory-specified control limits	A
Method performance for matrix, bias	MS/MSD	Recoveries within laboratory-specified control limits	S&A
Precision	LCS/LCSD and MS/MSD	RPDs within laboratory-specified control limits	A
Precision	Field Duplicates	RPD <25%	S&A
Bias/Contamination	Method Blank	Target analytes not detected at concentrations > 1/2 the RL	S&A
Analytical Completeness	Number of usable (not rejected) results out of total number of results	90%	S&A
Field Completeness	Number of samples collected out of planned samples	95%	S
Soil Samples Analyzed for Organochlorine Pesticides by EPA Method 8081B (TA)			
Representativeness	Cooler Temperature	< 6°C	S
Bias	Surrogates	Recoveries within laboratory-specified control limits	A
Accuracy	LCS/LCSD	Recoveries within laboratory-specified control limits	A
Precision	LCS/LCSD and MS/MSD	RPDs within laboratory-specified control limits	A
Method performance for matrix, bias	MS/MSD	Recoveries within laboratory-specified control limits	S&A
Precision	Field Duplicates	RPD <40%	S&A
Bias/Contamination	Method Blank	Target analytes not detected at concentrations > 1/2 the RL	S&A
Analytical Completeness	Number of usable (not rejected) results out of total number of results	90%	S&A
Field Completeness	Number of samples collected out of planned samples	95%	S

Abbreviations/Acronyms:

A = analytical
ARI = Analytical Resources, Incorporated in Tukwila, WA
°C = degrees Celsius
DQI = data quality indicator
EPA = US Environmental Protection Agency
LCS = laboratory control spike
LCSD = laboratory control spike duplicate
MQO = measurement quality objective

MS = matrix spike
MSD = matrix spike duplicate
QC = quality control
RL = reporting limit
RPD = relative percent difference
S = sampling
TA = TestAmerica Laboratories, Inc. located in Tacoma, WA

Table C-2
Sample Containers, Preservatives, and Holding Times
Sampling and Analysis Plan/Quality Assurance Project Plan
Webster Nursery
Tumwater, Washington

Matrix	Method	Container	Preservative	Holding Time (a)	Minimum Mass/Volume	Laboratory Performing Analyses
Groundwater	Pesticides by EPA 8081B LL	1-L amber glass	<6°C, Na ₂ S ₂ O ₃	7 days/40 days	1 L	ARI
Soil	Pesticides by EPA 8081B	4-oz glass jar with Teflon lid	<6°C	14 days/40 days	40 g	TA-Tacoma

Note:

(a) Time from sample collection to extraction/Time from sample extraction to analysis.

Acronyms/Abbreviations:

ALS = ALS Environmental laboratory

°C = degrees Celsius

EPA = United States Environmental Protection Agency

g = grams

L = liter

LL = low level

oz = ounces

TA = TestAmerica Laboratories, Inc.

Table C-3
Reporting Limit Goals
Sampling and Analysis Plan/Quality Assurance Project Plan
Webster Nursery
Tumwater, Washington

Analyte	CAS RN	Groundwater		Soil		
		CUL (µg/L)	RL (a) (µg/L)	CUL (µg/kg)		RL (b) (µg/kg)
				Vadose	Saturated	
4,4'-DDD	72-54-8	--	0.00125	--	--	1.00
4,4'-DDE	72-55-9	--	0.00125	--	--	1.00
4,4'-DDT	50-29-3	--	0.001	--	--	1.00
Aldrin	309-00-2	--	0.000625	--	--	0.50
alpha-BHC	319-84-6	--	0.000625	--	--	0.50
alpha-Chlordane	5103-71-9	--	0.000625	--	--	0.50
beta-BHC	319-85-7	--	0.000625	--	--	1.00
beta-Chlordane	5566-34-7	--	0.000625	--	--	0.50
Chlordane	57-74-9	0.25	0.200	2,060	103	5.00
delta-BHC	319-86-8	--	0.000625	--	--	0.50
Dieldrin	60-57-1	--	0.00125	--	--	1.00
Endosulfan I	959-98-8	--	0.000625	--	--	0.50
Endosulfan II	33213-65-9	--	0.00125	--	--	1.00
Endosulfan Sulfate	1031-07-8	--	0.00125	--	--	1.00
Endrin	72-20-8	--	0.00125	--	--	1.00
Endrin Aldehyde	7421-93-4	--	0.00125	--	--	1.00
Endrin Ketone	53494-70-5	--	0.00125	--	--	1.00
gamma-BHC (Lindane)	58-89-9	--	0.000625	--	--	0.50
Heptachlor	76-44-8	0.0194	0.000625	37.8	1.9	1.00
Heptachlor Epoxide	1024-57-3	0.00481	0.000625	80.2	4.02	0.50
Methoxychlor	72-43-5	--	0.00625	--	--	5.00
Toxaphene	8001-35-2	--	0.125	--	--	50.0

Notes:

1. CULs are based on MTCA Method B cleanup levels.
- (a) Groundwater samples are anticipated to be analyzed by ARI using EPA Method 8081B LL.
(b) Soil samples will be analyzed by TA using EPA Method 8081B.

Acronyms/Abbreviations:

- = CUL is not applicable
- ARI = Analytical Resources, Incorporated in Tukwila, WA
- CUL = MTCA Method B cleanup Level
- EPA = US Environmental Protection Agency
- LL = low-level
- µg/kg = micrograms per kilogram
- µg/L = micrograms per liter
- MTCA = Model Toxics Control Act
- RL = reporting limit
- TA = TestAmerica Laboratories, Inc. located in Tacoma, WA