### APPENDIX A TERRESTRIAL ECOLOGICAL EVALUATION



### **Voluntary Cleanup Program**

### Washington State Department of Ecology Toxics Cleanup Program

### TERRESTRIAL ECOLOGICAL EVALUATION FORM

Under the Model Toxics Control Act (MTCA), a terrestrial ecological evaluation is necessary if hazardous substances are released into the soils at a Site. In the event of such a release, you must take one of the following three actions as part of your investigation and cleanup of the Site:

- 1. Document an exclusion from further evaluation using the criteria in WAC 173-340-7491.
- 2. Conduct a simplified evaluation as set forth in WAC 173-340-7492.
- 3. Conduct a site-specific evaluation as set forth in WAC 173-340-7493.

When requesting a written opinion under the Voluntary Cleanup Program (VCP), you must complete this form and submit it to the Department of Ecology (Ecology). The form documents the type and results of your evaluation. You still need to submit your evaluation as part of your cleanup plan or report.

If you have questions about how to conduct a terrestrial ecological evaluation, please contact the Ecology site manager assigned to your Site. For additional guidance, please refer to <a href="http://www.ecy.wa.gov/programs/tcp/policies/terrestrial/TEEHome.htm">www.ecy.wa.gov/programs/tcp/policies/terrestrial/TEEHome.htm</a>.

#### Step 1: IDENTIFY HAZARDOUS WASTE SITE

Please identify below the hazardous waste site for which you are documenting an evaluation.

Facility/Site Name: Truck City Stop Site

Facility/Site Address: 3216 Old Highway 99 South, Mount Vernon, WA 98273

Facility/Site No: 2673; Cleanup Site ID: 5176 VCP Project No.:

#### **Step 2: IDENTIFY EVALUATOR**

Please identify below the person who conducted the evaluation and their contact information.

Name: Yen-Vy Van

Title: Senior Hydrogeologist

Organization:	Maul Foster Alongi, In	IC.
---------------	------------------------	-----

Mailing address: 411 First Avenue, Suite 610

City:	Seattle		Sta	te: WA	Zip code:	98104
Phone:	206-858-7618	Fax:		E-mail: yvand	@maulfoster.com	n

Step 3: DOCUMENT EVALUATION TYPE AND RESULTS										
A. Exclusion from further evaluation.										
1. Does the Site qualify for an exclusion from further evaluation?										
X Yes If you answered "YES," then answer Question 2.										
No or If you answered "NO" or "UKNOWN," then skip to Step 3B of this form.										
2. What is the basis for the exclusion? Check all that apply. Then skip to Step 4 of this form.										
Point of Compliance: WAC 173-340-7491(1)(a)										
$\square$ All soil contamination is, or will be,* at least 15 feet below the surface.										
All soil contamination is, or will be,* at least 6 feet below the surface (or alternative depth if approved by Ecology), and institutional controls are used to manage remaining contamination.										
Barriers to Exposure: WAC 173-340-7491(1)(b)										
All contaminated soil, is or will be,* covered by physical barriers (such as buildings or paved roads) that prevent exposure to plants and wildlife, and institutional controls are used to manage remaining contamination.										
Undeveloped Land: WAC 173-340-7491(1)(c)										
<ul> <li>There is less than 0.25 acres of contiguous<sup>#</sup> undeveloped<sup>±</sup> land on or within 500 feet of any area of the Site and any of the following chemicals is present: chlorinated dioxins or furans, PCB mixtures, DDT, DDE, DDD, aldrin, chlordane, dieldrin, endosulfan, endrin, heptachlor, heptachlor epoxide, benzene hexachloride, toxaphene, hexachlorobenzene, pentachlorophenol, or pentachlorobenzene.</li> </ul>										
For sites not containing any of the chemicals mentioned above, there is less than 1.5 acres of contiguous <sup>#</sup> undeveloped <sup>±</sup> land on or within 500 feet of any area of the Site.										
Background Concentrations: WAC 173-340-7491(1)(d)										
Concentrations of hazardous substances in soil do not exceed natural background levels as described in WAC 173-340-200 and 173-340-709.										
<ul> <li>* An exclusion based on future land use must have a completion date for future development that is acceptable to Ecology.</li> <li>* "Undeveloped land" is land that is not covered by building, roads, paved areas, or other barriers that would prevent wildlife from feeding on plants, earthworms, insects, or other food in or on the soil.</li> <li>* "Contiguous" undeveloped land is an area of undeveloped land that is not divided into smaller areas of highways, extensive paving, or similar structures that are likely to reduce the potential use of the overall area by wildlife.</li> </ul>										

В.	Simplifie	Simplified evaluation.											
1.	Does the	te qualify for a simplified evaluation?											
	X	s If you answered "YES," then answer Qu	lestion 2 below.										
	🗌 I Unk	or wn If you answered " <b>NO</b> " or " <b>UNKNOWN</b> ,"	you answered " <b>NO</b> " or " <b>UNKNOWN,</b> " then skip to <b>Step 3C</b> of this form.										
2. Did you conduct a simplified evaluation?													
	x `	s If you answered "YES," then answer Qu	answered "YES," then answer Question 3 below.										
		If you answered " <b>NO,</b> " then skip to <b>Step</b>	f you answered " <b>NO,"</b> then skip to <b>Step 3C</b> of this form.										
3.	Was furth	evaluation necessary?											
		s If you answered "YES," then answer Qu	lestion 4 below.										
	X	If you answered " <b>NO,</b> " then answer <b>Que</b>	estion 5 below.										
4.	If further	aluation was necessary, what did you do?											
		Used the concentrations listed in Table 749-2 <b>Step 4</b> of this form.	as cleanup levels. If so, then skip to										
		Conducted a site-specific evaluation. If so, the	nen skip to <b>Step 3C</b> of this form.										
5.	If no furth	evaluation was necessary, what was the r	eason? Check all that apply. Then skip										
	Exposure	nalysis: WAC 173-340-7492(2)(a)											
		Area of soil contamination at the Site is not m	ore than 350 square feet.										
		Current or planned land use makes wildlife e	xposure unlikely. Used Table 749-1.										
	Pathway A	alysis: WAC 173-340-7492(2)(b)											
		No potential exposure pathways from soil cor	ntamination to ecological receptors.										
	Contamin	t Analysis: WAC 173-340-7492(2)(c)											
	X	No contaminant listed in Table 749-2 is, or wi concentrations that exceed the values listed i	ll be, present in the upper 15 feet at n Table 749-2.										
	<b>X</b>	No contaminant listed in Table 749-2 is, or wa alternative depth if approved by Ecology) at c listed in Table 749-2, and institutional control contamination.	II be, present in the upper 6 feet (or concentrations that exceed the values s are used to manage remaining										
	X	No contaminant listed in Table 749-2 is, or w concentrations likely to be toxic or have the p using Ecology-approved bioassays.	Il be, present in the upper 15 feet at otential to bioaccumulate as determined										
	X	No contaminant listed in Table 749-2 is, or wi alternative depth if approved by Ecology) at o the potential to bioaccumulate as determined institutional controls are used to manage rem	Il be, present in the upper 6 feet (or concentrations likely to be toxic or have using Ecology-approved bioassays, and aining contamination.										

C.	Site-speci	fic evaluation. A site-specific evaluation process consists of two parts: (1) formulating								
	the probler require cor	n, and (2) selecting the methods for addressing the identified problem. Both steps nsultation with and approval by Ecology. See WAC 173-340-7493(1)(c).								
1.	Was there	a problem? See WAC 173-340-7493(2).								
	Yes If you answered " <b>YES</b> ," then answer <b>Question 2</b> below.									
	X N	If you answered " <b>NO</b> ," then identify the reason here and then skip to <b>Question 5</b> below:								
		No issues were identified during the problem formulation step.								
		While issues were identified, those issues were addressed by the cleanup actions for protecting human health.								
2.	What did y	you do to resolve the problem? See WAC 173-340-7493(3).								
		Used the concentrations listed in Table 749-3 as cleanup levels. If so, then skip to <b>Question 5</b> below.								
		Used one or more of the methods listed in WAC 173-340-7493(3) to evaluate and address the identified problem. <i>If so, then answer <b>Questions 3 and 4</b> below.</i>								
3.	<b>If you con</b> Check all th	ducted further site-specific evaluations, what methods did you use? hat apply. See WAC 173-340-7493(3).								
		Literature surveys.								
		Soil bioassays.								
		Wildlife exposure model.								
		Biomarkers.								
		Site-specific field studies.								
		Weight of evidence.								
		Other methods approved by Ecology. If so, please specify:								
4.	What was	the result of those evaluations?								
		Confirmed there was no problem.								
		Confirmed there was a problem and established site-specific cleanup levels.								
5.	Have you problem re	already obtained Ecology's approval of both your problem formulation and esolution steps?								
	□ Y	es If so, please identify the Ecology staff who approved those steps:								
	□ N	lo								

#### Step 4: SUBMITTAL

Please mail your completed form to the Ecology site manager assigned to your Site. If a site manager has not yet been assigned, please mail your completed form to the Ecology regional office for the County in which your Site is located.



If you need this publication in an alternate format, please call the Toxics Cleanup Program at 360-407-7170. Persons with hearing loss can call 711 for Washington Relay Service. Persons with a speech disability can call 877-833-6341.

# $\begin{array}{c} APPENDIX \ B \\ \text{Ground water Compliance Monitoring Plan} \end{array}$

### GROUNDWATER COMPLIANCE MONITORING PLAN

TRUCK CITY SITE MOUNT VERNON, WASHINGTON



Prepared for SKAGIT COUNTY MOUNT VERNON, WASHINGTON November 11, 2014 Project No. 0714.02.02

Prepared by Maul Foster & Alongi, Inc. 1329 N State Street, Suite 301, Bellingham WA 98225

### GROUNDWATER COMPLIANCE MONITORING PLAN

TRUCK CITY SITE PROPERTY The material and data in this plan were prepared under the supervision and direction of the undersigned.

MAUL FOSTER & ALONGI, INC.

Yen-Vy Van, LHG Senior Hydrogeologist

Justin L. Clary, PE Principal Engineer

Jim Darling Vice President, Principal Planner

R:\0714.02 Skagit County\Report\02\_2014.11.11 Draft Cleanup Action Plan\Appendix B Groundwater Comp Plan\Truck City Groundwater CMP.docx

### CONTENTS

TABLES	ANDI	LLUSTRATIONS	IV
ACRO	NYMS A	AND ABBREVIATIONS	V
1	INTRC 1.1	DUCTION PURPOSE OF GROUNDWATER COMPLIANCE MONITORING PLAN	1 1
2	BACK 2.1 2.2 2.3 2.4	GROUND SITE DESCRIPTION SITE HISTORY PREVIOUS INVESTIGATIONS POINT OF COMPLIANCE	2 2 3 3 4
3	CON0 3.1 3.2 3.3 3.4	CEPTUAL SITE MODEL GEOLOGY AND HYDROGEOLOGY SOURCE AND NATURE AND EXTENT OF RESIDUAL CONTAMINATION RISK EVALUATION POST-REMEDIAL ACTION CONDITIONS	5 5 6 7 8
4	REME	DIATION LEVELS	8
5	MONI 5.1 5.2 5.3 5.4	TORING PROGRAM MONITORING OBJECTIVES MONITORING WELL NETWORK STAGES OF MONITORING SAMPLING AND ANALYSIS	8 8 10 11
6	CONT 6.1 6.2 6.3 6.4	TINGENCY MEASURES TIER 1 TIER 2 TIER 3 TIER 4	12 12 13 13 14
7	NOTIF	ICATION AND REPORTING	14
8	SCHEI	DULE	15
LIMITA	<b>FIONS</b>		
	NOFC		

REFERENCES

TABLES

FIGURES

#### APPENDIX

WELL LOGS

### TABLES AND ILLUSTRATIONS

FOLLOWING PLAN:

TABLES

- 1 SUMMARY OF SOIL ANALYTICAL RESULTS
- 2 SUMMARY OF GROUNDWATER ANALYTICAL RESULTS
- 3 REMEDIATION LEVELS AT ALL MONITORING WELLS
- 4 COMPLIANCE MONITORING WELLS NETWORK

#### FIGURES

- 1 SITE LOCATION
- 2 SITE PARCELS MAP
- 3 SITE FEATURES AND PREVIOUS ENVIRONMENTAL INVESTIGATIONS
- 4 SITE FEATURES AND LOCATIONS OF INVESTIGATIONS
- 5 CROSS SECTION TRANSECT
- 6 GENERALIZED GEOLOGIC CROSS SECTION A-A'
- 7 GROUNDWATER POTENTIOMETRIC MAP—JULY 2014
- 8 SOIL ANALYTICAL RESULTS
- 9 GROUNDWATER ANALYTICAL RESULTS
- 10 PROPOSED SKAGIT COUNTY JAIL SITE CONDITIONS
- 11 COMPLIANCE MONITORING NETWORK

AEG	Associated Environmental Group, LLC
AGI	Applied Geotechnology, Inc.
bgs	below ground surface
BTEX	benzene, toluene, ethylbenzene, and total xylenes
COI	chemical of interest
the County	Skagit County, Washington
CUL	cleanup level
Ecology	Washington State Department of Ecology
ESA	environmental site assessment
IHS	indicator hazardous substance
MFA	Maul Foster & Alongi, Inc.
MTC	Materials Testing & Consulting, Inc.
MTCA	Model Toxics Control Act
NWTPH	Northwest Total Petroleum Hydrocarbons
POC	point of compliance
the Property	The proposed jail property
REL	remediation level
RI/FS	remedial investigation and feasibility study
TPH	total petroleum hydrocarbons
the Site	Truck City Site, Skagit County parcel P29546
USEPA	U.S. Environmental Protection Agency
UST	underground storage tank
VOC	volatile organic compound
WAC	Washington Administrative Code

This Compliance Monitoring Plan (CMP) presents the Washington State Department of Ecology's (Ecology) proposed ground water CMP for the Truck City site ("Site") (Facility Site ID: 2673, Cleanup Site ID: 5176). The Site is located at 3216 Old Highway 99 South, Mount Vernon in Skagit County, Washington (Figure 1). The Site, in combination with other adjacent parcels, is proposed for construction of the Skagit County jail. The proposed jail property (Property) comprises the following five parcels: Skagit County parcels P29546 (Truck City parcel) and four adjoining undeveloped parcels to the south, P119262, P119263, P119265, and P119267 (Figure 2). The parcels are owned by various parties, and Skagit County (the "County") has executed purchase and sale agreement(s) for the parcels. The Truck City parcel comprises the entire Site based on data available at this time. As part of that effort, the County is pursuing a Prospective Purchaser Consent Decree with the Washington State Department of Ecology (Ecology).

This plan has been prepared to meet the groundwater monitoring requirements specified in the cleanup action plan for the Site and was developed in accordance with the compliance monitoring requirements put forth in the Washington State Model Toxics Control Act (MTCA) (Washington Administrative Code [WAC] 173-340-410). The approach put forth in this plan is consistent with the Washington State Department of Ecology (Ecology)-approved Public Review Remedial Investigation and Feasibility Study (RI/FS) (MFA, 2014).

### 1.1 Purpose of Groundwater Compliance Monitoring Plan

The final remedy for the site, as described in the cleanup action plan (Ecology, 2014a), includes removal of contaminated soils, bioremediation, and natural attenuation.

The goals of this compliance monitoring plan are to:

- Identify existing and proposed replacement monitoring wells (to be installed after completion of petroleum-contaminated-soil excavation) for inclusion in the compliance monitoring network and provide criteria for siting and installing future monitoring wells.
- Describe cleanup levels (CULs) for use in existing and future monitoring wells.
- Provide guidelines and criteria for assessing compliance with CULs during the protection, performance, and confirmational stages of groundwater monitoring, including monitoring frequency.
- Identify contingent actions to be implemented in response to noncompliance with CULs and the criteria for triggering these actions.
- Provide criteria for decommissioning monitoring wells.

• Provide criteria for modifying the monitoring frequency, as a contingent action, in response to a change in the stage of monitoring, or in response to achievement of cleanup criteria.

Ecology has determined that the highest beneficial use of groundwater is protection of surface water. Groundwater CULs based on protection of surface water and the point of compliance (POC) at the site boundary were established in the Ecology-approved public review RI/FS (MFA, 2014).

Groundwater data collected at the site from 1989 to 2014 showed that selected indicator hazardous substance (IHS) concentrations, including gasoline- and diesel-range total petroleum hydrocarbons (TPH) and benzene, exceed MTCA Method A CULs within the site boundary (MFA, 2014). These findings support the use of sentinel wells at the site boundary for monitoring CUL compliance at the POC.

### 2.1 Site Description

The Site is located in section 32, township 34 north, range 4 east, of the Willamette Meridian. The Property comprises five rectangular parcels: the Truck City parcel, an 8.01-acre tax parcel; two 1.0-acre tax parcels (parcel numbers P119262 and P119263); a 1.75-acre tax parcel (parcel number P119265); and a 1.88-acre tax parcel (parcel number P119267) (refer to Figure 2). The Property's surface topography is generally flat. Access to the Site/Property is from Old Highway 99 South, adjacent to the west property boundary.

Fifteen former underground storage tank (UST) locations were identified at the Truck City Site. Historical UST nests include the northern UST and southern UST nests, which had housed four USTs and three USTs, respectively (Figure 2). These USTs were decommissioned and removed in 1993, during an interim remedial action conducted by Ecology (Ecology, 1993). The USTs had a capacity of 5,000 gallons each. The current and only operational UST nest at the Site is the eastern UST nest, which houses three 5,000-gallon gasoline USTs and one 15,000-gallon diesel UST. This UST system was upgraded in 1998. Two 500-gallon USTs, located between the diesel pump islands and the gasoline pump islands, and a former septic tank, used as a waste oil tank, were also decommissioned and removed during the interim removal action. Additionally, a UST, of unknown size (and presumably a former heating oil tank), may be located beneath the retail store footprint. This UST reportedly was decommissioned in place. Figure 3 presents the Site's features and previous environmental investigation features.

The Property is currently zoned "Public." The City of Mt. Vernon has designated the proposed county jail as an Essential Public Facility. The Truck City parcel contains six buildings associated with the commercial operations of the gas station, truck stop and truck wash, restaurant, and retail store. Five of the buildings—the contractor's staging shop, office space, truck wash building, retail

BACKGROUND

R:\0714.02 Skagit County\Report\02\_2014.11.11 Draft Cleanup Action Plan\Appendix B Groundwater Comp Plan\Truck City Groundwater CMP.docx

store, and restaurant/café—were constructed in 1978. The building currently used for storage was constructed in 1957.

The gas station pump islands, fueling facilities, and truck scale (weigh station) are located in the western area of the Truck City parcel. The diesel pump islands and the Truck City parcel's current operational USTs are located in the central area of the parcel, adjacent south of the truck wash building. Long-term truck parking is designated in the east area of the parcel. Figure 4 presents the Site's current site features and recent investigation locations.

### 2.2 Site History

Archival records indicate that the vicinity once was, generally, rural farmland with local residences. The Site was developed by 1953 and operated as a truck stop and restaurant until the truck stop burned in 1976. The parcel was redeveloped to its current configuration in 1978, and operations have not significantly changed since then. Several subsurface investigations were conducted at the Site between 1989 and 2014. Ecology completed an interim soil remedial cleanup action in 1993.

### 2.3 Previous Investigations

Subsurface investigations have been conducted on the Site since 1989 to assess potential petroleumhydrocarbon impacts related to the operation of the retail gasoline station. Applied Geotechnology, Inc. (AGI) conducted a hydrocarbon assessment of the Site in 1989. AGI advanced eight borings, to approximately 15 to 20 feet below ground surface (bgs), adjacent to the northern, southern, and eastern UST nests; gasoline and diesel pump islands; and truck wash area. Six of the borings were completed as 2-inch-diameter monitoring wells. AGI concluded that soil and groundwater gasoline and diesel petroleum hydrocarbon contamination was present around the northern and southern UST nests, and the potential exists for off-site migration of these chemicals of interest (COIs). Detected concentrations of gasoline- and diesel-range TPH and associated petroleum fuel volatile organic compounds (VOCs), specifically benzene, toluene, and total xylenes, are above Ecology's current MTCA Method A CULs. Groundwater flow direction at the Site was assessed to be west to southwesterly (AGI, 1989).

Ecology conducted an interim action cleanup in 1993. Seven USTs, 5,000 gallons in capacity each and located in the northern and southern UST nests, were decommissioned and removed, along with associated product lines. Two additional 500-gallon-capacity USTs, as well as a septic tank full of waste oil, were encountered during the contaminated-soil-excavation activities and were also removed. Ecology reported that, because the septic system had been used for waste oil disposal and was connected to the parcel's storm drain system, the septic tank may be one of the contaminant sources at this parcel (Ecology, 1993). The interim action removed 6,244 cubic yards of contaminated soil and 89,991 gallons of contaminated water. The impacted soil was placed on an on-site treatment pad in the northeastern area of the Site for aeration and biodegradation. Final confirmation samples from the stockpiled soil showed detections of gasoline-range TPH below CULs, with residual diesel-range TPH concentrations above CULs. The USTs were reported to be in good condition, with no holes. However, impacted soil was apparent in the excavation pit (sidewalls and base of the excavation). A petroleum sheen was also observed in groundwater that

R:\0714.02 Skagit County\Report\02\_2014.11.11 Draft Cleanup Action Plan\Appendix B Groundwater Comp Plan\Truck City Groundwater CMP.docx

had seeped into the pit. Ecology also reported the presence of free product in the form of fuel seeps from the excavation sidewalls (Ecology, 1993). The monitoring wells installed in the excavation area by AGI were destroyed during excavation activities. Ecology concluded that groundwater contamination at the Site may be an ongoing issue.

Associated Environmental Group, LLC (AEG) conducted a site characterization of the Site in 2005. Eleven borings were advanced via a direct-push-probe drilling rig to depths ranging from approximately 5 to 8 feet bgs. The borings were placed in the perimeters north, east, and south of the pump islands and UST nests. Shallow soil and groundwater samples were collected at all borings. Analytical results for all samples indicated no detectable presence of petroleum hydrocarbons (AEG, 2005).

In 2005, an unknown volume of diesel was spilled at the Site when a truck driver filling a rig allowed an unattended fueling nozzle to fall out of the tank during fueling activities. The spill spread to a ditch (known as Maddox Creek), which is located adjacent to and east of the Site/Property and flows south parallel to Old Highway 99 South to Hickox Road (approximately 0.68 mile south of the Property). This spill went unreported until the Ecology Spills Team traced the source back to the Truck City parcel (Ecology, Environmental Report Tracking System No. 546209, 2005). Sheen was observed in Maddox Creek. Ecology retained NRC Environmental Services to clean up the spill. Absorbent booms and pads were placed in Maddox Creek. Subsequently, Materials Testing & Consulting, Inc. (MTC) conducted sediment sampling in Maddox Creek, in the vicinity of the Site/Property, to assess whether residual contamination remains in the creek. Based on current data the sediments in Maddox Creek no longer appear to be impacted by releases at the Site.

MTC conducted an initial Phase II environmental site assessment (ESA) in February 2014 and a supplemental ESA in March 2014. Eleven borings were advanced, via a direct-push-probe drilling rig, to a maximum depth of 15 feet bgs. The borings were located in and outside of the former excavation remediation area. Soil samples were collected from all borings for laboratory analyses. One groundwater sample was collected from a boring placed south of the former UST nests in the western area of the Truck City parcel. MTC assessed the condition of several remaining monitoring wells at the Site and concluded that most wells were inaccessible or unusable (MTC, 2014a). A secondary groundwater sample was collected from an existing well located north of the truck scale. Three surficial soil samples were also collected at adjoining parcels to the south. MTC concluded that the remediated area contained localized, residual soil contaminated with petroleum at concentrations below MTCA Method A CULs. However, impacted soil, at concentrations above MTCA CULs for gasoline- and diesel-range TPH, was documented adjacent to the truck scale (MTC, 2014b). Laboratory analytical results for the two groundwater samples indicated no detectable TPH in the gasoline and diesel ranges or associated VOCs, specifically benzene, toluene, ethylbenzene, and total xylenes (BTEX).

### 2.4 Point of Compliance

For groundwater, the POC is the point or points where the groundwater CULs must be attained for a site to be in compliance with the cleanup standards. Groundwater CULs shall be attained in all

R:\0714.02 Skagit County\Report\02\_2014.11.11 Draft Cleanup Action Plan\Appendix B Groundwater Comp Plan\Truck City Groundwater CMP.docx

groundwaters from the POC to the outer boundary of the hazardous-substance plume. A conditional POC for groundwater is not proposed for the Property at this time.

POCs at the site will include all existing monitoring wells. Sentinel wells will include wells TC-1, TC-2, TC-4, and TC-6. The remaining wells, TC-3 and TC-5, are located at the former source areas. Site CULs, based on protection of surface water, apply at the POC. Compliance monitoring will be conducted at all monitoring wells, TC-1 through TC-6, to evaluate compliance with CULs at the former source areas and downgradient of these areas, near the southern and western perimeter of the Truck City parcel.

Sentinel wells will be used to evaluate whether groundwater at the downgradient POC is in compliance with CULs. IHS concentrations in groundwater at or below action levels will not exceed CULs at the POC. RELs are discussed in Section 4 of this plan. Sentinel wells are designated to allow monitoring between the former source areas and the property boundary of the Truck City parcel.

The fuel spill in 2005 was remediated, and sediment sampling in Maddox Creek at locales downgradient of the Site indicated cleanup activities were completed in accordance with MTCA. Based on current data the sediments in Maddox Creek no longer appear to be impacted by releases at the Site.

# 3 CONCEPTUAL SITE MODEL

The following is a summary of the investigation findings and the resultant conceptual site model as presented in the public review RI/FS (MFA, 2014).

### 3.1 Geology and Hydrogeology

The Property and vicinity have been mapped as recent alluvium and artificial fill. Alluvium deposits encountered at the Property, at locations of investigation, consist of floodplain sequences ranging from fluvial silty sand and well sorted sand, to silt with intervening clay. Fill, comprising sandy gravel to gravelly silty sand, was generally present to approximately 3 to 5 feet bgs at the Truck City parcel, except in the former UST nests, where soil remedial cleanup action by Ecology in 1993 overexcavated this area to approximately 9.5 feet bgs. A cross section transect of the Site and a corresponding geologic cross section are presented in Figures 5 and 6, respectively.

The matrix of the unconfined shallow aquifer appears to be silty sand. Depth to groundwater, encountered during subsurface exploration activities, was variable throughout the Site/Property, ranging approximately from 3.5 to 9.5 feet bgs. The static water level at completed monitoring wells TC-1 through TC-6, at the Truck City parcel, ranged approximately from 5.80 to 6.45 feet bgs during the groundwater monitoring and sampling event conducted on July 18, 2014. The direction of groundwater migration at the Site during the July 2014 groundwater event, based on

professionally surveyed elevations at monitoring wells TC-1 through TC-6, is generally to the southsoutheast, with tangent to the west (refer to Figure 7).

AGI reported a west-to-southwesterly groundwater flow direction at the Site during their investigation in October 1989, based on water levels measured from installed monitoring wells. Seasonal groundwater flow direction fluctuations are expected at the Site/Property and vicinity because of the shallow depth to groundwater in the floodplain area. The local and regional discharge points in the area appear to be to the west-southwest, toward Britt Slough and the Skagit River. At their closest points, Britt Slough and the Skagit River are located approximately 0.5 mile and 1.5 mile, respectively, west of the Property. Maddox Creek, located adjacent east of the Property, flows south, parallel to Old Highway 99 South; intersects at Hickox Road; and flows west from this intersection.

### 3.2 Source and Nature and Extent of Residual Contamination

Based on historical and MFA's recent subsurface investigations, the source of soil and groundwater contamination is the historical operation of a gasoline station at the Truck City parcel.

IHSs identified for site soil include gasoline-range TPH and ethylbenzene (Table 1). IHSs identified for site groundwater are:

- Gasoline-range TPH
- Diesel-range TPH
- Benzene

The selected remedy for the site addresses these IHSs. There is residual soil contamination on the Truck City parcel adjacent south of the former northern UST nest, in the vicinity of boring TCBH-3 and adjacent east of the truck scale (Figure 8). Site data indicate IHS concentrations exceeding CULs in groundwater adjacent to the former southern and northern UST nests (borings TCBH-1 and TCBH-3, respectively) and the former septic waste oil tank (well TC-5) (MFA, 2014).

Figure 9 and Table 2 show IHSs that were detected in groundwater at concentrations above their respective CULs, based on MFA's remedial investigation conducted in July 2014.

#### 3.2.1.1 Groundwater Contamination

CUL exceedances were detected only in well TC-5 and at borings TCBH-1 and TCBH-3. These locales of investigation represent former source areas at the Truck City parcel. Total arsenic was detected above its CUL only at TC-2; however, in our professional opinion, this detection was due to the high level of turbidity in this groundwater sample, as concentrations of dissolved arsenic from TC-2 were below the CUL (Table 2).

In general, IHS concentrations in shallow groundwater at the Site show decreasing trends of TPH and benzene, based on a comparison and evaluation of historical analytical results from investigations conducted from 1989 through 2014. IHS impacts appear to be localized to the former source areas in the western area of the Truck City parcel.

R:\0714.02 Skagit County\Report\02\_2014.11.11 Draft Cleanup Action Plan\Appendix B Groundwater Comp Plan\Truck City Groundwater CMP.docx

### 3.3 Risk Evaluation

The Property is currently zoned "Public." Properties immediately adjacent to the site are largely composed of similar, large-lot commercial and light-industrial uses. The Truck City parcel currently contains two buildings. The northern building is used as the convenience store for the gasoline station. The southern building is a café. The remaining parcels of the Property are undeveloped. The footprint of the proposed county jail encompasses the central area of the Truck City parcel and adjoining southern parcels of the Property. The northwestern portion of the proposed jail will overlie a localized area of soil remediation for removal of historical residual contamination. Figure 10 presents an overlay of the proposed jail with respect to current residual-impacted areas at the Site.

Therefore, it is possible that persons will occupy this area of the Property at some time in the foreseeable future. Any future development will need to be protective of persons at the Property.

The following are potentially complete human health exposure pathways.

Commercial/construction/workers—there are currently no building structures at the localized impacted area at the Site. Therefore, there are no current commercial workers potentially exposed to COIs in soil. However, construction activities likely will be performed as part of site redevelopment. Construction workers could contact IHSs in soil at 0 to 15 feet bgs through incidental ingestion, dermal contact, and inhalation of impacted soil particulates. There is currently no potable water use at or near the Property and there are no known plans to develop this resource. In the future, potable water to the Property may be provided by the Skagit County Public Utility District No. 1, including water for any future development.

The impacted groundwater is shallow and localized. Future construction workers may be exposed to the impacted shallow groundwater through ingestion, dermal contact, and inhalation of chemicals volatilizing from groundwater, and appropriate protection of construction workers will be required.

Remedial action will be required to protect persons from potential exposure to volatile chemicals from the subsurface. Soil gas has the potential to migrate, and, without remedial action, persons in nearby future buildings could potentially be exposed to IHSs.

Note: this is an assessment of current potential exposure scenarios if the Site is not remediated before buildings are constructed. The intent of future cleanup actions and the subsequent recommended cleanup alternative is to remediate the soil and groundwater so that these scenarios are addressed and concerns are negated once buildings are constructed.

Following cleanup, the site will be used as an essential public facility and is anticipated to operate as the county jail.

There is no exposure by ecological receptors at the site. The site is covered by buildings, pavement, or other physical barriers that prevent plants or wildlife from being exposed.

### 3.4 Post-Remedial Action Conditions

The focus of the compliance groundwater monitoring discussed in this plan is to confirm that the site remedy is protective of groundwater. The primary objectives of the monitoring program are to provide early warning, via sentinel wells, of a potential change in groundwater conditions that could indicate that contaminants could potentially migrate off site (see Section 5 for further details). The surface water exposure pathway has been eliminated by the completed remedial actions associated with Maddox Creek. Monitoring will continue in accordance with this plan to ensure that groundwater protection continues.



The compliance monitoring program put forth in this plan relies on sentinel wells (TC-1, TC-2, TC-4, and TC-6) to provide early warning of a possible exceedance of groundwater CULs at the POC. CULs are based on MTCA Method A groundwater CULs (Table 3).

## 5 MONITORING PROGRAM

This section provides the monitoring program objectives and details, including selection of the monitoring network, stages of monitoring, and the sampling and analysis program.

### 5.1 Monitoring Objectives

The primary objectives of the groundwater-related remedial actions at the Truck City parcel are to reduce source area concentrations in groundwater, protect groundwater from further contamination, and prevent contaminant migration off site. The groundwater monitoring program will:

- Provide confirmation of the ongoing effectiveness of the site remedy.
- Ensure that CULs are met at the POC.
- Provide early warning, via sentinel wells, of a potential increase in source area groundwater concentrations.
- Prevent exceedances of CULs at the POC through implementation of contingency measures, if needed.

### 5.2 Monitoring Well Network

The compliance monitoring program relies on the use of sentinel wells (i.e., wells located near the groundwater source area, upgradient of the POC). The compliance monitoring network includes

R:\0714.02 Skagit County\Report\02\_2014.11.11 Draft Cleanup Action Plan\Appendix B Groundwater Comp Plan\Truck City Groundwater CMP.docx

existing wells TC-1 through TC-6 (Figure 11). Sentinel well locations are based on the following criteria:

- They are downgradient of the source area.
- They are situated to allow monitoring for compliance with CULs at the POC and to provide ongoing evaluation of the efficacy of the completed remedial action.

Well logs for TC-1 through TC-6 are provided in the appendix.

The following table summarizes the intended use for each well included in the compliance monitoring network.

Monitoring Well	Well Type	Purpose							
TC-1	Sentinel well	Assess compliance with CULs							
TC-2	Sentinel well	Assess compliance with CULs							
TC-3	Source area well	Evaluate remedy effectiveness and							
		contaminant trends							
TC-4	Sentinel well	Assess compliance with CULs							
TC-5	Source area well	Evaluate remedy effectiveness and							
		contaminant trends							
TC-6	Sentinel well	Assess compliance with CULs							

Table 4Compliance Monitoring Network

Sentinel wells will be monitored for compliance with CULs (see Section 4). The source area wells will be monitored to evaluate concentration trends in the source area and will also be monitored for compliance purposes (i.e., achievement of CULs or action levels).

### 5.2.1 Monitoring Well Installation

It is assumed that monitoring wells TC-4 and TC-5 will be removed as part of the soil excavation cleanup activities, i.e., excavation and removal of localized residual contamination. Replacement wells will be installed in either the same locations or in their vicinity to continue assessment of these locations on the Truck City parcel. The replacement monitoring wells will be installed in accordance with Washington State well construction standards (WAC 173-160). Soil descriptions and dispositions will be logged during well installations. Site characterization is complete and soil samples will not be collected for chemical analysis. Ecology will be notified within 30 days of the installation of replacement compliance network wells.

### 5.2.2 Monitoring Well Decommissioning

Inactive monitoring wells, which may include wells that are not included in the compliance monitoring network or compliance network wells that are deemed no longer needed for compliance monitoring (as discussed in the next section), may be decommissioned after consultation and with Ecology's approval. Ecology will be notified at least 30 days prior to well-decommissioning R:\0714.02 Skagit County\Report\02\_2014.11.11 Draft Cleanup Action Plan\Appendix B Groundwater Comp Plan\Truck City Groundwater CMP.docx

activities. All active wells, and inactive wells that have not yet been decommissioned, will be maintained in order to meet the functional well standards put forth in the Washington State Minimum Standards for Construction and Maintenance of Wells (WAC 173-160). Monitoring well decommissioning will be completed by a licensed well driller in accordance with WAC 173-160.

### 5.3 Stages of Monitoring

Compliance monitoring at the site will be conducted in three stages in accordance with WAC 173-340-410. This section includes detailed information on each stage of monitoring, including:

- Monitoring frequency
- Data evaluation and compliance requirements and procedures
- Criteria for terminating the compliance monitoring program

The protection and performance monitoring stages will include all compliance network wells, which consist of source area wells and sentinel wells (see Section 5.2 and Figure 5); the confirmational monitoring stage will include only sentinel wells.

If an action level is exceeded in a sentinel well at any time during the monitoring program, then the contingency measures outlined in Section 6 of this plan will go into effect and will be conducted concurrently with other monitoring activities.

Source area wells will be monitored to assess IHS concentration trends in the source area for purposes of better understanding concentration and hydraulic gradients, but will not be used for determining compliance with cleanup requirements.

### 5.3.1 Protection Monitoring

Protection monitoring is conducted to confirm that human health and the environment are adequately protected during the construction, operation, and maintenance period of a remedial action.

Protection monitoring will be conducted on a quarterly basis for the first four to six quarters of the monitoring program and will involve the entire network of wells (TC-1 through TC-6).

Quarterly monitoring may begin, at the discretion of the property owner and operator, six to nine months after completion of remedial action. Monitoring of the other compliance network wells will continue on the approved schedule.

### 5.3.2 Performance Monitoring

Performance monitoring is conducted to confirm that the interim action or cleanup action has attained CULs established for the Truck City parcel. Protection monitoring and performance monitoring may be combined and will proceed to the confirmational monitoring stage.

Performance monitoring requirements include attaining four consecutive quarters of either detections below RELs or non-detects at the source area wells.

### 5.3.3 Confirmational Monitoring

Confirmational monitoring is conducted to confirm the long-term effectiveness of an interim action or cleanup action once CULs have been attained. The confirmational monitoring phase will begin after the performance monitoring requirements have been met (as discussed in the previous section). The monitoring program will be terminated once the confirmational monitoring requirements discussed below have been met.

During the confirmational monitoring stage, only sentinel wells will be monitored. The source area wells will no longer be monitored and may be decommissioned, as discussed in the previous section.

The sentinel wells will be monitored on a quarterly basis until the following requirements have been met:

- IHS concentrations in the sentinel wells have been below action levels for four consecutive quarters, beginning with the first confirmational monitoring event.
- Following four consecutive quarters of concentrations below action levels in sentinel wells during the confirmational monitoring stage, the owner or operator, after consultation with Ecology, may discontinue compliance monitoring and abandon the sentinel wells. Ecology will be provided with a notice of intent to abandon the sentinel wells 30 days prior to abandonment.

The objective of the monitoring program, as stated in Section 5.1, is to prevent groundwater contaminant migration off site by ensuring that the CULs are met at the POC. Meeting the requirements listed for each of the three stages of the monitoring program will provide confirmation that this primary objective has been met, as follows:

- CULs have been achieved in the source area.
- Action levels have not been exceeded in the sentinel wells, and confirmational monitoring indicates that they are not likely to exceed action levels in the future, indicating that the threat of off-site migration has been eliminated.

Therefore, once the confirmational monitoring requirements listed above have been met, the monitoring program may be terminated and the sentinel wells may be decommissioned.

### 5.4 Sampling and Analysis

Groundwater monitoring will include measuring water levels and water quality parameters (e.g., dissolved oxygen, pH, temperature, and specific conductance) and the collection and analysis of groundwater samples.

Groundwater samples collected in association with routine compliance monitoring activities (i.e., not as part of the contingency measures discussed in Section 6 of this plan) will be analyzed for IHSs, using the following analytical methods or other, comparable, analytical methods deemed to be suitable alternatives and approved for use by Ecology:

- Gasoline-range TPH by Northwest Total Petroleum Hydrocarbon (NWTPH)-Gx with U.S. Environmental Protection Agency (USEPA) 5035 sample preparation
- Diesel-range TPH by NWTPH-Dx Method
- VOCs associated with petroleum fuel, specifically BTEX, by USEPA 8021B with USEPA 5035 sample preparation

The analytical methods used will be verified to ensure that the method reporting limits do not exceed CULs. Additionally, selected groundwater samples will be analyzed for geochemical parameters (including nitrate, manganese, ferrous iron, sulfate, and methane) to continue assessment of the presence of electron acceptors during the biodegradation process and to evaluate the biodegradation of TPH and selected VOCs. Analytical methods for these geochemical parameters include:

- Nitrate by USEPA 353.2
- Manganese by USEPA 6020A
- Ferrous iron by USEPA ApplEnvMic7-87-1536
- Sulfate by ASTM D516-02
- Methane by RSK 175

### 6 CONTINGENCY MEASURES

Sentinel wells will be monitored during all three stages of the compliance monitoring program (as discussed in the previous section). If an IHS concentration in a sentinel well exceeds the associated CUL nine months after completion of remedial action at the Truck City parcel, then contingency measures will be implemented. Contingency measures are specific followup actions that will be implemented in response to defined triggers, as discussed in the sections below.

Contingencies are organized into four tiers.

### 6.1 Tier 1

Tier 1 is triggered when, after completion of the remedial action, a CUL is exceeded during two consecutive monitoring events in one (or more) sentinel well(s).

Quarterly monitoring will continue at all sentinel wells until IHS concentrations remain below CULs for four consecutive quarters. Allowing for up to eight quarters of quarterly monitoring will provide

R:\0714.02 Skagit County\Report\02\_2014.11.11 Draft Cleanup Action Plan\Appendix B Groundwater Comp Plan\Truck City Groundwater CMP.docx

sufficient data to evaluate concentration trends and seasonal variations for two consecutive seasons. If IHS concentrations are below CULs for four consecutive quarters before two years of monitoring are complete, monitoring activities may cease after consultation with and Ecology's approval. The Tier 1 contingency action will be considered complete, and Tier 2 contingency measures will not be triggered. However, if IHS concentrations are not below CULs for two consecutive quarters, Tier 2 contingency measures may be triggered.

A longer period of quarterly monitoring may be conducted before proceeding to Tier 2 if:

- IHS concentrations are showing stable or declining trends; and
- No detected IHS concentration is greater than two times an action level.

Ecology will be notified if quarterly monitoring is extended beyond two years. If IHS concentrations are not below action levels for four consecutive quarters at any time during the two-year period, and a Tier 2 contingency has already been implemented for that well(s) and IHS(s), then Tier 3 contingency measures will be triggered.

### 6.2 Tier 2

Tier 2 contingency measures follow a Tier 1 response and are triggered when IHS concentrations in a sentinel well are not below action CULs for two consecutive quarters at any time during a two-year quarterly monitoring period (or longer if the conditions listed in the previous section are met and Ecology has been notified).

If a Tier 2 contingency is triggered, then supplemental in situ bioremediation will be implemented. Injection of additional bioremediation products by direct-push drilling into the subsurface in the vicinity of monitoring wells with detections above CULs will provide a supplemental source of oxygen to enable the indigenous microorganisms (bacteria) to continue to break down COIs.

If higher action levels are not supported by the Tier 2 modeling work, then Tier 3 contingency measures will be triggered.

### 6.3 Tier 3

Tier 3 follows a Tier 2 response and is triggered when:

- a) Higher action levels are not supported by the Tier 2 work, or
- b) IHS concentrations in a sentinel well are not below CULs for four consecutive quarters at any time during a two-year quarterly monitoring period.

Tier 3 involves installation of up to two additional sentinel well(s) in the immediate vicinity, either downgradient or crossgradient, of the existing sentinel well (or wells) with the CUL exceedances. Monitoring in the affected sentinel well(s) will continue on a quarterly basis while the Tier 3 sentinel well locations are selected and the new well(s) are installed and developed. New sentinel wells will be installed in accordance with Ecology regulations.

The purpose of installing a new sentinel well(s) in the vicinity of the original, affected sentinel well is to determine whether the CUL exceedances observed in the original well are localized or representative of widespread groundwater contamination and/or IHS migration at concentrations that exceed CULs.

Following installation and development, the new sentinel wells will be monitored on a quarterly basis and concentrations compared to CULs. If CULs are exceeded in the new wells during any of the next four quarters, Tier 4 contingency measures, as discussed below, will be triggered. If no CULs are exceeded, the original sentinel well will be decommissioned, the new sentinel wells will be incorporated into the compliance monitoring network, and monitoring will proceed according to the current stage of monitoring.

### 6.4 Tier 4

Tier 4 follows a Tier 3 response and is triggered when CULs are exceeded in new sentinel well(s) installed as a Tier 3 response. Tier 4 involves additional subsurface investigation and/or source characterization, which may indicate a need for additional remedial action(s) in order to ensure that CULs are met at the POC.

Tier 4 contingency measures, if needed, will be determined on a case-by-case basis in consultation with Ecology. However, Tier 4 activities will focus characterization efforts on the upgradient source areas, as identified in the RI/FS (MFA, 2014). Tier 4 will include producing a work plan with proposed additional subsurface characterization and/or source characterization activities and a schedule for completion for review and approval by Ecology.

7 NOTIFICATION AND REPORTING

Ecology will be notified of the following activities:

- Revisions to the compliance monitoring network, including decommissioning or replacement of compliance network wells.
- Reverting to a previous stage of the monitoring program (e.g., from performance monitoring to protection monitoring).
- Proceeding to the confirmational monitoring stage and termination of the monitoring program.
- Tier 1 contingency measures have been triggered or contingency measures have been elevated to the next tier.
- Extending the Tier 1 contingency monitoring beyond two years without initiating Tier 2 contingency measures.

• Implementation of certain contingency measures, including installation of additional sentinel wells, and developing and conducting additional subsurface investigation and/or source area characterization activities.

Groundwater monitoring reports will be prepared on a quarterly basis, at a minimum, unless Ecology has preapproved a longer reporting timeframe. The reports will provide a description of sampling activities, analytical data, field measurements of groundwater quality parameters and groundwater levels, a discussion of analytical data trends, and data validation reports. The data validation reports will provide a review of all raw data to verify that the laboratory has supplied the required quality assurance and quality control deliverables. The data will be validated against USEPA, Washington State, and laboratory-specific criteria for completeness and usability.



The proposed compliance monitoring activities, as outlined in this plan, will begin within six months following execution of the Prospective Purchaser Consent Decree and Ecology approval of this plan.

The services undertaken in completing this plan were performed consistent with generally accepted professional consulting principles and practices. No other warranty, express or implied, is made. These services were performed consistent with our agreement with our client. This plan is solely for the use and information of our client unless otherwise noted. Any reliance on this plan by a third party is at such party's sole risk.

Opinions and recommendations contained in this plan apply to conditions existing when services were performed and are intended only for the client, purposes, locations, time frames, and project parameters indicated. We are not responsible for the impacts of any changes in environmental standards, practices, or regulations subsequent to performance of services. We do not warrant the accuracy of information supplied by others, or the use of segregated portions of this plan.

AEG. 2005. Phase II—Site characterization report, Truck City Truck Stop, 3228 Old Highway 99, Mount Ecology. 1993.

AGI. 1989. Hydrocarbon contamination assessment, Truck City Truck Stop, 1731 Old Highway 99 South, Mount Vernon, Washington. Applied Geotechnology, Inc. November 13.

Ecology. 1993. Interim action cleanup report, Truck City Truck Stop, 1731 Old Highway 99 South, Mount Vernon, Washington. Washington State Department of Ecology. January 8.

Ecology. 2014a. Draft cleanup action plan, Truck City site, Mount Vernon, Washington. Washington State Department of Ecology, Toxics Cleanup Program, Northwest Regional Office. Bellevue, Washington. October.

Ecology, 2014b. Correspondence with Site Manager.

MFA. 2014. Draft public review remedial investigation/feasibility study, Truck City site, Mount Vernon, Washington. Prepared for Skagit County. Maul Foster & Alongi, Inc., Bellingham, Washington. October 2.

MTC. 2014a. Phase II environmental site assessment, Truck City site, 3228 Old Highway 99 South, Mount Vernon, WA 98273. Materials Testing & Consulting, Inc. February 17.

MTC. 2014b. Phase II environmental site assessment, Truck City site, 3228 Old Highway 99 South, Mount Vernon, WA 98273. Materials Testing & Consulting, Inc. March 17.

# TABLES



		Location:	TC-1	TC-2	TC-2	TC-2	TC-3	TC-3	TC-4	TC-4	TC-5	TC-5
	S	ample Name:	TC1-S2-8.5	TC2-S-6.5	TCDUP-S	TC2-S-15.0	TC3-S-9.7	TC3-S-15.0	TC4-S-7.0	TC4-S-15.0	TC5-S-9.5	TC5-S-15.0
	Col	lection Date:	7/15/2014	7/17/2014	7/17/2014	7/17/2014	7/17/2014	7/17/2014	7/16/2014	7/16/2014	7/17/2014	7/17/2014
	Collection [	Depth (ft bgs):	8.5	6.5	6.5	15	9.7	15	7	15	9.5	15
	MTCA	MTCA										
		Industrial										
	UNEO	industrial										
TPH (mg/kg)												
Gasoline Range Hydrocarbons	30	30	2 U	2 U	2 U	2 U	2 U	2 U	2 U	2 U		
Diesel Range Hydrocarbons	2000	2000	50 U	50 U	50 U	50 U	50 U	50 U	50 U	50 U	50 U	50 U
Motor Oil Range Hydrocarbons	2000	2000	250 U	250 U	250 U	250 U	250 U	250 U	250 U	250 U	350	250 U
TPH Identification												
Gasoline Range Hydrocarbons	NV	NV										
Diesel Range Hydrocarbons	NV	NV										
Motor Oil Range Hydrocarbons	NV	NV										
VOCs (mg/kg)	_											
1,1,1,2-Tetrachloroethane	NV	NV	0.05 U				0.05 U	0.05 U				
1,1,1-Trichloroethane	2	2	0.05 U				0.05 U	0.05 U				
1,1,2,2-Tetrachloroethane	NV	NV	0.05 U				0.05 U	0.05 U				
1,1,2-Trichloroethane	NV	NV	0.05 U				0.05 U	0.05 U				
1,1-Dichloroethane	NV	NV	0.05 U				0.05 U	0.05 U				
1,1-Dichloroethene	NV	NV	0.05 U				0.05 U	0.05 U				
1,1-Dichloropropene	NV	NV	0.05 U				0.05 U	0.05 U				
1,2,3-Trichlorobenzene	NV	NV	0.25 U				0.25 U	0.25 U				
1,2,3-Trichloropropane	NV	NV	0.05 U				0.05 U	0.05 U				
1,2,4-Trichlorobenzene	NV	NV	0.25 U				0.25 U	0.25 U				
1,2,4-Trimethylbenzene	NV	NV	0.05 U				0.05 U	0.05 U				
1,2-Dibromo-3-chloropropane	NV	NV	0.5 U				0.5 U	0.5 U				
1,2-Dibromoethane	0.005	0.005	0.005 U				0.005 UJ	0.005 U				
1,2-Dichlorobenzene	NV	NV	0.05 U				0.05 U	0.05 U				
1,2-Dichloroethane	NV	NV	0.05 U				0.05 U	0.05 U				
1,2-Dichloropropane	NV	NV	0.05 U				0.05 U	0.05 U				
1,3,5-Trimethylbenzene	NV	NV	0.05 U				0.05 U	0.05 U				
1,3-Dichlorobenzene	NV	NV	0.05 U				0.05 U	0.05 U				
1,3-Dichloropropane	NV	NV	0.05 U				0.05 U	0.05 U				
1,4-Dichlorobenzene	NV	NV	0.05 U				0.05 U	0.05 U				
2,2-Dichloropropane	NV	NV	0.05 U				0.05 U	0.05 U				
2-Butanone	NV	NV	0.5 U				0.5 U	0.5 U				
2-Chlorotoluene	NV	NV	0.05 U				0.05 U	0.05 U				
2-Hexanone	NV	NV	0.5 U				0.5 U	0.5 U				

		Location:	TC-1	TC-2	TC-2	TC-2	TC-3	TC-3	TC-4	TC-4	TC-5	TC-5
	S	ample Name:	TC1-S2-8.5	TC2-S-6.5	TCDUP-S	TC2-S-15.0	TC3-S-9.7	TC3-S-15.0	TC4-S-7.0	TC4-S-15.0	TC5-S-9.5	TC5-S-15.0
	Col	llection Date:	7/15/2014	7/17/2014	7/17/2014	7/17/2014	7/17/2014	7/17/2014	7/16/2014	7/16/2014	7/17/2014	7/17/2014
	Collection [	Depth (ft bgs):	8.5	6.5	6.5	15	9.7	15	7	15	9.5	15
	MTCA	MTCA										
	URIU	Industrial										
	UNEO	industrial										
4-Chlorotoluene	NV	NV	0.05 U				0.05 U	0.05 U				
4-Isopropyltoluene	NV	NV	0.05 U				0.05 U	0.05 U				
4-Methyl-2-pentanone	NV	NV	0.5 U				0.5 U	0.5 U				
Acetone	NV	NV	0.5 U				0.5 U	0.5 U				
Benzene	0.03	0.03	0.03 U	0.02 U	0.02 U	0.02 U	0.03 U	0.03 U	0.02 U	0.02 U	0.02 U	0.02 U
Bromobenzene	NV	NV	0.05 U				0.05 U	0.05 U				
Bromodichloromethane	NV	NV	0.05 U				0.05 U	0.05 U				
Bromoform	NV	NV	0.05 U				0.05 U	0.05 U				
Bromomethane	NV	NV	0.5 U				0.5 U	0.5 U				
Carbon tetrachloride	NV	NV	0.05 U				0.05 U	0.05 U				
Chlorobenzene	NV	NV	0.05 U				0.05 U	0.05 U				
Chloroethane	NV	NV	0.5 U				0.5 U	0.5 U				
Chloroform	NV	NV	0.05 U				0.05 U	0.05 U				
Chloromethane	NV	NV	0.5 UJ				0.5 UJ	0.5 UJ				
cis-1,2-Dichloroethene	NV	NV	0.05 U				0.05 U	0.05 U				
cis-1,3-Dichloropropene	NV	NV	0.05 U				0.05 U	0.05 U				
Dibromochloromethane	NV	NV	0.05 U				0.05 U	0.05 U				
Dibromomethane	NV	NV	0.05 U				0.05 U	0.05 U				
Dichlorodifluoromethane	NV	NV	0.5 UR				0.5 UR	0.5 UR				
Ethylbenzene	6	6	0.05 U	0.02 U	0.02 U	0.02 U	0.05 U	0.05 U	0.02 U	0.02 U	0.02 U	0.04
Hexachlorobutadiene	NV	NV	0.25 U				0.25 U	0.25 U				
Isopropylbenzene	NV	NV	0.05 U				0.05 U	0.05 U				
m,p-Xylene	NV	NV	0.1 U				0.1 U	0.1 U				
Methyl tert-butyl ether	0.1	0.1	0.05 U				0.05 U	0.05 U				
Methylene chloride	0.02	0.02	0.5 U				0.5 U	0.5 U				
Naphthalene	5	5	0.05 U				0.05 U	0.05 U				
n-Hexane	NV	NV	0.25 U				0.25 U	0.25 U				
n-Propylbenzene	NV	NV	0.05 U				0.05 U	0.05 U				
o-Xylene	NV	NV	0.05 U				0.05 U	0.05 U				
sec-Butylbenzene	NV	NV	0.05 U				0.05 U	0.05 U				
Styrene	NV	NV	0.05 U				0.05 U	0.05 U				
tert-Butylbenzene	NV	NV	0.05 U				0.05 U	0.05 U				
Tetrachloroethene	0.05	0.05	0.025 U				0.025 U	0.025 U				

		Location:	TC-1	TC-2	TC-2	TC-2	TC-3	TC-3	TC-4	TC-4	TC-5	TC-5
	S	ample Name:	TC1-S2-8.5	TC2-S-6.5	TCDUP-S	TC2-S-15.0	TC3-S-9.7	TC3-S-15.0	TC4-S-7.0	TC4-S-15.0	TC5-S-9.5	TC5-S-15.0
	Col	lection Date:	7/15/2014	7/17/2014	7/17/2014	7/17/2014	7/17/2014	7/17/2014	7/16/2014	7/16/2014	7/17/2014	7/17/2014
	Collection [	Depth (ft bgs):	8.5	6.5	6.5	15	9.7	15	7	15	9.5	15
	MTCA	MTCA										
	Method A	Method A										
	UNLO	industrial										
Toluene	7	7	0.05 U	0.02 U	0.02 U	0.02 U	0.05 U	0.05 U	0.02 U	0.02 U	0.02 U	0.02 U
trans-1,2-dichloroethene	NV	NV	0.05 U				0.05 U	0.05 U				
trans-1,3-Dichloropropene	NV	NV	0.05 U				0.05 U	0.05 U				
Trichloroethene	0.03	0.03	0.02 U				0.02 U	0.02 U				
Trichlorofluoromethane	NV	NV	0.5 U				0.5 U	0.5 U				
Vinyl chloride	NV	NV	0.05 U				0.05 U	0.05 U				
Xylenes, Total	9	9		0.06 U	0.06 U	0.06 U			0.06 U	0.06 U	0.06 U	0.19
PAHs (mg/kg)										_		
1-Methylnaphthalene	NV	NV	0.01 U						0.01 U	0.01 U		0.01 U
2-Methylnaphthalene	NV	NV	0.011						0.01 U	0.01 U		0.01 U
Acenaphthene	NV	NV	0.01 U						0.01 U	0.01 U		0.01 U
Acenaphthylene	NV	NV	0.01 U						0.01 U	0.01 U		0.01 U
Anthracene	NV	NV	0.01 U						0.01 U	0.01 U		0.01 U
Benzo(a)anthracene	NV	NV	0.01 U						0.01 U	0.01 U		0.01 U
Benzo(a)pyrene	0.1	2	0.1 U						0.01 U	0.01 U		0.01 U
Benzo(b)fluoranthene	NV	NV	0.1 U						0.01 U	0.01 U		0.01 U
Benzo(ghi)perylene	NV	NV	0.1 U						0.01 U	0.01 U		0.01 U
Benzo(k)fluoranthene	NV	NV	0.1 U						0.01 U	0.01 U		0.01 U
Chrysene	NV	NV	0.026						0.01 U	0.01 U		0.01 U
Dibenzo(a,h)anthracene	NV	NV	0.1 U						0.01 U	0.01 U		0.01 U
Fluoranthene	NV	NV	0.01 U						0.01 U	0.01 U		0.01 U
Fluorene	NV	NV	0.01 U						0.01 U	0.01 U		0.01 U
Indeno(1,2,3-cd)pyrene	NV	NV	0.1 U						0.01 U	0.01 U		0.01 U
Naphthalene	5	5	0.01 U						0.01 U	0.01 U		0.01 U
Phenanthrene	NV	NV	0.013						0.01 U	0.01 U		0.01 U
Pyrene	NV	NV	0.01 U						0.01 U	0.01 U		0.01 U
Metals (mg/kg)							•			•	•	
Arsenic	20	20		6.34		6.94	2.9	1 U				
Barium	NV	NV		26.1		51.5	30.4	6.69				
Cadmium	2	2		1 U		1 U	1 U	1 U				
Chromium	19 <sup>a</sup>	19 <sup>a</sup>		8.87		15.4	8.03	3.35				
Lead	250	1000		3.12		4.85	2.49	1 U				
Mercury	2	2		0.1 U		0.1 U	0.1 U	0.1 U				

		Location:	TC-1	TC-2	TC-2	TC-2	TC-3	TC-3	TC-4	TC-4	TC-5	TC-5
	Sa	ample Name:	TC1-S2-8.5	TC2-S-6.5	TCDUP-S	TC2-S-15.0	TC3-S-9.7	TC3-S-15.0	TC4-S-7.0	TC4-S-15.0	TC5-S-9.5	TC5-S-15.0
	Collection Date:		7/15/2014	7/17/2014	7/17/2014	7/17/2014	7/17/2014	7/17/2014	7/16/2014	7/16/2014	7/17/2014	7/17/2014
	Collection D	Depth (ft bgs):	8.5	6.5	6.5	15	9.7	15	7	15	9.5	15
	MTCA Method A URLU	MTCA Method A Industrial										
Selenium	NV	NV		1 U		1 U	1 U	1 U				
Silver	NV	NV		1 U		1 U	1 U	1 U				
EPH (mg/kg)												
C8-C10 Aliphatic Hydrocarbons	NV	NV										5.74 U
C10-C12 Aliphatic Hydrocarbons	NV	NV										5.74 U
C12-C16 Aliphatic Hydrocarbons	NV	NV										5.74 U
C16-C21 Aliphatic Hydrocarbons	NV	NV										5.74 U
C21-C34 Aliphatic Hydrocarbons	NV	NV										408
C8-C10 Aromatic Hydrocarbons	NV	NV										5.74 U
C10-C12 Aromatic Hydrocarbons	NV	NV										5.74 U
C12-C16 Aromatic Hydrocarbons	NV	NV										5.74 U
C16-C21 Aromatic Hydrocarbons	NV	NV										5.74 U
C21-C34 Aromatic Hydrocarbons	NV	NV										510

	Location:		TC-6	TC-6	TCBH-1	TCBH-2	TCBH-3	TCBH-3	TCBH-4	TCBH-4	TCBH-5	TCBH-5
	Sample Name:		TC6-S-7.0	TC6-S-15.0	TCBH1-S-8.5	TCBH2-S-15.0	TCBH3-S-8.5	TCBH3-S-14.5	TCBH4-S-6.0	TCBH4-S-15.0	TCBH5-S-4.5	TCBH5-S-15.0
	Collection Date:		7/17/2014	7/17/2014	7/15/2014	7/15/2014	7/15/2014	7/15/2014	7/15/2014	7/15/2014	7/18/2014	7/18/2014
	Collection Depth (ft bgs):		7	15	8.5	15	8.5	14.5	6	15	4.5	15
	L ITO A	NITO A										
	MICA Method A	MICA Method A										
	URLU	Industrial										
TPH (mg/kg)			1	r								
Gasoline Range Hydrocarbons	30	30	2 U	2 U	2 U	2 U	2800	2 U	2 U	2 U	2 U	2 U
Diesel Range Hydrocarbons	2000	2000	50 U	50 U	50 U	50 U	950	50 U	50 U	50 U	50 U	50 U
Motor Oil Range Hydrocarbons	2000	2000	250 U	250 U	250 U	250 U	250 U	250 U	250 U	250 U	250 U	250 U
TPH Identification												
Gasoline Range Hydrocarbons	NV	NV										
Diesel Range Hydrocarbons	NV	NV										
Motor Oil Range Hydrocarbons	NV	NV										
VOCs (mg/kg)												
1,1,1,2-Tetrachloroethane	NV	NV					0.05 U					
1,1,1-Trichloroethane	2	2					0.05 U					
1,1,2,2-Tetrachloroethane	NV	NV					0.05 U					
1,1,2-Trichloroethane	NV	NV					0.05 U					
1,1-Dichloroethane	NV	NV					0.05 U					
1,1-Dichloroethene	NV	NV					0.05 U					
1,1-Dichloropropene	NV	NV					0.05 U					
1,2,3-Trichlorobenzene	NV	NV					0.25 U					
1,2,3-Trichloropropane	NV	NV					0.05 U					
1,2,4-Trichlorobenzene	NV	NV					0.25 U					
1,2,4-Trimethylbenzene	NV	NV					0.34					
1,2-Dibromo-3-chloropropane	NV	NV					0.5 U					
1,2-Dibromoethane	0.005	0.005					0.005 UJ					
1,2-Dichlorobenzene	NV	NV					0.05 U					
1,2-Dichloroethane	NV	NV					0.05 U					
1,2-Dichloropropane	NV	NV					0.05 U					
1,3,5-Trimethylbenzene	NV	NV					0.77					
1,3-Dichlorobenzene	NV	NV					0.05 U					
1,3-Dichloropropane	NV	NV					0.05 U					
1,4-Dichlorobenzene	NV	NV					0.05 U					
2,2-Dichloropropane	NV	NV					0.05 U					
2-Butanone	NV	NV					0.5 U					
2-Chlorotoluene	NV	NV					0.05 U					
2-Hexanone	NV	NV					0.5 U					

	Location:		TC-6	TC-6	TCBH-1	TCBH-2	TCBH-3	TCBH-3	TCBH-4	TCBH-4	TCBH-5	TCBH-5
	Sample Name:		TC6-S-7.0	TC6-S-15.0	TCBH1-S-8.5	TCBH2-S-15.0	TCBH3-S-8.5	TCBH3-S-14.5	TCBH4-S-6.0	TCBH4-S-15.0	TCBH5-S-4.5	TCBH5-S-15.0
	Collection Date:		7/17/2014	7/17/2014	7/15/2014	7/15/2014	7/15/2014	7/15/2014	7/15/2014	7/15/2014	7/18/2014	7/18/2014
	Collection Depth (ft bgs):		7	15	8.5	15	8.5	14.5	6	15	4.5	15
	MTCA	MTCA										
	IVIEthod A	Industrial										
	UNEO	industrial										
4-Chlorotoluene	NV	NV					0.05 U					
4-Isopropyltoluene	NV	NV					0.47					
4-Methyl-2-pentanone	NV	NV					0.5 U					
Acetone	NV	NV					0.5 U					
Benzene	0.03	0.03	0.02 U	0.02 U	0.02 U	0.02 U	0.03 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U
Bromobenzene	NV	NV					0.05 U					
Bromodichloromethane	NV	NV					0.05 U					
Bromoform	NV	NV					0.05 U					
Bromomethane	NV	NV					0.5 U					
Carbon tetrachloride	NV	NV					0.05 U					
Chlorobenzene	NV	NV					0.05 U					
Chloroethane	NV	NV					0.5 U					
Chloroform	NV	NV					0.05 U					
Chloromethane	NV	NV					0.5 UJ					
cis-1,2-Dichloroethene	NV	NV					0.05 U					
cis-1,3-Dichloropropene	NV	NV					0.05 U					
Dibromochloromethane	NV	NV					0.05 U					
Dibromomethane	NV	NV					0.05 U					
Dichlorodifluoromethane	NV	NV					0.5 UR					
Ethylbenzene	6	6	0.02 U	0.02 U	0.02 U	0.02 U	7.8	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U
Hexachlorobutadiene	NV	NV					0.25 U					
Isopropylbenzene	NV	NV					1.7					
m,p-Xylene	NV	NV					0.31					
Methyl tert-butyl ether	0.1	0.1					0.05 U					
Methylene chloride	0.02	0.02					0.5 U					
Naphthalene	5	5					3.1					
n-Hexane	NV	NV					4.9					
n-Propylbenzene	NV	NV					7.4					
o-Xylene	NV	NV					0.23					
sec-Butylbenzene	NV	NV					1					
Styrene	NV	NV					0.05 U					
tert-Butylbenzene	NV	NV					0.05 U					
Tetrachloroethene	0.05	0.05					0.025 U					
		Location:	TC-6	TC-6	TCBH-1	TCBH-2	TCBH-3	TCBH-3	TCBH-4	TCBH-4	TCBH-5	TCBH-5
---------------------------	-----------------	-----------------	-----------	------------	-------------	--------------	-------------	--------------	-------------	--------------	-------------	--------------
	Sa	ample Name:	TC6-S-7.0	TC6-S-15.0	TCBH1-S-8.5	TCBH2-S-15.0	TCBH3-S-8.5	TCBH3-S-14.5	TCBH4-S-6.0	TCBH4-S-15.0	TCBH5-S-4.5	TCBH5-S-15.0
	Col	lection Date:	7/17/2014	7/17/2014	7/15/2014	7/15/2014	7/15/2014	7/15/2014	7/15/2014	7/15/2014	7/18/2014	7/18/2014
	Collection [	Depth (ft bgs):	7	15	8.5	15	8.5	14.5	6	15	4.5	15
	MTCA	MTCA										
	URIU	Industrial										
	ONEO	industrial										
Toluene	7	7	0.02 U	0.02 U	0.02 U	0.02 U	0.05 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U
trans-1,2-dichloroethene	NV	NV					0.05 U					
trans-1,3-Dichloropropene	NV	NV					0.05 U					
Trichloroethene	0.03	0.03					0.02 U					
Trichlorofluoromethane	NV	NV					0.5 U					
Vinyl chloride	NV	NV					0.05 U					
Xylenes, Total	9	9	0.06 U	0.06 U	0.06 U	0.06 U		0.06 U	0.06 U	0.06 U	0.06 U	0.06 U
PAHs (mg/kg)	-					-		-		-		
1-Methylnaphthalene	NV	NV										
2-Methylnaphthalene	NV	NV										
Acenaphthene	NV	NV										
Acenaphthylene	NV	NV										
Anthracene	NV	NV										
Benzo(a)anthracene	NV	NV										
Benzo(a)pyrene	0.1	2										
Benzo(b)fluoranthene	NV	NV										
Benzo(ghi)perylene	NV	NV										
Benzo(k)fluoranthene	NV	NV										
Chrysene	NV	NV										
Dibenzo(a,h)anthracene	NV	NV										
Fluoranthene	NV	NV										
Fluorene	NV	NV										
Indeno(1,2,3-cd)pyrene	NV	NV										
Naphthalene	5	5										
Phenanthrene	NV	NV										
Pyrene	NV	NV										
Metals (mg/kg)												
Arsenic	20	20										
Barium	NV	NV										
Cadmium	2	2										
Chromium	19 <sup>a</sup>	19 <sup>a</sup>										
Lead	250	1000										
Mercury	2	2										

		Location:	TC-6	TC-6	TCBH-1	TCBH-2	TCBH-3	TCBH-3	TCBH-4	TCBH-4	TCBH-5	TCBH-5
	S	ample Name:	TC6-S-7.0	TC6-S-15.0	TCBH1-S-8.5	TCBH2-S-15.0	TCBH3-S-8.5	TCBH3-S-14.5	TCBH4-S-6.0	TCBH4-S-15.0	TCBH5-S-4.5	TCBH5-S-15.0
	Col	lection Date:	7/17/2014	7/17/2014	7/15/2014	7/15/2014	7/15/2014	7/15/2014	7/15/2014	7/15/2014	7/18/2014	7/18/2014
	Collection [	Depth (ft bgs):	7	15	8.5	15	8.5	14.5	6	15	4.5	15
	MTCA Method A URLU	MTCA Method A Industrial										
Selenium	NV	NV										
Silver	NV	NV										
EPH (mg/kg)												
C8-C10 Aliphatic Hydrocarbons	NV	NV										
C10-C12 Aliphatic Hydrocarbons	NV	NV										
C12-C16 Aliphatic Hydrocarbons	NV	NV										
C16-C21 Aliphatic Hydrocarbons	NV	NV										
C21-C34 Aliphatic Hydrocarbons	NV	NV										
C8-C10 Aromatic Hydrocarbons	NV	NV										
C10-C12 Aromatic Hydrocarbons	NV	NV										
C12-C16 Aromatic Hydrocarbons	NV	NV										
C16-C21 Aromatic Hydrocarbons	NV	NV										
C21-C34 Aromatic Hydrocarbons	NV	NV										

								I		1	1		
		Location:	TCBH-6	TCBH-7	TCBH-8	TCBH-8	TCBH-9	TCBH-9	TCBH-10	TCBH-11	TCBH-12	TCBH-13	TCBH-14
	S	ample Name:	TCBH6-S-4.8	TCBH7-S-15.0	TCBH8-S-9.5	TCBH8-S-15.0	TCBH9-S-9.5	TCBH9-S-15.0	TCBH10-S-4.0	TCBH11-S-4.7	TCBH12-S-3.5	TCBH13-S-4.5	TCBH14-S-8.5
	Col	llection Date:	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/18/2014	7/18/2014	7/18/2014	7/18/2014	7/18/2014
	Collection [	Depth (ft bgs):	4.8	15	9.5	15	9.5	15	4	4.7	3.5	4.5	8.5
	MTCA	MTCA											
	Method A URLU	Method A Industrial											
TPH (mg/kg)													
Gasoline Range Hydrocarbons	30	30		2 U	2 U	2 U	2 U	2 U					
Diesel Range Hydrocarbons	2000	2000		50 U	50 U	50 U	50 U	50 U					
Motor Oil Range Hydrocarbons	2000	2000		250 U	250 U	250 U	250 U	250 U					
TPH Identification													
Gasoline Range Hydrocarbons	NV	NV	ND						ND	ND	ND	ND	ND
Diesel Range Hydrocarbons	NV	NV	ND						ND	ND	ND	ND	ND
Motor Oil Range Hydrocarbons	NV	NV	ND						ND	ND	ND	ND	ND
VOCs (mg/kg)				•		•		•		•	•		
1,1,1,2-Tetrachloroethane	NV	NV											
1,1,1-Trichloroethane	2	2											
1,1,2,2-Tetrachloroethane	NV	NV											
1,1,2-Trichloroethane	NV	NV											
1,1-Dichloroethane	NV	NV											
1,1-Dichloroethene	NV	NV											
1,1-Dichloropropene	NV	NV											
1,2,3-Trichlorobenzene	NV	NV											
1,2,3-Trichloropropane	NV	NV											
1,2,4-Trichlorobenzene	NV	NV											
1,2,4-Trimethylbenzene	NV	NV											
1,2-Dibromo-3-chloropropane	NV	NV											
1,2-Dibromoethane	0.005	0.005											
1,2-Dichlorobenzene	NV	NV											
1,2-Dichloroethane	NV	NV											
1,2-Dichloropropane	NV	NV											
1,3,5-Trimethylbenzene	NV	NV											
1,3-Dichlorobenzene	NV	NV											
1,3-Dichloropropane	NV	NV											
1,4-Dichlorobenzene	NV	NV											
2,2-Dichloropropane	NV	NV											
2-Butanone	NV	NV											
2-Chlorotoluene	NV	NV											
2-Hexanone	NV	NV											

		Location:	TCBH-6	TCBH-7	TCBH-8	TCBH-8	TCBH-9	TCBH-9	TCBH-10	TCBH-11	TCBH-12	TCBH-13	TCBH-14
	Sa	ample Name:	TCBH6-S-4.8	TCBH7-S-15.0	TCBH8-S-9.5	TCBH8-S-15.0	TCBH9-S-9.5	TCBH9-S-15.0	TCBH10-S-4.0	TCBH11-S-4.7	TCBH12-S-3.5	TCBH13-S-4.5	TCBH14-S-8.5
	Coll	lection Date:	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/18/2014	7/18/2014	7/18/2014	7/18/2014	7/18/2014
	Collection D	Depth (ft bgs):	4.8	15	9.5	15	9.5	15	4	4.7	3.5	4.5	8.5
	MTCA	MTCA											
	URLU	Industrial											
4-Chlorotoluene	NV	NV											
4-Isopropyltoluene	NV	NV											
4-Methyl-2-pentanone	NV	NV											
Acetone	NV	NV											
Benzene	0.03	0.03	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U
Bromobenzene	NV	NV											
Bromodichloromethane	NV	NV											
Bromoform	NV	NV											
Bromomethane	NV	NV											
Carbon tetrachloride	NV	NV											
Chlorobenzene	NV	NV											
Chloroethane	NV	NV											
Chloroform	NV	NV											
Chloromethane	NV	NV											
cis-1,2-Dichloroethene	NV	NV											
cis-1,3-Dichloropropene	NV	NV											
Dibromochloromethane	NV	NV											
Dibromomethane	NV	NV											
Dichlorodifluoromethane	NV	NV											
Ethylbenzene	6	6	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U
Hexachlorobutadiene	NV	NV											
Isopropylbenzene	NV	NV											
m,p-Xylene	NV	NV											
Methyl tert-butyl ether	0.1	0.1											
Methylene chloride	0.02	0.02											
Naphthalene	5	5											
n-Hexane	NV	NV											
n-Propylbenzene	NV	NV											
o-Xylene	NV	NV											
sec-Butylbenzene	NV	NV											
Styrene	NV	NV											
tert-Butylbenzene	NV	NV											
Tetrachloroethene	0.05	0.05											

# Table 1 Summary of Soil Analytical Results Truck City Site Property Mount Vernon, Washington

Page 10 of 13

		Location:	TCBH-6	TCBH-7	TCBH-8	TCBH-8	TCBH-9	TCBH-9	TCBH-10	TCBH-11	TCBH-12	TCBH-13	TCBH-14
	Sa	ample Name:	TCBH6-S-4.8	TCBH7-S-15.0	TCBH8-S-9.5	TCBH8-S-15.0	TCBH9-S-9.5	TCBH9-S-15.0	TCBH10-S-4.0	TCBH11-S-4.7	TCBH12-S-3.5	TCBH13-S-4.5	TCBH14-S-8.5
	Coll	ection Date:	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/18/2014	7/18/2014	7/18/2014	7/18/2014	7/18/2014
	Collection D	epth (ft bgs):	4.8	15	9.5	15	9.5	15	4	4.7	3.5	4.5	8.5
	MTCA	MTCA											
	IVIEthod A	Method A											
	UNEO	maasman											
Toluene	7	7	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U	0.02 U
trans-1,2-dichloroethene	NV	NV											
trans-1,3-Dichloropropene	NV	NV											
Trichloroethene	0.03	0.03											
Trichlorofluoromethane	NV	NV											
Vinyl chloride	NV	NV											
Xylenes, Total	9	9	0.06 U	0.06 U	0.06 U	0.06 U	0.06 U	0.06 U	0.06 U	0.06 U	0.06 U	0.06 U	0.06 U
PAHs (mg/kg)								•	•		•		•
1-Methylnaphthalene	NV	NV											
2-Methylnaphthalene	NV	NV											
Acenaphthene	NV	NV											
Acenaphthylene	NV	NV											
Anthracene	NV	NV											
Benzo(a)anthracene	NV	NV											
Benzo(a)pyrene	0.1	2											
Benzo(b)fluoranthene	NV	NV											
Benzo(ghi)perylene	NV	NV											
Benzo(k)fluoranthene	NV	NV											
Chrysene	NV	NV											
Dibenzo(a,h)anthracene	NV	NV											
Fluoranthene	NV	NV											
Fluorene	NV	NV											
Indeno(1,2,3-cd)pyrene	NV	NV											
Naphthalene	5	5											
Phenanthrene	NV	NV											
Pyrene	NV	NV											
Metals (mg/kg)					-					1		1	
Arsenic	20	20											
Barium	NV	NV											
Cadmium	2	2											
Chromium	19 <sup>a</sup>	19 <sup>a</sup>											
Lead	250	1000											
Mercury	2	2											

# Table 1 Summary of Soil Analytical Results Truck City Site Property Mount Vernon, Washington

Page 11 of 13

		Location:	TCBH-6	TCBH-7	TCBH-8	TCBH-8	TCBH-9	TCBH-9	TCBH-10	TCBH-11	TCBH-12	TCBH-13	TCBH-14
	Sa	ample Name:	TCBH6-S-4.8	TCBH7-S-15.0	TCBH8-S-9.5	TCBH8-S-15.0	TCBH9-S-9.5	TCBH9-S-15.0	TCBH10-S-4.0	TCBH11-S-4.7	TCBH12-S-3.5	TCBH13-S-4.5	TCBH14-S-8.5
	Col	lection Date:	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/18/2014	7/18/2014	7/18/2014	7/18/2014	7/18/2014
	Collection [	Depth (ft bgs):	4.8	15	9.5	15	9.5	15	4	4.7	3.5	4.5	8.5
	MTCA Method A URLU	MTCA Method A Industrial											
Selenium	NV	NV											
Silver	NV	NV											
EPH (mg/kg)													
C8-C10 Aliphatic Hydrocarbons	NV	NV											
C10-C12 Aliphatic Hydrocarbons	NV	NV											
C12-C16 Aliphatic Hydrocarbons	NV	NV											
C16-C21 Aliphatic Hydrocarbons	NV	NV											
C21-C34 Aliphatic Hydrocarbons	NV	NV											
C8-C10 Aromatic Hydrocarbons	NV	NV											
C10-C12 Aromatic Hydrocarbons	NV	NV											
C12-C16 Aromatic Hydrocarbons	NV	NV											
C16-C21 Aromatic Hydrocarbons	NV	NV											
C21-C34 Aromatic Hydrocarbons	NV	NV											

### NOTES:

Result values in **bold** font indicate exceedance of MTCA Method A cleanup level. Non-detect results are not evaluated against MTCA cleanup levels. Analytes and sample names with exceedances are also in **bold** font. -- = not analyzed. EPH = extractable petroleum hydrocarbons.

ft bgs = feet below ground surface.

J = the result is an estimated value.

mg/kg = milligrams per kilogram.

MTCA Method A = Model Toxics Control Act Method A.

ND = not detected

NV = no value.

PAHs = polycyclic aromatic hydrocarbons.

R = roentgen

TPH = total petroleum hydrocarbons.

U = the result is non-detect.

URLU = unrestricted land use.

VOCs = volatile organic compounds.

<sup>a</sup>MTCA Method A CUL for Hexavalent Chromium.

	Location:	TC-1	IC-1	IC-2	IC-3	TC-4	TC-5	TC-6	TCBH-1	TCBH-2
	Sample Name:	TC1-W-10.0	TCDup-W-10.0	TC2-W-10.0	TC3-W-10.0	TC4-W-10.0	TC5-W-10.0	TC6-W-10.0	TCBH1-W-8.5	TCBH2-W-8.5
	Collection Date:	7/17/2014	7/17/2014	7/18/2014	7/17/2014	7/18/2014	7/17/2014	7/18/2014	7/15/2014	7/15/2014
	Collection Depth (ft bas):	10	10	10	10	10	10	10	8.5	8.5
		-	-	-	-		-			
	MTCA Method A									
TPH (ug/L)						•				
Gasoline Range Hydrocarbons	800	100 U	100 U	100 U	380	100 U	800	100 U	100 U	100 U
Diesel Range Hydrocarbons	500	120 J		50 U		50 U	360 J	89 J	<b>790</b> J	50 U
Motor Oil Range Hydrocarbons	500	250 U		250 U		250 U	250 U	250 U	250 U	250 U
TPH Identification										
Gasoline Range Hydrocarbons	NV									
Diesel Range Hydrocarbons	NV									
Motor Oil Range Hydrocarbons	NV									
VOCs (ug/L)										
1,1,1,2-Tetrachloroethane	NV	1 U			1 U					
1,1,1-Trichloroethane	200	1 U			1 U					
1,1,2,2-Tetrachloroethane	NV	1 U			1 U					
1,1,2-Trichloroethane	NV	1 U			1 U					
1,1-Dichloroethane	NV	1 U			1 U					
1,1-Dichloroethene	NV	1 U			1 U					
1,1-Dichloropropene	NV	1 U			1 U					
1,2,3-Trichlorobenzene	NV	1 U			1 U					
1,2,3-Trichloropropane	NV	1 U			1 U					
1,2,4-Trichlorobenzene	NV	1 U			1 U					
1,2,4-Trimethylbenzene	NV	1 U			23					
1,2-Dibromo-3-chloropropane	NV	10 U			10 U					
1,2-Dibromoethane	0.01	0.01 U			0.01 U					
1,2-Dichlorobenzene	NV	1 U			1 U					
1,2-Dichloroethane	NV	1 U			1 U					
1,2-Dichloropropane	NV	1 U			1 U					
1,3,5-Trimethylbenzene	NV	1 U			6.2					
1,3-Dichlorobenzene	NV	1 U			1 U					
1,3-Dichloropropane	NV	1 U			1 U					
1,4-Dichlorobenzene	NV	1 U			1 U					
2,2-Dichloropropane	NV	1 U			1 U					

### Table 2

	Location: Sample Name:	TC-1 TC1-W-10.0	TC-1 TCDup-W-10.0	TC-2 TC2-W-10.0	TC-3 TC3-W-10.0	TC-4 TC4-W-10.0	TC-5 TC5-W-10.0	TC-6 TC6-W-10.0	TCBH-1 TCBH1-W-8.5	TCBH-2 TCBH2-W-8.5
	Collection Date:	7/17/2014	7/17/2014	7/18/2014	7/17/2014	7/18/2014	7/17/2014	7/18/2014	7/15/2014	7/15/2014
	Collection Depth (ft bgs):	10	10	10	10	10	10	10	8.5	8.5
	MTCA Method A									
2-Butanone	NV	10 U			10 U					
2-Chlorotoluene	NV	1 U			1 U					
2-Hexanone	NV	10 U			10 U					
4-Chlorotoluene	NV	1 U			1 U					
4-Isopropyltoluene	NV	1 U			1 U					
4-Methyl-2-pentanone	NV	10 U			10 U					
Acetone	NV	10 U			10 U					
Benzene	5	0.35 U	1 U	1 U	1.2	1 U	22	1 U	1 U	1 U
Bromobenzene	NV	1 U			1 U					
Bromodichloromethane	NV	1 U			1 U					
Bromoform	NV	1 U			1 U					
Bromomethane	NV	1 U			1 U					
Carbon tetrachloride	NV	1 U			1 U					
Chlorobenzene	NV	1 U			1 U					
Chloroethane	NV	1 U			1 U					
Chloroform	NV	1 U			1 U					
Chloromethane	NV	10 U			10 U					
cis-1,2-Dichloroethene	NV	1 U			1 U					
cis-1,3-Dichloropropene	NV	1 U			1 U					
Dibromochloromethane	NV	1 U			1 U					
Dibromomethane	NV	1 U			1 U					
Dichlorodifluoromethane	NV	1 UJ			1 UJ					
Ethylbenzene	700	1 U	1 U	1 U	8.1	1 U	25	1 U	1 U	1 U
Hexachlorobutadiene	NV	1 U			1 U					
Isopropylbenzene	NV	1 U			1 U					
m,p-Xylene	NV	2 U			27					
Methyl tert-butyl ether	20	1 U			1 U					
Methylene chloride	5	5 U			5 U					

	Location:	TC-1	TC-1	TC-2	TC-3	TC-4	TC-5	TC-6	TCBH-1	TCBH-2
	Sample Name:	TC1-W-10.0	TCDup-W-10.0	TC2-W-10.0	TC3-W-10.0	TC4-W-10.0	TC5-W-10.0	TC6-W-10.0	TCBH1-W-8.5	TCBH2-W-8.5
	Collection Date:	7/17/2014	7/17/2014	7/18/2014	7/17/2014	7/18/2014	7/17/2014	7/18/2014	7/15/2014	7/15/2014
	Collection Depth (ft bgs):	10	10	10	10	10	10	10	8.5	8.5
	MTCA Method A									
Naphthalene	160	1 U			5.2					
n-Hexane	NV	1 U			12					
n-Propylbenzene	NV	1 U			2.8					
o-Xylene	NV	1 U			5.6					
sec-Butylbenzene	NV	1 U			1 U					
Styrene	NV	1 U			1 U					
tert-Butylbenzene	NV	1 U			1 U					
Tetrachloroethene	5	1 U			1 U					
Toluene	1000	1 U	1 U	1 U	1 U	1 U	1.7	1 U	1 U	1 U
trans-1,2-dichloroethene	NV	1 U			1 U					
trans-1,3-Dichloropropene	NV	1 U			1 U					
Trichloroethene	5	1 U			1 U					
Trichlorofluoromethane	NV	1 U			1 U					
Vinyl chloride	0.2	0.2 U			0.2 U					
Xylenes, Total	1000		3 U	3 U		3 U	130	3 U	3 U	3 U
PAHs (ug/L)						-				
1-Methylnaphthalene	NV	0.1 U			0.28		0.77			
2-Methylnaphthalene	NV	0.1 U			0.34		0.48			
Acenaphthene	NV	0.1 U			0.1 U	0.1 U	0.1 U			
Acenaphthylene	NV	0.1 U			0.1 U	0.1 U	0.1 U			
Anthracene	NV	0.1 U			0.1 U	0.1 U	0.1 U			
Benzo(a)anthracene	NV	0.1 U			0.1 U	0.1 U	0.1 U			
Benzo(a)pyrene	0.1	0.1 U			0.1 U	0.1 U	0.1 U			
Benzo(b)fluoranthene	NV	0.1 U			0.1 U	0.1 U	0.1 U			
Benzo(ghi)perylene	NV	0.1 U			0.1 U	0.1 U	0.1 U			
Benzo(k)fluoranthene	NV	0.1 U			0.1 U	0.1 U	0.1 U			
Chrysene	NV	0.1 U			0.1 U	0.1 U	0.1 U			

# Table 2Summary of Groundwater Analytical ResultsTruck City Site Property

# Mount Vernon, Washington

	Location:	TC-1	TC-1	TC-2	TC-3	TC-4	TC-5	TC-6	TCBH-1	TCBH-2
	Sample Name:	TC1-W-10.0	TCDup-W-10.0	TC2-W-10.0	TC3-W-10.0	TC4-W-10.0	TC5-W-10.0	TC6-W-10.0	TCBH1-W-8.5	TCBH2-W-8.5
	Collection Date:	7/17/2014	7/17/2014	7/18/2014	7/17/2014	7/18/2014	7/17/2014	7/18/2014	7/15/2014	7/15/2014
	Collection Depth (ft bgs):	10	10	10	10	10	10	10	8.5	8.5
	MTCA Method A									
Dibenzo(a,h)anthracene	NV	0.1 U			0.1 U	0.1 U	0.1 U			
Fluoranthene	NV	0.1 U			0.1 U	0.1 U	0.1 U			
Fluorene	NV	0.1 U			0.1 U	0.1 U	0.1 U			
Indeno(1,2,3-cd)pyrene	NV	0.1 U			0.1 U	0.1 U	0.1 U			
Naphthalene	160	0.1 U			0.83	0.1 U	8.6			
Phenanthrene	NV	0.1 U			0.1 U	0.1 U	0.1 U			
Pyrene	NV	0.1 U			0.1 U	0.1 U	0.1 U			
Total Metals (ug/L)										
Arsenic	5			<b>7.1</b> J	1.29					
Barium	NV			125 J	85.3					
Cadmium	NV			1 UJ	1 U					
Chromium	NV			1.02 J	2.29					
Lead	15			1 UJ	1 U					
Manganese	NV		1300 J		708					
Mercury	2			0.25 U	0.1 U					
Selenium	NV			1 UJ	1 U					
Silver	NV			1 UJ	1 U					
Dissolved Metals (ug/L)						•				
Arsenic	5			1.37						
Barium	NV			79.8						
Cadmium	NV			1 U						
Chromium	NV			1 U						
Lead	15			1 U						
Manganese	NV	1200								
Mercury	2			0.1 U						
Selenium	NV			1 U						
Silver	NV			1 U						
Dissolved Gases (ug/L)	· · · · · · · · · · · · · · · · · · ·		-	-	-	-	-	-	-	-

# Table 2

	Location:	TC-1	TC-1	TC-2	TC-3	TC-4	TC-5	TC-6	TCBH-1	TCBH-2
	Sample Name:	TC1-W-10.0	TCDup-W-10.0	TC2-W-10.0	TC3-W-10.0	TC4-W-10.0	TC5-W-10.0	TC6-W-10.0	TCBH1-W-8.5	TCBH2-W-8.5
	Collection Date:	7/17/2014	7/17/2014	7/18/2014	7/17/2014	7/18/2014	7/17/2014	7/18/2014	7/15/2014	7/15/2014
	Collection Depth (ft bas):	10	10	10	10	10	10	10	8.5	8.5
									010	0.0
	MTCA Method A									
Methane	NV	7.1			48					
Anions (mg/L)	-		-			-			-	
Nitrate	NV	0.329 J			1.47					
Sulfate	NV	198			126					
Ferrous Iron (mg/L)										
Ferrous Iron	NV	16.4			5.4					
EPH (ug/L)										
C8-C10 Aliphatic Hydrocarbons	NV	80 U					213 U			
C10-C12 Aliphatic Hydrocarbons	NV	80 U					213 U			
C12-C16 Aliphatic Hydrocarbons	NV	80 U					213 U			
C16-C21 Aliphatic Hydrocarbons	NV	80 U					213 U			
C21-C34 Aliphatic Hydrocarbons	NV	162					271			
C8-C10 Aromatic Hydrocarbons	NV	89.9 J					213 UJ			
C10-C12 Aromatic Hydrocarbons	NV	80 UJ					213 UJ			
C12-C16 Aromatic Hydrocarbons	NV	80 U					213 U			
C16-C21 Aromatic Hydrocarbons	NV	86					676			
C21-C34 Aromatic Hydrocarbons	NV	14500					49000			
VPH (ug/L)										
C5-C6 Aliphatic Hydrocarbons	NV	10 U			214					
C6-C8 Aliphatic Hydrocarbons	NV	10 U			80.7					
C8-C10 Aliphatic Hydrocarbons	NV	10 U			44.3					
C10-C12 Aliphatic Hydrocarbons	NV	10 U			99.2					
C8-C10 Aromatic Hydrocarbons	NV	10 U			82.6					
C10-C12 Aromatic Hydrocarbons	NV	10 U			117					
C12-C13 Aromatic Hydrocarbons	NV	10 U			10 U					
Benzene	5	5 U			5 U					
Ethylbenzene	700	5 U			6.93					
m,p-Xylene	NV	5 U			22.9					
o-Xylene	NV	5 U			5 U					
Methyl tert-butyl ether	20	5 U			5 U					
Naphthalene	160	5 U			5 U					
Toluene	1000	5 U			5 U					

	Location:	TCBH-3	TCBH-4	TCBH-5	TCBH-5	TCBH-6	TCBH-7	TCBH-8	TCBH-9	TCBH-10	TCBH-13
	Sample Name:	TCBH3-W-8.5	TCBH4-W-6.0	TCBH5-W-4.5 (1)	TCBH5-W-4.5 (2)	TCBH6-W-4.8	TCBH7-W-6.5	TCBH8-W-9.5	TCBH9-W-6.5	TCBH10-W-4.0	TCBH13-W-4.5
	Collection Date:	7/15/2014	7/15/2014	7/18/2014	7/18/2014	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/18/2014	7/18/2014
	Collection Depth (ft bgs):	8.5	6	4.5	4.5	4.8	6.5	9.5	6.5	4	4.5
	MTCA Method A										
Gasoline Pange Hydrocarbons	800	1900	100 11	100 11	100 []		100 U	100 11	100 11		
Diosol Pango Hydrocarbons	500	1100	120 1	210 1	210 1		56 1	50 U	50 U		
Motor Oil Range Hydrocarbons	500	250 U	250 11	210 J	210 J		250 J	250 U	250 U		
TPH Identification	500	230 0	230 0	230 0	230 0		230 0	230 0	230 0		
Gasoline Range Hydrocarbons	NV					ND				ND	ND
Diesel Range Hydrocarbons	NV					ND				ND	ND
Motor Oil Range Hydrocarbons	NV					ND				ND	ND
VOCs (ug/L)											110
1.1.1.2-Tetrachloroethane	NV	1 U									
1,1,1-Trichloroethane	200	1 U									
1,1,2,2-Tetrachloroethane	NV	1 U									
1,1,2-Trichloroethane	NV	1 U									
1,1-Dichloroethane	NV	1 U									
1,1-Dichloroethene	NV	1 U									
1,1-Dichloropropene	NV	1 U									
1,2,3-Trichlorobenzene	NV	1 U									
1,2,3-Trichloropropane	NV	1 U									
1,2,4-Trichlorobenzene	NV	1 U									
1,2,4-Trimethylbenzene	NV	160									
1,2-Dibromo-3-chloropropane	NV	10 U									
1,2-Dibromoethane	0.01	0.01 U									
1,2-Dichlorobenzene	NV	1 U									
1,2-Dichloroethane	NV	1 U									
1,2-Dichloropropane	NV	1 U									
1,3,5-Trimethylbenzene	NV	54									
1,3-Dichlorobenzene	NV	1 U									
1,3-Dichloropropane	NV	1 U									
1,4-Dichlorobenzene	NV	1 U									
2,2-Dichloropropane	NV	1 U									

	Location:	TCBH-3	TCBH-4	TCBH-5	TCBH-5	TCBH-6	TCBH-7	TCBH-8	TCBH-9	TCBH-10	TCBH-13
	Sample Name:	TCBH3-W-8.5	TCBH4-W-6.0	TCBH5-W-4.5 (1)	TCBH5-W-4.5 (2)	TCBH6-W-4.8	TCBH7-W-6.5	TCBH8-W-9.5	TCBH9-W-6.5	TCBH10-W-4.0	TCBH13-W-4.5
	Collection Date:	7/15/2014	7/15/2014	7/18/2014	7/18/2014	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/18/2014	7/18/2014
	Collection Depth (ft bgs):	8.5	6	4.5	4.5	4.8	6.5	9.5	6.5	4	4.5
	MTCA Method A										
2-Butanone	NV	10 U									
2-Chlorotoluene	NV	1 U									
2-Hexanone	NV	10 U									
4-Chlorotoluene	NV	1 U									
4-Isopropyltoluene	NV	2.1									
4-Methyl-2-pentanone	NV	10 U									
Acetone	NV	10 U									
Benzene	5	4.2	1 U	1 U	1 U	1 U	1 U	1 U	1 U	1 U	1 U
Bromobenzene	NV	1 U									
Bromodichloromethane	NV	1 U									
Bromoform	NV	1 U									
Bromomethane	NV	1 U									
Carbon tetrachloride	NV	1 U									
Chlorobenzene	NV	1 U									
Chloroethane	NV	1 U									
Chloroform	NV	1 U									
Chloromethane	NV	10 U									
cis-1,2-Dichloroethene	NV	1 U									
cis-1,3-Dichloropropene	NV	1 U									
Dibromochloromethane	NV	1 U									
Dibromomethane	NV	1 U									
Dichlorodifluoromethane	NV	1 UJ									
Ethylbenzene	700	160	1 U	1 U	1 U	1 U	1 U	1 U	1 U	1 U	1 U
Hexachlorobutadiene	NV	1 U									
Isopropylbenzene	NV	21									
m,p-Xylene	NV	50									
Methyl tert-butyl ether	20	1 U									
Methylene chloride	5	5 U									

	Location:	TCBH-3	TCBH-4	TCBH-5	TCBH-5	TCBH-6	TCBH-7	TCBH-8	TCBH-9	TCBH-10	TCBH-13
	Sample Name:	TCBH3-W-8.5	TCBH4-W-6.0	TCBH5-W-4.5 (1)	TCBH5-W-4.5 (2)	TCBH6-W-4.8	TCBH7-W-6.5	TCBH8-W-9.5	TCBH9-W-6.5	TCBH10-W-4.0	TCBH13-W-4.5
	Collection Date:	7/15/2014	7/15/2014	7/18/2014	7/18/2014	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/18/2014	7/18/2014
	Collection Depth (ft bgs):	8.5	6	4.5	4.5	4.8	6.5	9.5	6.5	4	4.5
	MTCA Method A										
Naphthalene	160	95									
n-Hexane	NV	41									
n-Propylbenzene	NV	70									
o-Xylene	NV	3.8									
sec-Butylbenzene	NV	4.4									
Styrene	NV	1 U									
tert-Butylbenzene	NV	1 U									
Tetrachloroethene	5	1 U									
Toluene	1000	1 U	1 U	1 U	1 U	1 U	1 U	1 U	1 U	1 U	1 U
trans-1,2-dichloroethene	NV	1 U									
trans-1,3-Dichloropropene	NV	1 U									
Trichloroethene	5	1 U									
Trichlorofluoromethane	NV	1 U									
Vinyl chloride	0.2	0.2 U									
Xylenes, Total	1000		3 U	3 U	3 U	3 U	3 U	3 U	3 U	3 U	3 U
PAHs (ug/L)											
1-Methylnaphthalene	NV										
2-Methylnaphthalene	NV										
Acenaphthene	NV				0.1 U						
Acenaphthylene	NV				0.1 U						
Anthracene	NV				0.1 U						
Benzo(a)anthracene	NV				0.1 U						
Benzo(a)pyrene	0.1				0.1 U						
Benzo(b)fluoranthene	NV				0.1 U						
Benzo(ghi)perylene	NV				0.1 U						
Benzo(k)fluoranthene	NV				0.1 U						
Chrysene	NV				0.1 U						

	Location:	TCBH-3	TCBH-4	TCBH-5	TCBH-5	TCBH-6	TCBH-7	TCBH-8	TCBH-9	TCBH-10	TCBH-13
	Sample Name:	TCBH3-W-8.5	TCBH4-W-6.0	TCBH5-W-4.5 (1)	TCBH5-W-4.5 (2)	TCBH6-W-4.8	TCBH7-W-6.5	TCBH8-W-9.5	TCBH9-W-6.5	TCBH10-W-4.0	TCBH13-W-4.5
	Collection Date:	7/15/2014	7/15/2014	7/18/2014	7/18/2014	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/18/2014	7/18/2014
	Collection Depth (ft bgs):	8.5	6	4.5	4.5	4.8	6.5	9.5	6.5	4	4.5
	MTCA Method A										
Dibenzo(a,h)anthracene	NV				0.1 U						
Fluoranthene	NV				0.1 U						
Fluorene	NV				0.1 U						
Indeno(1,2,3-cd)pyrene	NV				0.1 U						
Naphthalene	160				0.1 U						
Phenanthrene	NV				0.1 U						
Pyrene	NV				0.1 U						
Total Metals (ug/L)						•				• •	
Arsenic	5										
Barium	NV										
Cadmium	NV										
Chromium	NV										
Lead	15										
Manganese	NV										
Mercury	2										
Selenium	NV										
Silver	NV										
Dissolved Metals (ug/L)											
Arsenic	5										
Barium	NV										
Cadmium	NV										
Chromium	NV										
Lead	15										
Manganese	NV										
Mercury	2										
Selenium	NV										
Silver	NV										
Dissolved Gases (ug/L)											

	Location:	TCBH-3	TCBH-4	TCBH-5	TCBH-5	TCBH-6	TCBH-7	TCBH-8	TCBH-9	TCBH-10	TCBH-13
	Sample Name:	TCBH3-W-8.5	TCBH4-W-6.0	TCBH5-W-4.5 (1)	TCBH5-W-4.5 (2)	TCBH6-W-4.8	TCBH7-W-6.5	TCBH8-W-9.5	TCBH9-W-6.5	TCBH10-W-4.0	TCBH13-W-4.5
	Collection Date:	7/15/2014	7/15/2014	7/18/2014	7/18/2014	7/16/2014	7/16/2014	7/16/2014	7/16/2014	7/18/2014	7/18/2014
	Collection Depth (ft bas):	8.5	6	4.5	4.5	4.8	6.5	9.5	6.5	4	4.5
	oolicetion Deptin (n bg3).	010					0.0	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	0.0		
	MTCA Method A										
Methane	NV										
Anions (mg/L)	-										
Nitrate	NV										
Sulfate	NV										
Ferrous Iron (mg/L)											
Ferrous Iron	NV										
EPH (ug/L)											
C8-C10 Aliphatic Hydrocarbons	NV										
C10-C12 Aliphatic Hydrocarbons	NV										
C12-C16 Aliphatic Hydrocarbons	NV										
C16-C21 Aliphatic Hydrocarbons	NV										
C21-C34 Aliphatic Hydrocarbons	NV										
C8-C10 Aromatic Hydrocarbons	NV										
C10-C12 Aromatic Hydrocarbons	NV										
C12-C16 Aromatic Hydrocarbons	NV										
C16-C21 Aromatic Hydrocarbons	NV										
C21-C34 Aromatic Hydrocarbons	NV										
VPH (ug/L)											
C5-C6 Aliphatic Hydrocarbons	NV										
C6-C8 Aliphatic Hydrocarbons	NV										
C8-C10 Aliphatic Hydrocarbons	NV										
C10-C12 Aliphatic Hydrocarbons	NV										
C8-C10 Aromatic Hydrocarbons	NV										
C10-C12 Aromatic Hydrocarbons	NV										
C12-C13 Aromatic Hydrocarbons	NV										
Benzene	5										
Ethylbenzene	700										
m,p-Xylene	NV										
o-Xylene	NV										
Methyl tert-butyl ether	20										
Naphthalene	160										
Toluene	1000										

### NOTES:

Result values in **bold** font indicate exceedance of MTCA Method A cleanup level. Non-detect results are not evaluated against MTCA cleanup levels. Analytes and sample names with exceedances are also in **bold** font.

-- = not analyzed.

EPH = extractable petroleum hydrocarbons.

ft bgs = feet below ground surface.

J = the result is an estimated value.

mg/L = milligrams per liter.

MTCA Method A = Model Toxics Control Act Method A.

ND = not detected

NV = no value.

PAHs = polycyclic aromatic hydrocarbons.

TPH = total petroleum hydrocarbons.

U = the result is non-detect.

ug/L = micrograms per liter.

VOCs = volatile organic compounds.

VPH = volatile petroleum hydrocarbons.

<sup>a</sup>MTCA Method A CUL for Hexavalent Chromium.

### Table 3 Remediation Levels at All Monitoring Wells Truck City Site Property Mount Vernon, Washington

Indicator Hazardous Substance:	Gasoline-range TPH	Diesel-range TPH	Benzene	Arsenic							
Cleanup Level (ug/L):	800	500	5	5							
Remediation Levels at All Monitoring Wells (ug/L)											
Sentinel wells											
TC-1 (southern perimeter of Site)	100U	120J	1U								
TC-2 (western perimeter of Site)	100U	50U	1U	7.1J							
TC-4 (northwestern perimeter of Site)	100U	50U	1U								
TC-6 (southwestern perimeter of Site)	100U	1U									
Wells in interior of Site											
TC-3 (source area well)	380		1.2	1.29							
TC-5 (source area well)	800	360J	22								
NOTES:											
= not analyzed											
J = Result is an estimated value.											
TPH = total petroleum hydrocarbons.											
U = Result is non-detect.											
ug/L = micrograms per liter.											

# FIGURES







This prod for legal,

Source: US Geological Survey (1990) 7.5-minute topographic quadrangle: Mount Vernon Section 32, Township 34 North, Range 4 East

MAUL FOSTER ALONGI p. 971 544 2139 | www.maulfoster.com

uct is for informational purposes and may not have been prepared for, or be suitable nigineening, or surveying purposes. Users of this information should review or primary data and information sources to ascertain the surfaction of the surfaction.



### Figure 1 Site Location

Truck City Site Mount Vernon, Washington





Source: Aerial photograph obtained from Esri ArcGIS Online; parcels obtained from Skagit County.

### Aerial Imagery Date: 1999



This product is for informational purposes and may not have been prepared for, or be suitable for legal, engineering, or surveying purposes. Users of this information should review or consult the primary data and information sources to ascertain the usability of the information.

# Legend



# Figure 2 Site Parcels Map Truck City Site Mount Vernon, Washington



oject:

ŝ



# Figure 3 Site Features & Previous **Environmental Investigations**

Truck City Site Mount Vernon, Washington

Legend

### **Previous Investigation**

•	Hand Auger - Surface Sediment Sample
•	Soil Borings
Ð	Active Monitoring Well
X	Decommissioned - No Steel Monument
ø	Decommissioned - Steel Monument
	Former Soil Excavation Area
	USTs
	Septic System
	Parcel Boundary
$\searrow$	Catch Basin

Aerial Imagery Date: 2010

Notes:

- 1. Site features were digitized from figures prepared by Materials Testing & Consulting, Inc., Associated Environmental Group, LLC, and Applied Geotechnology, Inc. 2. The locations of all features are approximate.



Source: Aerial photograph obtained from Esri ArcGIS Online; parcels obtained from Skagit County



This product is for informational purposes and may not have been prepared for, or be suitable for legal, engineering, or surveying purposes. Users of this information should review or consult the primary data and information sources to ascertain the usability of the inform



# Figure 4 Site Features and Locations of Investigations

Truck City Site Mount Vernon, Washington

### Legend

### **MFA Investigation**

- Boring
- Monitoring Well

### **Previous Investigation**

Existing Monitoring Well



Former Soil Excavation Area



### **Underground Utilities**

- Communications - Electric Gas Water USTs Septic System
  - Site Boundary
  - Parcel Boundary

### Aerial Imagery Date: 2010

Notes:

- 1. Site features were digitized from figures prepared by Materials Testing & Consulting, Inc., Associated Environmental Group, LLC, and Applied Geotechnology, Inc. Utilities and well positions imported from survey by Pacific Geomatic Services in July 2014. 2. The locations of digitized features are approximate.





Source: Aerial photograph obtained from Esri ArcGIS Online; parcels obtained from Skagit County; well and utility positions from Pacific Geomatic Services, July 2014



This product is for informational purposes and may not have been prepared for, or be suitable for legal, engineering, or surveying purposes. Users of this information should review or tion sources to ascertain the usability of the infor





# Figure 5 Cross Section Transect

Truck City Site Mount Vernon, Washington

# Legend

### **MFA** Investigation

- Boring
- Monitoring Well

### **Previous Investigation**

- Existing Monitoring Well Former Soil Excavation Area
- CrossSectionTransect USTs Site Boundary
  - Parcel Boundary
- Catch Basin

### Aerial Imagery Date: 2010

- Notes: 1. Site features were digitized from figures pre-pared by Materials Testing & Consulting, Inc., Associated Environmental Group, LLC, and Applied Geotechnology, Inc. Utilities and well positions imported from survey by Pacific Geomatic Services in July 2014. 2. The locations of digitized features are approximate.



Source: Aerial photograph obtained from Esri ArcGIS Online; parcels obtained from Skagit County; well and utility positions from Pacific Geomatic Services, July 2014



This product is for informational purposes and may not have been prepared for, or be suitable for legal, engineering, or surveying purposes. Users of this information should review or consult the primary data and information sources to ascertain the usability of the inform





Path: X:\0714.02 Skagit County Truck City/Projects\Fig\_7 Groundwater Potentiometric M

4.02 Produced By: gherbert Approved By: Print Date: 10/30/2014

# Figure 7 Groundwater Potentiometric Map - July 2014

Truck City Site Mount Vernon, Washington

# Legend



Groundwater Flow Direction

### **Previous Investigation**

Existing Monitoring Well
 Catch Basin
 USTs
 Septic System

Site Boundary

Parcel Boundary

Aerial Imagery Date: 2010

### Notes:

- 1. MSL = mean sea level.
- Site features were digitized from figures prepared by Materials Testing & Consulting, Inc., Associated Environmental Group, LLC, and Applied Geotechnology, Inc. Utilities and well positions imported from survey by Pacific Geomatic Services in July 2014.
- 3. Groundwater elevations were measured July 2014.



Source: Aerial photograph obtained from Esri ArcGIS Online; parcels obtained from Skagit County; well and utility positions from Pacific Geomatic Services, July 2014



This product is for informational purposes and may not have been prepared for, or be suitable for legal, engineering, or surveying purposes. Users of this information should review or consult the primary data and information sources to ascertain the usability of the information.



# Figure 8 Soil Analytical **Results**

Truck City Site Mount Vernon, Washington

### Legend

### **MFA** Investigation

•	Boring
Ð	Monitoring Well
$\ge$	Catch Basin
	USTs
	Septic System
	Site Boundary

# Parcel Boundary

### Notes:

- Analysis Results:
- NA = Not Analyzed.
- ND = Not Detected.
- mg/kg = Milligrams per Kilogram.
- PAH = Polycyclic Aromatic Hydrocarbons.
- TPH = Total Petroleum Hydrocarbons.

Results above Model Toxics Control Act (MCTA) Method A cleanup level are shown in **bold red** 

Refer to Table 1, Summary of Soil Analytical Results, for a complete summary of laboratory results.

Site features were digitized from figures pre-pared by Materials Testing & Consulting, Inc., Associated Environmental Group, LLC, and Applied Geotechnology, Inc. Utilities and well positions imported from survey by Pacific Geomatic Services in July 2014.

The locations of digitized features are approximate.

Aerial Imagery Date: 2010



Source: Aerial photograph obtained from Esri ArcGIS Online: parcels obtained from Skagit County; well and utility positions from Pacific Geomatic Services, July 2014



This product is for informational purposes and may not have been prepared for, or be suitable for legal, engineering, or surveying purposes. Users of this information should review or nsult the primary data and information sources to ascertain the usability of the inform



# Figure 9 **Groundwater Analytical Results**

Truck City Site Mount Vernon, Washington

### Legend

### **MFA Investigation**

•	Boring
Ð	Monitoring Well
$\mathbf{\times}$	Catch Basin
	USTs
	Septic System
	Site Boundary

# Parcel Boundary

### Notes:

- Analysis Results:
- NA = Not Analyzed.
- ND = Not Detected.
- PAH = Polycyclic Aromatic Hydrocarbons.
- TPH = Total Petroleum Hydrocarbons.
- ug/L = Micrograms per Liter.
- Results above Model Toxics Control Act (MCTA) Method A cleanup level are shown in **bold red**
- Refer to Table 2, Summary of Groundwater Analytical Results, for a complete summary of laboratory results.
- Site features were digitized from figures prepared by Materials Testing & Consulting, Inc., Associated Environmental Group, LLC, and Applied Geotechnology, Inc. Utilities and well positions imported from survey by Pacific Geomatic Services in July 2014.
- The locations of digitized features are approximate.

Aerial Imagery Date: 2010





Source: Aerial photograph obtained from Esri ArcGIS Online: parcels obtained from Skagit County; well and utility positions from Pacific Geomatic Services, July 2014



This product is for informational purposes and may not have been prepared for, or be suitable for legal, engineering, or surveying purposes. Users of this information should review or nation sources to ascertain the usability of the inform



# Figure 10 Proposed Skagit County Jail Site Conditions

Truck City Site Mount Vernon, Washington

### Legend

### **MFA** Investigation

•	Boring
Ð	Monitoring Well
$\mathbf{X}$	Catch Basin
	Building
	Hard Surface
4	Other
	Parcel Boundary

#### Notes:

Analysis Results:

- mg/kg = Milligrams/Kilogram. TPH = Total Petroleum Hydrocarbons.
- ug/L = Micrograms per Liter.

Only results above Model Toxics Control Act (MTCA) Method A cleanup level are shown.

Refer to Table 1, Summary of Soil Analytical Results and Table 2, Summary of Groundwater Analytical Results, for a complete summary of laboratory results.

Site features were digitized from figures pre-pared by Materials Testing & Consulting, Inc., Associated Environmental Group, LLC, and Applied Geotechnology, Inc. Utilities and well positions imported from survey by Pacific Geomatic Services in July 2014. The locations of digitized features are

approximate.

Aerial Imagery Date: 2010





Source: Aerial photograph obtained from Esri ArcGIS Online; parcels obtained from Skagit County; well and utility positions from Pacific Geomatic Services, July 2014



This product is for informational purposes and may not have been prepared for, or be suitable for legal, engineering, or surveying purposes. Users of this information should review or consult the primary data and information sources to ascertain the usability of the information



# Figure 11 **Compliance Monitoring** Well Network

Truck City Site Mount Vernon, Washington

### Legend

•

Monitoring Well and elevation in feet (MSL)

### **Previous Investigation**

Existing Monitoring Well



Catch Basin

USTs

Septic System

Site Boundary

Parcel Boundary

#### Aerial Imagery Date: 2010

### Notes:

- 1. MSL = mean sea level.
- MSL = mean sea level.
   Site features were digitized from figures pre-pared by Materials Testing & Consulting, Inc., Associated Environmental Group, LLC, and Applied Geotechnology, Inc. Utilities and well positions imported from survey by Pacific Geomatic Services in July 2014.
   Groundwater elevations were measured
- 3. Groundwater elevations were measured July 2014.



Source: Aerial photograph obtained from Esri ArcGIS Online; parcels obtained from Skagit County; well and utility positions from Pacific Geomatic Services, July 2014



This product is for informational purposes and may not have been prepared for, or be suitable for legal, engineering, or surveying purposes. Users of this information should review or for legal, engineering, or surveying purposes. Users of this information should review or consult the primary data and information sources to ascertain the usability of the informa-

# APPENDIX WELL LOGS



			G	eologic	Borehole Log/Well Construction			
Mau	Il Foster &	Alongi, Inc.	Project Numb 0714 02 02	per	Well Number TC-1	Sheet		
Proj Proj Stai Drill Geo San	iect Name iect Location tt/End Date ler/Equipment blogist/Engineer nple Method	Truck City Site Mount Vernon, 7/15/2014 to 7/1 Holt Services, I Yen-Vy Van Geoprobe	WA 7/2014 nc./Geoprobe 7822DT	<u> </u>	TOC Elevation (feet) Surface Elevation (feet) Northing Easting Hole Depth 15.0-feet Outer Hole Diam 3 5-inch			
(S	Well		ample Data		Soil Descripti	on		
Depth (feet, BG	Details	Interval Percent Recovery Collection Method	Name (Type)	Lithologic Column				
Ē		40 GP			0.0 to 0.4 feet: ASPHALT.			
Ē 1				0000	0.4 to 1.0 feet: BASE GRAVEL (GP)	; gray; 100% gravel. (FILL)		
3					1.0 to 5.0 feet: SILTY SAND with GF fines; 65% sand; 15% gravel; m	RAVEL (SM); medium brown; 20% edium dense; moist.		
E 5		10 GP	TC1-S1-5.0		5.0 to 10.0 feet: SANDY SILT (ML);	gray; 55% fines; 45% sand, fine		
E 6			PID = 0.0 ppm		grained; soft to medium stiff; mo	ist to wet @ 8.5 feet.		
		,				-		
7 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		7						
9		-	TC1-S2-8.5 PID = 0.0 ppm					
		100 GP			10.0 to 15.0 feet: POORLY GRADEL	D SAND (SP); gray; 5% fines;		
11					95% sand, well sorted, fine grain medium grained from 13.5 to 15.	ned from 10.0 to 13.5 feet, .0 feet; loose to medium dense;		
Ē					saturated.	· · · ·		
_ 12								
Ē								
13						-		
			TC1-S3-15.0					
		ID #DID 070 Davies		9" woli				
	PID = photoio ppm = parts p Water level obs drilling	pnization detector. per million.	Water le ■	evel observ	ed after well			
∩			<u> </u>					

				G	Geologic Borehole Log/Well Construction							
Mau	I Foster &	Alongi, In	<b>C.</b>	Project Numb	er	Well Number	Sheet					
Proj Proj Star Drill Geo San	Project Name Project Location Start/End Date Driller/Equipment Geologist/Engineer Sample Method Truck City Sit Mount Vernor 7/17/2014 to 7 Holt Services, Geoprobe			4 eoprobe 7822DT		TOC Elevation (fee Surface Elevation Northing Easting Hole Depth Outer Hole Diam	et) (feet) 15.0-feet 3.5-inch					
- San	Well	Geoprobe	Sample	a Data		Soil Description						
Depth (feet, BGS	Details	Interval Percent Recovery	Method Collection	Name (Type)	Lithologic Column							
Ē		20	GP			0.0 to 0.4 feet: ASPHALT.						
1 1 2 3 4 5						0.4 to 5.0 feet: SANDY GRAVEL (GW sand, fine to coarse; 60% gravel, medium dense; dry. (FILL)	/); tan brown; 5% fines; 35% fine to medium, subangular; - - - - - - - -					
6		100	GP			5.0 to 6.5 feet: SILTY SAND (SM); gr sand; medium dense; moist to we	ayish brown; 35% fines; 65% et @ 6.5 feet. -					
7 8 9				TC2-S-6.5 PID = 2.0 ppm TC2-S-9.0		6.5 to 10.0 feet: SILT (ML); medium to intermittent pockets of silty clay; s moist to wet @ 9.0 feet.	o dark gray; 100% fines; soft; saturated from 7.0 to 8.0 feet, 					
10 11 12 13		- 100 (	GP	TC2-S-12.0		10.0 to 14.5 feet: POORLY GRADED 95% sand, medium, well sorted; i 11.0-14.5 feet.	SAND (SP); gray; 5% fines; medium dense; saturated @ -					
14				TC2-S-15.0 PID = 0.0 ppm		14.5 to 15.0 feet: CLAY (CL); gray; 10 local wood chips; moist to wet.	00% fines, high plasticity; soft;					
NOTE	NOTES:       Ecology Well ID #BIP 879. Boring completed as pre-packed 2" well.         PID = photoionization detector.       ppm = parts per million.         Water level observed at time of diversion       Water level observed after well development.											

			_		Geologic Borehole Log/Well Construction						
Μαι	Il Foster &	Alongi,	Inc.	Project	Numb	er	Well Number	Sheet			
Pro Pro Sta Dril Geo Sau	Project Name     Truck City Site       Project Location     Mount Vernon,       Start/End Date     7/17/2014 to 7/1       Driller/Equipment     Holt Services, II       Geologist/Engineer     Yen-Vy Van       Sample Method     Geoprobe			VA 7/2014 c./Geoprobe 7822	2DT		TOC Elevation (fe Surface Elevation Northing Easting Hole Depth Outer Hole Diam	eet) (feet) 15.0-feet 3 5-inch			
	Well						Soil Description	0n			
Depth (feet, BGS	Details	Interval Percent Recovery	Collection Method	Name (Type)	Blows/6"	Lithologic Column					
Ē		100	GP				0.0 to 0.4 feet: ASPHALT.				
1     2     3     4       5     6     7     8     9     10       11     12     13		<u>7</u> 100	GP	ТС3-S-8.5 PID = 712 pp TC3-S-9.7 PID = 712 pp	m		<ul> <li>0.4 to 8.5 feet: SANDY GRAVEL (GV sand, fine to coarse; 60% gravel medium dense; dry. (FILL)</li> <li>8.5 to 9.0 feet: SILTY SAND (SM); gimedium dense; strong fuel odor;</li> <li>9.0 to 14.0 feet: POORLY GRADED 90% sand, medium, well sorted; gravel; strong fuel odor; moist to feet.</li> </ul>	<i>N</i> ); tan brown; 5% fines; 35% , fine to medium, subangular; ray; 35% fines; 65% sand; moist. SAND (SP); dark gray; 5% fines; 5% gravel; local fine subangular wet, saturated @ 10.0 to 11.5			
14				TC3-S-15.0 PID = 0.3 pp	) m		14.0 to 15.0 feet: SILTY SAND (SM), medium dense; moist to wet.	; gray; 35% fines; 65% sand;			
	ES: Ecology Well PID = photoic ppm = parts p Water level obs	ID #BIP 877. onization detec per million. served at tim	Boring tor. <b>ne of</b>	completed as pre-pa	cked 2 ater le	" well. Impact	ed from approximately 8.5 to 15.0 feet. ed after well				
iL ¥	arming.			<u> </u>	veiop	ment.					

					Geologic Borehole Log/Well Construction				
Mau	I Foster &	Alongi,	Inc.	Project	Numb	per	Well Number	Sheet	
Proj Proj Star Drill Geo San	ect Name ect Location t/End Date er/Equipment logist/Engineer nple Method	Truck City Site Mount Vernon, WA 7/16/2014 to 7/16/2014 Holt Services, Inc./Geoprobe 7822DT Yen-Vy Van Geoprobe				, <u> </u>	TOC Elevation (fe Surface Elevation Northing Easting Hole Depth Outer Hole Diam	eet) (feet) 15.0-feet 3.5-inch	
	Well	Sample Data					Soil Description	<u></u>	
Depth (feet, BGS	Details	Lithologici				Lithologic Column			
Ē		100	GP				0.0 to 0.4 feet: ASPHALT.		
1 2 3 4				TC4-S-2.0			<ul> <li>0.4 to 5.0 feet: BASE GRAVEL / SIL gray; 10% fines; 30% sand; 60% dry. (FILL)</li> <li>2.5 to 7.0 feet: SILTY SAND (SM); lig 65% sand; local fine subangular staining; dry.</li> </ul>	TY SAND (GW); dark brown and gravel; medium dense to dense; pht to medium brown; 35% fines; gravel; local iron oxidation	
6 7		<b>— 100</b>	GP	TC4-S-5.0 PID = 0.0 pp	m				
8 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1				TC4-S-7.0 PID = 0.0 pp	m		7.0 to 9.0 feet: SILT (ML); gray; 1009 moist to wet @ 7.0 feet, saturate 9.0 to 15.0 feet: POORLY GRADED	% fines; medium stiff; layered silt; d @ 7.5 to 9.0 feet. SAND (SP); gray; 5% fines; 95%	
10 11 12 13 14		_ 100	GP	ТС4-S-15.0 РІD = 1.3 рр	) m		sand, well sorted, medium graine moist to wet @ 15.0 feet.	ed; saturated @ 9.0 to 14.0 feet,	
NOTES:       Ecology Well ID #BIP 875. Boring completed as pre-packed 2" well.         PID = photoionization detector.       ppm = parts per million.         Vater level observed at time of drilling.       Vater level observed after well development.									
				Geologic Borehole Log/Well Construction					
--	---	---	-------------------------------	---	----------	----------------------	---	---	--
Mau	Maul Foster & Alongi, Inc.			Project I	Numb	per	Well Number Sheet		
Project Name Project Location Start/End Date Driller/Equipment Geologist/Engineer Sample Method		Truck City Site on Mount Vernon, WA e 7/17/2014 to 7/17/2014 nent Holt Services, Inc./Geoprobe 7822DT gineer Yen-Vy Van				, <u> </u>	TOC Elevation (feet) Surface Elevation (feet) Northing Easting Hole Depth 15.0-feet		
San		Geoprobe	; 	mala Data					
Depth (feet, BGS)	Details	Interval Percent Recovery	Collection Method <u>c</u>	ample Data lag gun Name (Type)	Blows/6"	Lithologic Column	Soll Descripti	on	
		20	GP				0.0 to 0.4 feet: ASPHALT.		
1		<b>2 20 100</b>	GP	ТС5-S-9.5 PID = 0.0 ppr	'n		<ul> <li>0.4 to 4.0 feet: SANDY GRAVEL (GI sand; 65% gravel, fine to coarse (FILL)</li> <li>4.0 to 5.0 feet: GRAVELLY SAND (S 60% sand, fine to coarse; 25% g</li> <li>5.0 to 6.5 feet: SILTY CLAY (CL); mi plasticity; soft; moist.</li> <li>6.5 to 13.0 feet: SILTY SAND (SM); sand; loose; moist to saturated (</li> </ul>	W); tan brown; 10% fines; 25% a, subangular; medium dense; dry. gravel; medium dense; moist. edium brown; 100% fines, low grayish brown; 35% fines; 65% @ 10.0 feet.	
14 14				TC5-S-13.0			13.0 to 14.0 feet: SANDY SILT (ML), slight sheen; saturated.	; gray; 75% fines; 25% sand;	
-ICBH4				TC5-S-15.0 PID = 1.8 ppr	m		14.0 to 15.0 feet: POORLY GRADEL fines; 95% sand, well sorted, me diesel-like fuel odor; moist to we	D SAND (SP); dark gray; 5% dium; medium dense; strong t.	
	ES: Ecology Well PID = photoio	ID #BIP 876. nization detec	Boring ctor.	completed as pre-pac	cked 2	" well. Fuel ir	npacted from approximately 10.0 to 15.0 fe	eet.	
	ppm = parts p Water level obs drilling.	er million. served at tir	ne of						

			_		Geologic Borehole Log/Well Construction					
Mau	I Foster &	Alongi,	Inc.	Project Ni 0714 0	umber 2 02	Well Number	Sheet			
Project Name Project Location Start/End Date Driller/Equipment Geologist/Engineer Sample Method		Truck City Site Mount Vernon, WA 7/17/2014 to 7/17/2014 Holt Services, Inc./Geoprobe 7822DT Yen-Vy Van			)T	TOC Elevation (feet) Surface Elevation (feet) Northing Easting Hole Depth Output Jole Diage				
San	Well	Geoprobe	<del>،</del> ب	ample Data			Soil Description			
Depth (feet, BGS) Percent Recovery				Name (Type)	Blows/6" Lithologic Column					
		100	GP			0.0 to 0.4 feet: ASPHALT.	(CIAA) block brown 400/ France			
1 2 3 4 5 6		- 100 7_	GP	ТС6-S-3.0 PID = 0.0 ppm		3.0 to 7.0 feet: SAND with GRAVEL 75% sand; 15% gravel; loose; m 3.0 to 7.0 feet: SILTY SANDY CLAY moderate plasticity; 25% sand; n oxidation staining; moist to wet (	(SW); black brown; 10% fines; oist. (CL); light brown; 75% fines, nedium stiff; abundant iron @ 7.0 feet.			
8 9		7		ТС6-S-7.0 PID = 1.3 ppm		7.0 to 9.0 feet: SILTY CLAY (CL); gra soft; saturated. 9.0 to 12.5 feet: SILTY SAND (SM); g medium dense: saturated	ay; 100% fines, low plasticity; 			
10 11 12		100	GP	TC6-S-12.5		12.5 to 13.5 feet: POORLY GRADED sand, well sorted, medium; medi	- - - - - - - - - - - - - - - - - - -			
14				TC6-S-13.5 TC6-S-15.0		13.5 to 15.0 feet: SILTY SAND (SM); medium dense; moist to wet.	; gray; 35% fines; 65% sand; 			
E_ 15	S: Ecology Well PID = photoio	ID #BIP 880. nization dete	Boring ctor.	נסקק בעוש באניים באיז איז איז איז איז איז איז איז איז איז	u popularia	]				
Ţ	ppm = parts p Water level obs drilling.	er million. Served at tir	ne of	Wate deve	er level observ elopment.	ved after well				

## APPENDIX C Sampling Analysis Plan

### SAMPLING AND ANALYSIS PLAN

#### TRUCK CITY SITE PROPERTY

Prepared for SKAGIT COUNTY MOUNT VERNON, WASHINGTON July 8, 2014 Project No. 0714.02.02

Prepared by Maul Foster & Alongi, Inc. 1329 N State Street, Suite 301, Bellingham WA 98225



#### SAMPLING AND ANALYSIS PLAN

TRUCK CITY SITE PROPERTY The material and data in this plan were prepared under the supervision and direction of the undersigned.

MAUL FOSTER & ALONGI, INC.

Yen-Vy Van, LHG Senior Hydrogeologist

Justin L. Clary, PE Principal Engineer

Jim Darling **Principal** Planner

R:\0714.02 Skagit County\Report\02\_2014.07.08 Truck City Site Final Work Plan\SAP\Truck City SAP.docx

#### CONTENTS

TABLE	es and illustrations	V
ACR	ONYMS AND ABBREVIATIONS	VI
1	INTRODUCTION 1.1 INVESTIGATION OBJECTIVES	1 1
2	ACCESS AND SITE PREPARATION 2.1 ACCESS 2.2 SITE PREPARATION AND COORDINATION	2 2 2
3	<ul> <li>SOIL AND GROUNDWATER ASSESSMENT</li> <li>3.1 BORINGS</li> <li>3.2 DOCUMENTATION</li> <li>3.3 BORING DECOMMISSIONING</li> <li>3.4 MONITORING WELLS</li> <li>3.5 GROUNDWATER ELEVATIONS</li> <li>3.6 SURVEYING</li> <li>3.7 EQUIPMENT CLEANING AND DECONTAMINATION</li> <li>3.8 MANAGEMENT OF INVESTIGATION-DERIVED WASTE</li> </ul>	2 3 4 4 5 5 5 6
4	SOIL SAMPLING 4.1 PROCEDURE 4.2 NOMENCLATURE 4.3 COMPOSITE SOIL SAMPLING	6 6 7 8
5	<ul> <li>GROUNDWATER SAMPLING</li> <li>5.1 RECONNAISSANCE GROUNDWATER SAMPLING</li> <li>5.2 MONITORING WELL GROUNDWATER SAMPLING</li> <li>5.3 NOMENCLATURE</li> </ul>	8 8 8 9
6	SOIL VAPOR SAMPLING 6.1 PROCEDURE 6.2 NOMENCLATURE	9 9 10
7	SUBSLAB SOIL VAPOR SAMPLING 7.1 PROCEDURE 7.2 NOMENCLATURE	10 10 11
8	INDOOR/BACKGROUND AIR SAMPLING 8.1 PROCEDURE 8.2 NOMENCLATURE	12 12 12
9	<ul> <li>ANALYTICAL METHODS</li> <li>9.1 CHEMICALS OF INTEREST</li> <li>9.2 LABORATORY TEST METHODS AND REPORTING LIMITS</li> <li>9.3 QA/QC SAMPLES GENERATED IN FIELD</li> <li>9.4 LABORATORY OPERATIONS</li> <li>9.5 SAMPLE CONTAINERS, PRESERVATION, AND HANDLING</li> <li>9.6 SAMPLE CUSTODY</li> <li>9.7 INSTRUMENTATION</li> <li>9.8 LABORATORY QA/QC SAMPLES</li> </ul>	13 13 13 14 15 15 15 16 18

 $\label{eq:resonance} R:\label{eq:resonance} 0714.02\ Skagit\ County\Report\02\_2014.07.08\ Truck\ City\ Site\ Final\ Work\ Plan\SAP\Truck\ City\ SAP.docx$ 

### CONTENTS (CONTINUED)

	9.9 9.10	FIELD QC DATA REDUCTION, VALIDATION, AND REPORTING	19 19
10	REPOR	RTING	22
LIMITAT	IONS		
REFERE	NCES		
TABLES			
FIGURE	S		
ATTACI	hment Borin	A IG LOG FORM	
ATTACI	HMENT	В	

FIELD SAMPLING DATA SHEET FORMS

FOLLOWING PLAN:

TABLES

- 1 SOIL SAMPLE HANDLING SUMMARY
- 2 GROUNDWATER SAMPLE HANDLING SUMMARY

FIGURES

- 1 SOIL GAS / EVACUATED SAMPLER SYSTEM
- 2 SCHEMATIC DIAGRAM OF A SUBSLAB SAMPLING PROBE
- 3 SUBSLAB SOIL GAS EVACUATED SAMPLER SYSTEM, GROUND LEVEL

#### ACRONYMS AND ABBREVIATIONS

bgs	below ground surface
BTEX	benzene, toluene, ethylbenzene, and total xylenes
COC	chain of custody
COI	chemical of interest
the County	Skagit County, Washington
DRO	diesel-range organic
Ecology	Washington State Department of Ecology
FSDS	field sampling data sheet
GRO	gasoline-range organic
IDW	investigation-derived waste
LCS	laboratory control sample
LDS	laboratory duplicate sample
MFA	Maul Foster & Alongi, Inc.
MS/MSD	matrix spike and matrix spike duplicate
MTCA	Model Toxics Control Act
PAH	polycyclic aromatic hydrocarbon
pН	potential hydrogen
PID	photoionization detector
the Property	Truck City parcel and four adjoining undeveloped parcels
	to the south in Mt. Vernon, Washington
PRT	post run tubing
QA	quality assurance
QC	quality control
SAP	sampling and analysis plan
TPH	total petroleum hydrocarbons
TPH-HCID	total petroleum hydrocarbon identification
Truck City parcel	Skagit County parcel P29546
USEPA	U.S. Environmental Protection Agency
VOC	volatile organic compound
WAC	Washington Administrative Code

## INTRODUCTION

Maul Foster & Alongi, Inc. (MFA) has prepared this sampling and analysis plan (SAP) consistent with the requirements of the Washington Administrative Code (WAC) 173-340-820 for Skagit County, Washington (the County) to guide the collection of samples during the focused site assessment investigation at parcels associated with the County's proposed county jail property in Mount Vernon, Washington (Figure 1 of MFA, 2014). The proposed county jail property comprises the following five parcels (collectively referred to in this plan as the Property): Skagit County parcel P29546 (Truck City parcel) and four adjoining undeveloped parcels to the south: P119262, P119263, P119265, and P119267 (see Figure 1 of MFA, 2014). The parcels are owned by various parties, and the County is in negotiation to acquire them. The Property is the focus of the site assessment. The Truck City parcel is commercially occupied by a gas station, truck stop and truck wash, restaurant, and small retail store. The remaining parcels on the Property are undeveloped rural grassland.

The procedures described in this SAP will be used for various phases and tasks of the project. The goal of the sampling is to obtain reliable data about physical, environmental, and chemical conditions at the Property in order to support the goals and objectives of the focused site assessment.

This SAP has been prepared consistent with the requirements of the Washington State Department of Ecology's (Ecology) Guidance on Sampling and Data Analysis Methods (Ecology, 1995), Guidance for Preparing Quality Assurance Project Plans for Environmental Studies (Ecology, 2004), Guidance for Evaluating Soil Vapor Intrusion in Washington State: Investigation and Remedial Action (Ecology, 2009), and the 1993 Model Toxics Control Act (MTCA) (WAC Chapter 173-340).

#### 1.1 Investigation Objectives

The primary objective of the SAP is to establish procedures for the collection of data of sufficient quality to evaluate the nature and extent of impacted soil and groundwater at the Property. The site assessment work plan references the relevant procedures and protocols from this SAP; identifies specific media to be sampled; and identifies the locations, frequency, and types of field or laboratory analyses that will be conducted. The SAP is meant to ensure that reliable data are obtained in support of the development of remedial actions at the Property if such actions are necessary for the protection of human health and the environment. It provides a consistent set of procedures that will be used throughout the various work phases identified in the work plan (MFA, 2014).

Once the nature and extent of soil and groundwater impacts have been determined, further investigation, which may involve the collection of other media (e.g., soil gas, indoor or ambient air, subslab vapor), may be proposed. The procedures for collection of samples of other media are summarized in this SAP, in case these are necessary in future scopes of work.

If a phase of work or an otherwise unforeseen change in methodology requires modification to this SAP, an addendum may be prepared that describes the specific revision(s), or the alternative

procedures used will be documented in the site assessment report. Procedures are provided that will be used to direct the investigation process so that the following conditions are met:

- Data collected are of high quality, representative, and verifiable.
- Use of resources is cost effective.
- Data can be used by the County and Ecology to support selection and implementation of remedial actions, if necessary.

This SAP describes methods that will be used for sampling environmental media, decontaminating equipment, and managing investigation-derived waste (IDW). It also includes procedures for collecting, analyzing, evaluating, and reporting useful data. This SAP includes quality assurance (QA) procedures for field activities, quality control (QC) procedures, and data validation.

## 2 ACCESS AND SITE PREPARATION

#### 2.1 Access

The County has obtained signed agreements from all the current businesses at the Property, granting access for MFA to conduct environmental investigation activities. MFA will coordinate activities directly with the County, Ecology, and retail tenants at the Property and will notify the County and the Ecology project manager before beginning work at the Property.

#### 2.2 Site Preparation and Coordination

Before subsurface field sampling programs begin at the Property, public and private utility-locating services will be used to check for underground utilities and pipelines near the proposed sample locations. MFA will coordinate fieldwork with the County to define the locations of possible on-site utilities and piping or other subsurface obstructions. Ecology will be notified a minimum of 48 hours before field activities begin.

## 3 SOIL AND GROUNDWATER ASSESSMENT

The proposed locations of soil and reconnaissance groundwater borings are shown on Figures 3 and 4 of the focused site assessment work plan (MFA, 2014). Subsurface soil and reconnaissance groundwater samples at the Property will be collected using a combination drilling rig capable of direct-push (i.e., Geoprobe<sup>TM</sup>) and hollow-stem auger drilling techniques. Selected borings (TC-1 through TC-6), which will be completed as established 2-inch-diameter monitoring wells, will be advanced using the direct-push drill method to enable continuous collection of soil cores to

approximately 15 feet below ground surface (bgs) for vertical assessment at areas of known soil and/or groundwater impacts and at locales hydraulically downgradient of potential sources of environmental concern. These borings will subsequently be overdrilled via hollow-stem augers and completed as monitoring wells. Remaining proposed borings at the Property and at off-site locales (which will not be completed as monitoring wells) will be advanced via direct-push drilling technique.

Field screening will include measuring soil headspace vapor using a photoionization detector (PID) or an organic vapor monitor and documenting visual and olfactory observations.

Soil and groundwater samples will be analyzed following the program outlined in the work plan table (MFA, 2014). If there is evidence of impacts in the field, the sample depths may be altered in order to collect samples in and/or beneath the impacted areas. Additional analyses may be recommended based on field observations.

#### 3.1 Borings

The borings will be advanced using a direct-push drill rig and a hollow-stem auger drill rig. Soil and groundwater samples will be collected using industry-standard sampling techniques. In the event that refusal is met before the desired boring depth is reached (i.e., significant debris, cobbles, glacial till, or bedrock are encountered), a different type of drilling technology may be considered.

Reconnaissance groundwater samples will be collected using a stainless steel (e.g., Geoprobe) water sampler at probe boring locations. The water sampler will be advanced to the desired depth. The casing around the water sampler will be pulled back, exposing the screen. If water does not flow into the screen within 15 minutes, the sampler will be removed and a temporary well will be installed. This will consist of placing 0.010-inch machine slot screen with polyvinyl chloride riser into the boring and allowing the boring to stay open overnight. This procedure will enable potential shallow groundwater to collect in the boring. If no water is observed in the boring, then the boring will be abandoned. Permanent screen and risers will be installed at borings over-drilled by hollow-stem auger drilling technique to be completed as monitoring wells.

If practicable at borings not completed as monitoring wells, at least one casing volume of water will be purged before sample collection. Groundwater will be purged using new polyethylene tubing or a stainless steel bailer, following procedures summarized in Section 5.1. If there is enough water, some will be used to measure water quality field parameters, including items such as potential hydrogen (pH), specific conductance, and temperature.

New, disposable tubing will be used at each location to collect water samples. Nondisposable equipment used for water sample collection will be decontaminated both before its use at the facility and after each sample is collected.

Samples will be labeled, preserved, and shipped to the analytical laboratory under standard chain-of-custody (COC) procedures.

#### 3.2 Documentation

A log of soil samples will be prepared by a geologist or hydrogeologist licensed by the State of Washington or a person working under the direct supervision of a geologist or hydrogeologist licensed by the State of Washington. Boring logs will include information such as the project name and location, the name of the drilling contractor, the drilling method, the sampling method, sample depths, blow counts (if applicable), a description of soil encountered, and screened intervals. Soils will be described using American Society for Testing and Materials designation D2488-00, Standard Practice for Description and Identification of Soils (Visual-Manual Procedures). The information will be recorded on the MFA boring log form shown in Attachment A or in field notes.

#### 3.3 Boring Decommissioning

After a boring is no longer needed, it will be decommissioned with bentonite chips or with bentonite grout in accordance with the WAC for Minimum Standards for Construction and Maintenance of Wells (WAC 173-160, 1998).

#### 3.4 Monitoring Wells

Six permanent monitoring wells are currently proposed in this plan. Monitoring wells will be constructed according to the Washington well construction standards (Chapter 173-160 WAC) and as described below:

- Monitoring wells will be constructed with 2-inch-diameter polyvinyl chloride or stainless steel riser pipe and screened sections. The well screens will consist of 0.010-inch machine slots. The monitoring wells may be constructed with prepacked well screen with 10 x 20 washed silica sand or by placing materials downhole, following the WAC regulation listed above.
- Additional filter pack may be placed around the prepacked screen (if used). The additional filter pack will consist of graded 10 x 20 washed silica sand and will extend a maximum of 1 foot below the bottom of the screen and 3 feet above the top of the screen. A weighted line will be used to monitor the level of the filter pack during installation. The filter pack may be surged during installation.
- Bentonite grout or hydrated chips (e.g., 0.75-inch minus) will be used to seal the annulus above the filter pack. Potable water will be used. A weighted line will be used to measure the top of the bentonite chips as they are poured into place.
- At least 24 hours after installation of a well, the well will be developed by surging, bailing, or pumping to remove sediment that may have accumulated during installation and to improve the hydraulic connection with the water-bearing zone.
- Water quality field parameters such as specific conductance, pH, temperature, and turbidity will be measured during well development as deemed appropriate. The wells will be developed until the turbidity measurements are 10 nephelometric turbidity units or less, or until there is no noticeable decrease in turbidity. To the extent practical, water

quality field parameters will be considered stable when the specific conductance is within 10 percent of the previous reading, pH is within 0.1 standard unit of the previous reading, and temperature is within 0.1 degree Celsius of the previous reading.

#### 3.5 Groundwater Elevations

Water level measurements to the nearest 0.01 foot will be taken, using an electronic water level indicator. If it is not known, the depth of the boring or the monitoring well will also be measured. The depth to water will be measured from the top of the casing (typically the polyvinyl chloride riser pipe) at the surveyed elevation point. This reference point will be marked so that future readings are taken from the same reference point. In addition, the well condition (if applicable), including the condition of the lock, monument integrity, and legibility of well labels, will be recorded for each location. Gauging equipment will be decontaminated between wells in accordance with the procedures outlined in Section 3.7.

#### 3.6 Surveying

The location of the borings, surface samples, and other features of interest will be surveyed using a global positioning unit (e.g., Trimble<sup>TM</sup>) capable of submeter accuracy. The installed monitoring wells will be surveyed by a licensed surveyor.

#### 3.7 Equipment Cleaning and Decontamination

#### 3.7.1 Drilling Equipment

The working area of the drill rig and downhole drilling equipment will be steam-cleaned or pressurewashed after arrival on the Property and after use in each boring or monitoring well. Decontamination fluids will be transferred to drums approved by the Washington State Department of Transportation, and will be managed according to the procedures outlined in Section 3.8.

#### 3.7.2 Sampling Equipment

Nondisposable sampling equipment and reusable materials that contact the soil or water will be decontaminated before and after each sample and sampling location. Decontamination will consist of the following:

- Tap-water rinse (may consist of an equivalent high-pressure or hot-water rinse). Visible soil to be removed by scrubbing.
- Nonphosphate detergent wash, consisting of a dilute mixture of Liqui-Nox<sup>®</sup> (or equivalent) and tap water.
- Distilled-water rinse.
- Methanol solution rinse (1:1 solution of methanol with distilled water).
- Distilled-water rinse.

Decontamination fluids will be transferred to drums for management.

#### 3.8 Management of Investigation-Derived Waste

IDW may include items such as soil cuttings, purged groundwater, decontamination fluids, sampling debris, and personal protective equipment. The IDW will be segregated into solids, liquids, and sampling debris (e.g., personal protective equipment, tubing, bailers). IDW will be stored in a designated area on the Property in drums approved by the Washington State Department of Transportation.

Drums will be labeled with their contents, the approximate volume of material, the date of collection, and the origin of the material. The drums will be sealed, secured, and transferred to a designated area on the Property, pending characterization.

Analytical data from the soil-sampling and groundwater-sampling activities at borings advanced for investigation of potential impacts from total petroleum hydrocarbons (TPH) and associated volatile organic compounds (VOCs), previously described, will be used to characterize the soil cuttings, drilling fluids, purge water, and decontamination fluids generated during the drilling and sampling at these selected borings.

IDW associated with petroleum fuel contamination, at concentrations above Ecology MTCA Method A cleanup levels, will follow procedures and analytical tests set forth in WAC 173-303-090 and WAC 17-303-100 in accordance with Ecology MTCA cleanup regulations. The IDW will be disposed of at a regulated landfill.

Soil samples will be collected for lithologic description, field screening, and chemical analyses, as described below. The sampling intervals, depths, and initial sample analysis schedule are specified in the work plan (MFA, 2014).

#### 4.1 Procedure

Samples will be prepared, handled, and documented as follows:

- Soil sampling equipment will be decontaminated before it is used at each sampling location (see Section 3.7).
- Samples will be obtained using new, uncontaminated gloves or decontaminated, stainless steel spoon, trowel, or knife.
- Soil will be field-screened by measuring soil vapor headspace and documenting visual and olfactory observations. If headspace measurements are collected, a representative

SOIL SAMPLING

amount of soil will be placed in a new, food-grade, zip-lock plastic bag. Samples will then be warmed and agitated before headspace analysis is conducted by carefully piercing the bag with the PID. Field-screen results will be documented in the field book or boring log.

- Soil that will be analyzed for VOCs will be transferred directly from freshly exposed soil into laboratory-supplied containers, using the appropriate U.S. Environmental Protection Agency (USEPA) 5035A sampling procedures. The samples will be placed in 40-milliliter vials. Depending on the soil type, 5 milligrams of soil will be added to the prepared vials preserved with sodium bisulfate monohydrate or methanol. A soil sample will also be collected in an unpreserved glass jar to be analyzed for total petroleum hydrocarbon identification (TPH-HCID). The work plan table presents potential source areas and chemicals of interest (COIs) (MFA, 2014).
- Large particles (i.e., larger than 0.25 inch) may be removed before the sample is placed in a laboratory-supplied container.
- Soil samples will be transferred directly from the sampling device into laboratorysupplied glass jars, using a new, uncontaminated-gloved hand or decontaminated, stainless steel spoon, trowel, or knife.
- Sample containers will be labeled, packed in iced shipping containers with COC documentation (see Section 9), and hand-delivered or shipped to the laboratory.
- Sampling information will be recorded in a field notebook, on a field sampling data sheet (FSDS), and on the COC form.
- Generally, duplicate soil samples should be collected at the frequency of one duplicate sample for every 20 samples collected.

#### 4.2 Nomenclature

Soil samples will be labeled with a prefix to describe the location identification number, an "S" to indicate a soil sample matrix, and the sample depth in feet. The depth interval should be specified as the middle of the sampling interval. For example, a soil sample collected from a boring at location 1 and at 15 feet bgs will have the sample nomenclature of B1-S-15.0.

Duplicate soil samples will replace the location number with "DUP," and the sample will have the same sample time as the primary sample. A duplicate sample of the abovementioned sample would appear as BDUP-S-15.0. To avoid confusion, duplicate samples should not be collected from multiple locations at the same depth on the same day and time.

Relevant sample information will be documented on the exploratory boring log (see Attachment A) or an FSDS (see Attachment B).

#### 4.3 Composite Soil Sampling

Should soil stockpiles be created on site in the future, characterization of each stockpile will be completed through collection of representative composite soil samples. A clean shovel or hand auger will be used to dig up to 1.5 feet into the pile from at least three subsample locations. Each of the subsamples will be collected at least 0.5 foot bgs by hand with clean, disposable gloves. Subsample locations will be selected to obtain representative material, based on visual inspection and best professional judgment. To the extent possible, subsamples should consist of fine-particle-sized material, with larger rocks and debris removed. Subsamples will be combined and homogenized. The discrete samples will be placed into laboratory-supplied containers and submitted to the laboratory and held. The composite sample of the material source will be transferred to a laboratory-supplied glass container(s).

## 5 GROUNDWATER SAMPLING

During drilling, reconnaissance groundwater samples may be collected for chemical analyses, as described below. If monitoring wells are installed, groundwater samples may be collected following the procedure outlined below.

#### 5.1 Reconnaissance Groundwater Sampling

Reconnaissance groundwater samples will be collected using conventional methods associated with the drilling method (e.g., inertia or peristaltic pump). Before groundwater sampling, the boring will be purged to minimize solids and to ensure that a representative sample is collected.

Groundwater will be transferred directly into laboratory-supplied containers specific to the analysis required, as outlined in Section 9. If there is enough water, water quality field parameters (e.g., temperature, specific conductance, pH, turbidity) will be measured.

#### 5.2 Monitoring Well Groundwater Sampling

A peristaltic pump will collect groundwater samples, using standard low-flow sampling techniques, at installed monitoring wells. If possible, groundwater samples should be collected from the middle of the screened interval or, if the water level is below the top of the screen, from the middle of the water column. New, disposable tubing will be used at each monitoring location.

Before collection of groundwater samples, the water level will be measured and the well will be purged. If a peristaltic pump is used, the well should be purged at a USEPA-approved, low flow rate (e.g., 0.1 to 0.5 liter per minute). A minimum of one well volume will be purged before sample collection or until selected water quality field parameters (e.g., temperature, specific conductance, pH, turbidity) have stabilized. If the well goes dry during purging, a sample can be collected once the well recharges enough water. During purging, the flow rates, water levels, and water quality

parameters will be recorded on an appropriate field form or in the field notes. Groundwater will be transferred directly into laboratory-supplied containers specific to the analysis required.

#### 5.3 Nomenclature

Groundwater samples will be labeled with a prefix to describe the sampling location identification number, a "W" to indicate a water sample matrix, and the midpoint of the screened or open area sample depth in feet. For example, a reconnaissance groundwater sample collected from a boring at location 4 and with a screen from 30 feet to 35 feet bgs will have the sample nomenclature of B4-W-32.5.

Duplicate reconnaissance groundwater samples will replace the location number with "DUP," and the sample will have the same sample time as the primary sample. To avoid confusion, avoid collecting more than one a duplicate sample from the same depth at the same date and time. A duplicate sample of the abovementioned sample would appear as BDUP-W-32.5.

Relevant sample information will be documented on the exploratory boring log (see Attachment A) or an FSDS (see Attachment B); documentation may include items such as the screened interval or open space, equipment used, water quality field parameters, and the amount of water purged before sampling. The screened interval or open boring will be recorded on the boring log.

## 5 SOIL VAPOR SAMPLING

If soil vapor sampling is performed, it should be conducted as described below.

#### 6.1 Procedure

Soil borings for soil vapor sample collection will be advanced using direct-push technology (e.g., Geoprobe). A "post run tubing" (PRT) system will be used to reduce problems that may occur with sampling directly through the steel rods. The PRT system uses an adapter and tubing to isolate the soil gas sample from the drill rods, thereby reducing possible leaks of ambient air from the rod joints into the sample. A PRT point holder and expendable point are attached to the leading end of a sampling screen. The drill rods will be advanced to the desired sample depth. The PRT adapter attached to the sample tubing is threaded into the reverse thread fitting in the top of the point holder. The rods are then retracted to release the expendable point, exposing the screen and creating an opening where soil gas can enter the PRT system.

The upper end of the tubing will be connected to the purging/sampling system (Figure 1). A flow controller may be attached to the sample setup to regulate the flow of soil vapor into the sample container. The line will be purged for one minute or a period of time sufficient to achieve a purge volume that equals at least three volumes of the PRT system and sampling train, and then the sample will be collected using a laboratory-supplied stainless steel canister (e.g., Summa canister), or other appropriate container.

If a leak check is deemed necessary, helium will be contained around the sampling apparatus and sampling location, using a small, tent-like structure or shroud, to serve as a leak-check compound to verify the integrity of the sampling system before the sample is collected. See the attached Figure 1 for sample system configuration.

#### 6.2 Nomenclature

Soil vapor samples will be labeled with a prefix to describe the sampling location identification number, "SV" to indicate the soil vapor sample matrix, and the midpoint of the screened or open area sample depth. For example, a soil vapor sample collected from a boring at location 4 and with an open screen from 5 feet to 7 feet bgs will have the sample number B4-SV-6.0.

Duplicate soil vapor samples will replace the location number with "DUP," and the sample will have the same sample time as the primary sample. A duplicate sample of the abovementioned sample would appear as BDUP-SV-6.0.

Relevant sample information will be documented on the exploratory boring log (see Attachment A) or an FSDS (see Attachment B); documentation should include the screened interval or open space, equipment used, and helium meter readings.

## 7 SUBSLAB SOIL VAPOR SAMPLING

If subslab soil vapor sampling is performed, it should be conducted as described below.

#### 7.1 Procedure

Subslab soil vapor sampling may be performed to evaluate vapors that collect under a building's foundation. The following procedures may be followed to install subslab soil vapor sampling points.

Subslab utilities, such as water, sewer, and electrical, should be located and marked on the slab before drilling or cutting. If it is determined that a building has a moisture barrier and/or a tension slab, special care should be taken when drilling or cutting through the concrete slab. Subslab samples will not be collected if the slab is in contact with, or potentially could come into contact with, groundwater.

After removal of the floor covering, a 1.0- to 1.25-inch-diameter hole will be drilled through the concrete slab (see Figure 2). A hammer drill can be used to drill the holes. A vacuum should be used to remove drill cuttings from the borehole.

Vapor probes will be constructed of 1/8-inch- or 1/4-inch-diameter, stainless steel tubing (e.g., Swagelok®) with a permeable probe tip. A Teflon<sup>TM</sup> sealing disk should be placed, as needed, between the probe tip and the blank riser pipe to prevent the downward migration of materials into the sand pack. Dry, granular bentonite should be used to fill the borehole annular space to above the

R:\0714.02 Skagit County\Report\02\_2014.07.08 Truck City Site Final Work Plan\SAP\Truck City SAP.docx

base of the concrete foundation. Hydrated bentonite should then be placed above the dry granular bentonite. The bentonite for this portion of probe construction should be hydrated to ensure proper sealing. Care should be used in placement of the bentonite to prevent post-emplacement expansion, which might compromise both the probe and the cement seal. The remainder of the hole should be filled with bentonite grout if the probe installation is temporary, or with cement if the installation is permanent. Before the introduction of the bentonite grout or cement, the existing concrete surfaces in the borehole should be cleaned with a damp towel to increase the likelihood of a good seal. The vapor probe tip should be surrounded by a sand filter pack to ensure proper airflow to the probe tip.

Water used in the construction of the probe should be deionized, the bentonite grout should be contaminant-free and quick drying, and the metal probe components should be stainless steel and should be cleaned to remove manufacturer-applied cutting oils.

Before sampling, at least two hours should elapse following installation of a probe to allow the construction materials to cure and the subsurface to equilibrate (USEPA, 2006).

The upper end of the tubing will be connected to the purging/sampling system (Figure 3). A flow controller will be attached to the sample setup to regulate the flow of soil vapor into the sample container. Before sampling, the line will be purged for one minute or a period of time sufficient to achieve a purge volume that equals at least three volumes. Relevant sampling information, such as the sampling start and stop times, the initial and final canister vacuum readings, and weather conditions, should be recorded. If a stainless steel canister is used, the sample should be rejected or the data qualified if the initial canister pressure is not at least 28 inches of mercury or if the final canister pressure is greater than 5 inches of mercury.

Upon completion of the sampling events, the foundation probes will be decommissioned by overdrilling the probe tip, probe tubing, bentonite, and grout. The borehole will be filled with grout and concrete patch material.

#### 7.2 Nomenclature

Subslab soil vapor samples will be labeled with a prefix to describe the sampling location identification number, "BV" to indicate the subslab soil vapor sample matrix, and the midpoint of the screened or open area sample depth. For example, a subslab soil vapor sample collected from location 4 and with an open screen from 5 feet to 7 feet bgs will have the sample number L04-BV-6.0.

Duplicate soil vapor samples will replace the location number with "DUP," and the sample will have the same sample time as the primary sample. A duplicate sample of the abovementioned sample would appear as LDUP-SV.

Samples will be documented in field notes and will include the equipment used and the screened interval or open space.

If indoor or outdoor air sampling is performed, it should be conducted as described below.

#### 8.1 Procedure

Indoor air samples should be collected from each level, if applicable, of each building included in the assessment. Indoor air samples will be collected approximately 3 to 5 feet above the floor. If outdoor ambient air samples are collected, they should be taken from locations upwind of the building at approximately the same time as the indoor air sample collection.

A flow controller should be attached to the sample setup to regulate the flow of air into the sample container. If a 6-liter, stainless steel canister is used, the valve will be opened to collect the sample over a 24-hour period. Field data will be recorded, including items such as a description of the sample location, sampling start and stop times, the initial and final canister vacuum readings, and weather conditions. The sample should be rejected or the data qualified if the initial canister pressure is not at least -28 inch of mercury or if the final canister pressure is greater than -5 inch of mercury.

#### 8.2 Nomenclature

Indoor air samples will be labeled with a prefix to describe the sampling location identification number prefixed by L, "IA" to indicate the indoor air sample matrix, and a height above ground, in feet. Background air samples will be labeled with a prefix to describe the sampling location identification number prefixed by L, "BA" to indicate the background air sample matrix, and a height above ground, in feet. For example, an indoor air sample collected at location 4, 3 feet off the ground, will have the sample number L04-IA-4.0.

Duplicate air samples will replace the location number with "DUP," and the sample will have the same sample time as the primary sample. A duplicate sample of the abovementioned sample would appear as LDUP-IA-4.0.

Relevant sample information may be documented on an FSDS (see Attachment B) and should include items such as a description of the sample location, the screened interval or open space, and equipment used. Record field data before and after the sampling, including items such as the sampling start and stop times, the initial and final canister vacuum readings, temperature, relative humidity, and observations of conditions that may influence sampling results (e.g., presence or use of products that may contain COIs; open windows/doors; ventilation systems).

#### 9.1 Chemicals of Interest

Gasoline-range and diesel-range TPH and petroleum-fuel-associated VOCs, including benzene, toluene, ethylbenzene, and total xylenes (BTEX), were detected in subsurface soil and groundwater at the Truck City parcel, at concentrations above Ecology MTCA Method A cleanup levels. The following chemicals may be associated with known or suspected former site activities and have been identified as COIs: TPH and associated petroleum hydrocarbons, VOCs, metals, and polycyclic aromatic hydrocarbons (PAHs). COIs will be analyzed as outlined in the work plan table (MFA, 2014).

#### 9.2 Laboratory Test Methods and Reporting Limits

#### 9.2.1 Soil and Groundwater

In accordance with the QA/QC requirements set forth in this SAP, an accredited laboratory may perform the following analyses. Laboratory methods are summarized in the work plan table (MFA, 2014).

- Diesel-range TPH and residual-range TPH by Northwest Method NWTPH-Dx Extended
- Gasoline-range TPH by Northwest Method NWTPH-Gx
- VOCs associated with petroleum fuel, specifically BTEX, by USEPA 8021B
- VOCs associated with former automobile services by USEPA 8260C
- TPH-HCID by Ecology Method NWTPH-HCID

Selected groundwater samples from areas with confirmed historical petroleum fuel releases, including areas in the vicinity of borings TC-1, TC-3, and TC-5, will be analyzed for COIs outlined in Ecology MTCA Cleanup Table 830-1, Required Testing for Petroleum Releases:

- Table 830-1, Required Testing for Petroleum Releases, Gasoline Range Organics (GRO) suite, which includes gasoline-range TPH, BTEX, hexane, dibromoethane, 1-2 ethylene dibromide, dichloroethane, 1-2 ethylene dichloride, methyl tertiary-butyl ether, total lead, naphthalenes, and volatile petroleum hydrocarbons
- Table 830-1, Required Testing for Petroleum Releases, Diesel Range Organics (DRO) suite, which includes diesel- and residual-oil-range TPH, BTEX, carcinogenic PAHs, naphthalenes, and extractable petroleum hydrocarbons

• RCRA (Resource Conservation and Recovery Act) metals (including arsenic, selenium, barium, cadmium, chromium, silver, mercury, and lead) by USEPA 6020 series

To evaluate the potential biodegradation process, selected groundwater samples from TC-1 and TC-3 will also be analyzed for the following geochemical parameters to prescreen for the presence of electron acceptors:

- Nitrate by USEPA 353.2
- Manganese by USEPA 6020A
- Ferrous iron by USEPA ApplEnvMic7-87-1536
- Sulfate by ASTM D516-02
- Methane by RSK 175

#### 9.2.2 Soil Vapor/Subslab Vapor Sampling

In the event that soil vapor/subslab vapor sampling is recommended at the Property, chemical analyses will be determined based on chemical impacts observed in soil and/or groundwater. For example, samples may be analyzed for selected compounds by Modified USEPA Method TO-15 selective ion monitoring or USEPA Method TO-17. An accredited laboratory will provide a 1-liter, stainless steel canister (e.g., Summa canister) or sorbent tube for each sample to be analyzed for VOCs.

#### 9.2.3 Indoor/Background Air Sampling

In the event that indoor air/background air sampling is recommended at the Property, chemical analyses will be determined based on chemical impacts observed in soil, groundwater, and/or vapor sampling. For example, samples may be analyzed for selected VOC compounds by Modified USEPA Method TO-15 selective ion monitoring to achieve low reporting limits. An accredited laboratory may provide a 6-liter, stainless steel canister (e.g., Summa canister) or sorbent tube for each sample.

#### 9.3 QA/QC Samples Generated in Field

To ensure that field samples and quantitative field measurements are representative of the media collected and conditions being measured, sample collection and measurement methods will follow procedures documented in Section 4.1. QC samples collected in the field include field equipment rinsate blanks, trip blanks, and field duplicates. Field QC samples will be identified on the FSDSs. Field and trip blank results may indicate possible contamination introduced by field or laboratory procedures; field duplicates indicate precision in both field and laboratory procedures.

#### 9.4 Laboratory Operations

In the laboratory, QC samples may include matrix spike and matrix spike duplicate (MS/MSD) samples, laboratory control samples (LCSs), surrogate spike samples, and method blanks, as well as other QC samples and procedures as required by the individual methods.

#### 9.5 Sample Containers, Preservation, and Handling

#### 9.5.1 Preservation

Water samples will be collected in laboratory-supplied containers, as generally specified; see the summary in Table 2.

Soil samples for halogenated VOC and VOC analyses will be collected in 40-milliliter glass vials, using the USEPA 5035A method. Other soil samples will be collected in glass jars. The soil and groundwater samples will be stored in iced coolers at approximately 4 degrees Celsius. Sample containers will be supplied by the laboratory.

#### 9.5.2 Sample Packaging and Shipping

Soil and groundwater samples will be stored in iced shipping containers or a refrigerator designated for samples, and then transported to the analytical laboratory in containers. Air samples will be transported to the analytical laboratory in shipping containers or boxes.

#### 9.6 Sample Custody

Sample custody will be tracked from point of origin through analysis and disposal, using a COC form, which will be filled out with the appropriate sample and analytical information after samples are collected.

The following items will be recorded on the COC form:

- Project name
- Project number
- MFA project manager
- Sampler name(s)
- Sample number, date and time collected, media, number of bottles submitted
- Requested analyses for each sample
- Type of data package required
- Turnaround requirements

- Signature, printed name, and organization name of persons having custody of samples; date and time of transfer
- Additional instructions or considerations that would affect analysis (nonaqueous layers, archiving, etc.)

Persons in possession of the samples will be required to sign and date the COC form whenever samples are transferred between individuals or organizations. The COC will be included in the shipping containers. The laboratory will implement its in-house custody procedures, which begin when sample custody is transferred to laboratory personnel.

If samples are shipped via air or ground transportation (by a third party), the following custody procedures will be followed. The COC will be signed and custody will be relinquished to the carrier. The signed COC(s) will be packed in shipping containers with the samples, and a custody seal will be placed on the container. The shipping documentation will be used by the carrier to document custody of the package while it is in transit to the laboratory.

At the analytical laboratory, a designated sample custodian will accept custody of the samples and will verify that the COC form matches the samples received. The shipping container or set of containers is given a laboratory identification number, and each sample is assigned a unique sequential identification number.

#### 9.7 Instrumentation

#### 9.7.1 Field Instrumentation

Field instruments will be used during the investigations. The following field equipment may require calibration before use and periodically during sampling activities:

- pH meter
- Conductivity meter
- Dissolved-oxygen meter
- Oxygen/reduction potential meter
- Turbidity meter
- Thermometer
- PID
- Electronic water-level probe

Field-instrument calibration and preventive maintenance will follow the manufacturers' guidelines, and deviations from the established guidelines will be documented.

#### 9.7.1.1 Field Calibration

Generally, field instruments should be calibrated daily before work begins. Field personnel may decide to calibrate more than once a day if inconsistent or unusual readings occur, or if conditions

warrant more frequent calibration. Calibration activities should be recorded in logbooks or field notebooks. To ensure that field instruments are properly calibrated and remain operable, the following procedures will be used, at a minimum:

- Operation, maintenance, and calibration will be performed in accordance with the instrument manufacturers' specifications.
- Standards used to calibrate field instruments will meet the minimum requirements for source and purity recommended in the equipment operation manual. Standards will be checked for expiration dates that may be printed on the bottle. Standards that have expired should not be used.
- Acceptable criteria for calibration will be based on the limits set in the operations manual.
- Users of the equipment should be trained in the proper calibration and operation of the instrument.
- Operation and maintenance manuals for each field instrument should be available to persons using the equipment.
- Field instruments will be inspected before they are taken to the site.
- Field instruments will be calibrated at the start of each workday. Meters will be recalibrated, as necessary, during the work period.
- Calibration procedures (including items such as time, standards used, and calibration results) should be recorded in a field notebook. The information should be available if problems are encountered.

#### 9.7.1.2 Preventive Maintenance

Preventive maintenance of field instruments and equipment will follow the operations manuals. A schedule of preventive-maintenance activities should be followed to minimize downtime and ensure the accuracy of measurement systems. Maintenance will be documented in the field notebook.

#### 9.7.2 Laboratory Instrumentation

Specific laboratory instrument calibration procedures, frequency of calibration, and preparation of calibration standards will be according to the method requirements as developed by the USEPA, following procedures presented in SW-846 (USEPA, 1986).

#### 9.7.2.1 Laboratory Calibration and Preventive Maintenance

The laboratory calibration ranges specified in SW-846 (USEPA, 1986) will be followed.

Preventive maintenance of laboratory equipment will be the responsibility of the laboratory personnel and analysts. This maintenance includes routine care and cleaning of instruments and

inspection and monitoring of carrier gases, solvents, and glassware used in analyses. The preventivemaintenance approach for specific equipment should follow the manufacturers' specifications, good laboratory practices, and industry standard techniques.

Precision and accuracy data will be examined for trends and excursions beyond control limits to determine evidence of instrument malfunction. Maintenance should be performed when an instrument begins to change, as indicated by the degradation of peak resolution, shift in calibration curves, decrease in sensitivity, or failure to meet any of the QC criteria.

#### 9.8 Laboratory QA/QC Samples

The laboratory QC samples will be used to assess the accuracy and precision of the laboratory analysis. Each category of laboratory QA/QC will be performed by the laboratory as required by method-specific guidelines. The acceptance criteria presented in the guidelines will be adhered to, and samples that do not meet the criteria will be reanalyzed or qualified, as appropriate.

#### 9.8.1 Calibration Verification

Instruments will initially be calibrated at the start of the project or sample run, as required, and when any ongoing calibration does not meet control criteria. The number of points used in the initial calibration is defined in the analytical method. Calibration will be continued as specified in the analytical method to track instrument performance. If a continuing calibration does not meet control limits, analysis of project samples will be suspended until the source of the control failure is either eliminated or reduced to within control specifications.

#### 9.8.2 Matrix Spike/Matrix Spike Duplicate

MS samples are analyzed to assess the matrix effects on the accuracy of analytical measurements. MS/MSD samples will be prepared by spiking investigative samples with known amounts of analytes before extraction and preparation and analysis. The recoveries for the MS/MSD samples will be used to assess the accuracy and precision in the analytical method by measuring how well the analytical method recovers the target compounds in the investigative matrices. For each matrix type, at least one set of MS/MSD samples will be analyzed for each batch of samples of 20 (or fewer) samples received.

#### 9.8.3 Method Blanks

Method blanks are prepared using analyte-free (reagent) water and are processed with the same methodology (e.g., extraction, digestion) as the associated investigative samples. Method blanks are used to document contamination resulting in the laboratory from the analytical process. A method blank shall be prepared and analyzed in every analytical batch. The method blank results are used to verify that reagents and preparation do not impart unacceptable bias to the investigative sample results. The presence of analytes in the method blank sample will be evaluated against method-specific thresholds. If analytes are present in the method blank above the method-specific threshold, corrective action will be taken to eliminate the source of contamination before proceeding with

analysis. Investigative samples of an analytical batch associated with method blank results outside acceptance limits will be appropriately qualified by the data validation contractor.

#### 9.8.4 Laboratory Control Samples

LCSs are prepared by spiking laboratory-certified, reagent-grade water with the analytes of interest or a certified reference material that has been prepared and analyzed. The result for percent recovery of the LCS is a data quality indicator of the accuracy of the analytical method and laboratory performance.

#### 9.8.5 Laboratory Duplicate Samples

Laboratory duplicate samples (LDSs) are prepared by the laboratory by splitting an investigative sample into two separate aliquots and performing separate sample preparation and analysis on each aliquot. The results for relative percent difference of the primary investigative sample and the respective LDSs are used to measure precision in the analytical method and laboratory performance. For nonaqueous matrices, sample heterogeneity may affect the measured precision for the LDSs.

#### 9.9 Field QC

The following samples will be prepared by the sampling personnel in the field and submitted to the laboratory:

- Equipment Rinsate Blanks—To ensure that decontamination procedures are sufficient, an equipment rinsate blank will be collected when nondedicated, nondisposable equipment is used. At least one equipment rinsate blank will be collected for every 20 samples collected. If more than 20 samples are collected with the same equipment, or if high concentrations of contaminants are encountered, additional equipment rinsate blanks may be collected. Equipment rinsate blanks will be collected by passing laboratory deionized/distilled water through or over nondisposable sampling equipment.
- **Trip Blanks**—A trip blank monitors the potential for sample contamination during sample collection and transport. A trip blank consists of reagent-grade water in a new sample container, which is prepared at the same time as the sample containers. The trip blank will accompany the samples throughout collection, shipment, and storage. At least one trip blank should be included with each cooler in which samples for VOC analyses are stored.
- Field Duplicates—Field duplicates are collected to measure sampling and laboratory precision. At least one duplicate sample will be collected for every 20 samples.

#### 9.10 Data Reduction, Validation, and Reporting

The analytical laboratory will submit analytical data packages that include laboratory QA/QC results to permit independent and conclusive determination of data quality. MFA will determine data

quality, using the data evaluation procedures described in this section. The results of the MFA evaluation will be used to determine if the project data quality objectives are met.

#### 9.10.1 Field Data Reduction

Daily internal QC checks will be performed for field activities. Checks will consist of reviewing field notes and field activity memoranda to confirm that the specified measurements, calibrations, and procedures are being followed. The need for corrective action will be assessed on an ongoing basis, in consultation with the project manager.

#### 9.10.2 Laboratory Evaluation

Initial data reduction, evaluation, and reporting at the analytical laboratory will be carried out as described in USEPA SW-846 manuals for analyses (USEPA, 1986), as appropriate. Additional laboratory data qualifiers may be defined and reported to further explain the laboratory's QC concerns about a particular sample result. Additional data qualifiers will be defined in the laboratory's case narrative reports.

#### 9.10.3 Data Deliverables

Laboratory data deliverables are listed below. Electronic deliverables will contain the same data that are presented in the hard-copy report.

- Transmittal cover letter
- Case narrative
- Analytical results
- COC
- Surrogate recoveries
- Method blank results
- MS/MSD results
- Laboratory duplicate results

#### 9.10.4 MFA Evaluation

#### 9.10.4.1 Data QA/QC Review

MFA will evaluate the laboratory data for precision, completeness, accuracy, and compliance with the analytical method. MFA will review data according to applicable sections of USEPA organics and inorganics procedures (USEPA, 2008, 2010), as well as appropriate laboratory method-specific guidelines (USEPA, 1986).

Data qualifiers, as defined by the USEPA, are used to classify sample data according to their conformance to QC requirements. Common qualifiers are listed below:

- J—Estimate, qualitatively correct but quantitatively suspect.
- R—Reject, data not suitable for any purpose.
- U—Not detected at a specified reporting limit.

Poor surrogate recovery, blank contamination, or calibration problems, among other things, can require qualification of the sample data. When sample data are qualified, the reasons for the qualification should be stated in the data evaluation report.

QC criteria not defined in the guidelines for evaluating analytical data are adopted, where appropriate, from the analytical method.

The following information will be reviewed during data evaluation, as applicable:

- Sampling locations and blind sample numbers
- Sampling dates
- Requested analysis
- COC documentation
- Sample preservation
- Holding times
- Method blanks
- Surrogate recoveries
- MS/MSD results
- Laboratory duplicates (if analyzed)
- Field duplicates
- Field blanks
- LCSs
- Method reporting limits above requested levels
- Additional comments or difficulties reported by the laboratory
- Overall assessment

The results of the data evaluation review will be summarized for each data package. Data qualifiers will be assigned to sample results on the basis of USEPA guidelines, as applicable.

#### 9.10.4.2 Data Management and Reduction

MFA uses a database (i.e., EQuIS<sup>TM</sup>) to manage laboratory data. The laboratory will provide the analytical results in electronic, EQuIS-compatible format. Following data evaluation, data qualifiers will be entered into the database.

Data may be reduced to summarize particular data sets and to aid interpretation of the results. Statistical analyses may also be applied to results. Data-reduction QC checks will be performed on hand-entered data, calculations, and data graphically displayed. Data may be further reduced and managed using one or more of the following computer software applications:

- Microsoft Excel (spreadsheet)
- EQuIS (database)
- Microsoft Access (database)
- AutoCad and/or Arc GIS (graphics)
- USEPA ProUCL (statistical software)

10 REPORTING

After the data are received, MFA will generate a data report, which will summarize and screen the data against the applicable criteria.

The services undertaken in completing this plan were performed consistent with generally accepted professional consulting principles and practices. No other warranty, express or implied, is made. These services were performed consistent with our agreement with our client. This plan is solely for the use and information of our client unless otherwise noted. Any reliance on this plan by a third party is at such party's sole risk.

Opinions and recommendations contained in this plan apply to conditions existing when services were performed and are intended only for the client, purposes, locations, time frames, and project parameters indicated. We are not responsible for the impacts of any changes in environmental standards, practices, or regulations subsequent to performance of services. We do not warrant the accuracy of information supplied by others, or the use of segregated portions of this plan.

Ecology. 1995. Guidance on sampling and data analysis methods. Publication No. 94-49. Washington State Department of Ecology Toxics Cleanup Program. January.

Ecology. 2004. Guidance for preparing quality assurance project plans for environmental studies. Publication No. 04-03-030. Washington State Department of Ecology. July.

Ecology. 2009. Guidance for evaluating soil vapor intrusion in Washington State: investigation and remedial action. Publication No. 09-09-047. Washington State Department of Ecology Toxics Cleanup Program. October.

MFA. 2014. DRAFT Focused site assessment work plan, Truck City site property. Maul Foster & Alongi, Inc., Bellingham, Washington. July.

USEPA. 1986. Test methods for evaluating solid waste: physical/chemical methods. EPA-530/SW-846. U.S. Environmental Protection Agency, Office of Solid Waste and Emergency Response. September (revision 6, February 2007).

USEPA. 2006. Assessment of vapor intrusion in homes near the Raymark Superfund site using basement and sub-slab air samples. Document No. EPA/600/R-05/147. U.S. Environmental Protection Agency Office of Research and Development. March.

USEPA. 2008. USEPA contract laboratory program, national functional guidelines for organics data review. EPA 540/R-08/01. U.S. Environmental Protection Agency, Office of Emergency and Remedial Response. June.

USEPA. 2010. USEPA contract laboratory program national functional guidelines for inorganic superfund data review. EPA 540/R-10/011. U.S. Environmental Protection Agency, Office of Superfund Remediation and Technology Innovation. January.

## TABLES



#### Table 1 Soil Sample Handling Summary Truck City Site Property Mount Vernon, Washington

Analyte	Method	Suggested Volume	Container	Number of Containers	Preservative	Storage Temperature	Holding Time from Collection
Total Petroleum Hydrocarbons- Hydrocarbon Identification	NWTPH-HCID	4 ounces	Glass Jar	1 none		4 degrees C	14 days
Total Petroleum Hydrocarbons—Diesel and Residual Oil	NWTPH-Dx	4 ounces	Glass Jar	1	none	4 degrees C	14 days
Total Petroleum Hydrocarbons—Gasoline	NWTPH-Gx	5035 Sample Kit	VOA/Glass Jar	1 5035 Sample Kit 5035 Sample Kit		4 degrees C	14 days
Total Metals	USEPA 6010	4 ounces	Glass Jar	1	none	4 degrees C	six months
Mercury	USEPA SW7471	4 ounces	Glass Jar	1	none	4 degrees C	28 days
PAHs	USEPA 8270 SIM	4 ounces	Glass Jar	1	none	4 degrees C	14 days
PCBs	USEPA 8082	4 ounces	Glass Jar	1	none	4 degrees C	365 days
VOCs	USEPA 8260B	5035 Sample Kit	VOA/Glass Jar	1 5035 Sample Kit	5035 Sample Kit	4 degrees C	14 days
1,2-dibromoethane	USEPA 8260B SIM	5035 Sample Kit	VOA/Glass Jar	1 5035 Sample Kit	5035 Sample Kit	4 degrees C	14 days
SVOCs	USEPA 8270	4 ounces	Glass Jar	1	none	4 degrees C	14 days
VPH	NWTPH-VPH	5035 Sample Kit	VOA/Glass Jar	1 5035 Sample Kit	5035 Sample Kit	4 degrees C	14 days
EPH	NWTPH-EPH	4 ounces	Glass Jar	1	none	4 degrees C	14 days

NOTES:

5035 Sample Kit consists of two prepared 40-milliliter VOAs with 5 milliliters of sodium bisulfate, two prepared 40-milliliter VOAs with 5 milliliters of methanol; OR two prepared, capped soil plungers; and one 2-ounce jar for moisture content determination.

Total metals are arsenic, chromium (total), silver, mercury, barium, selenium, lead, and cadmium.

C = Celsius.

EPH = extractable petroleum hydrocarbons.

NWTPH = Northwest Total Petroleum Hydrocarbons.

PAH = polycyclic aromatic hydrocarbon.

PCB = polychlorinated biphenyl.

SIM = selective ion monitoring.

SVOC = semivolatile organic compound.

SW = solid waste.

USEPA = U.S. Environmental Protection Agency.

VOA = volatile organic analysis vial.

VOC = volatile organic compound.

VPH = volatile petroleum hydrocarbons.

# Table 2Groundwater Sample Handling SummaryTruck City Site PropertyMount Vernon, Washington

Analyte	Method	Suggested Volume	Container	Number of Containers	Preservative	Storage Temperature	Holding Time from Collection
Total Petroleum Hydrocarbons- Hydrocarbon Identification	NWTPH-HCID	4 ounces	Glass Jar	1	none	4 degrees C	14 days
Gasoline-range organics	NWTPH-Gx	40 milliliter	VOA	3	HCL pH < 2	4 degrees C	14 days
Diesel- and residual-range organics	NWTPH-Dx	125 milliliter	Amber Glass	1	HCL pH < 2	4 degrees C	14 days
Total and dissolved metals	USEPA 6020	500 milliliter	Polyethylene	1	HNO <sub>3</sub> pH < 2	4 degrees C	six months
VOCs	USEPA 8260C	40 milliliter	VOA	3	HCL pH < 2	4 degrees C	14 days
PCBs	USEPA 8082	1 liter	Amber Glass	2	none	4 degrees C	365 days
PAHs	USEPA 8270	1 liter	Amber Glass	2	none	4 degrees C	7 days
SVOCs	USEPA 8270	250 milliliter	Amber Glass	1	none	4 degrees C	7 days
EDB	USEPA 8011	40 milliliter	VOA	3	none	4 degrees C	7 days

NOTES:

Total metals are aluminum, arsenic, barium, cadmium, chromium, lead, mercury, selenium, silver, and titanium.

C = Celsius.

EDB = 1,2-dibromoethane.

HCL = hydrochloric acid.

HNO<sub>3</sub> = nitric acid.

NWTPH = Northwest Total Petroleum Hydrocarbons.

PAH = polycyclic aromatic hydrocarbon.

PCB = polychlorinated biphenyl.

SVOC = semivolatile organic compound.

USEPA = U.S. Environmental Protection Agency.

VOA = volatile organic analysis vial.

VOC = volatile organic compound.
## FIGURES









This product is for informational purposes and may not have been prepared for, or be suitable for legal, engineering, or surveying purposes. Users of this information should review or consult the primary data and information sources to ascertain the usability of the information.



## ATTACHMENT A BORING LOG FORM





	Boring/Well No.:	
Site:		
Location:		
Project #:		

### Boring Log Form

Drill Rig			MFA Staff:			Hole Dia:	Total Depth:
Drilling Co	<b>)</b> .:				Water Level:	WLE Note:	
Start Date	:	End Date:			Water Level:	WLE Note:	
Completio	on	Sample				Lithology	
	Top:	Time:	Depth:	Soil Type:		Color:	
	Length:		•	Top:	Fines:		Moisture:
	Type:	Sam	ple ID	Bottom:	Sand:		PID:
	% Recov:			Soil Class:	Gravel:		Line Type:
		•		Trace:		Impacts:	
				Notes:			1
	Top:	Time:	Depth:	Soil Type:		Color:	
	Length:			Top:	Fines:		Moisture:
	Type:	Sam	ple ID	Bottom:	Sand:		PID:
	% Recov:		I	Soil Class:	Gravel:		Line Type:
				Trace:		Impacts:	
				Notes:			1
	:qoT	Time:	Depth:	Soil Type:		Color:	
	Lenath:			Top:	Fines:		Moisture:
	Type:	Sam	ple ID	Bottom:	Sand:		PID:
	% Recov:			Soil Class:	Gravel:		Line Type:
				Trace:		Impacts:	
				Notes:			
	Top:	Time:	Depth:	Soil Type:		Color:	
	Lenath:			Top:	Fines:		Moisture:
	Type:	Sam	ple ID	Bottom:	Sand:		PID:
	% Recov:			Soil Class:	Gravel:		Line Type:
				Trace:		Impacts:	
				Notes:			1
	Top:	Time:	Depth:	Soil Type:		Color:	
	Length:		• • •	Top:	Fines:		Moisture:
	Type:	Sam	ple ID	Bottom:	Sand:		PID:
	% Recov:		ı	Soil Class:	Gravel:		Line Type:
		•		Trace:		Impacts:	
				Notes:	Notes:		
	Top:	Time:	Depth:	Soil Type:		Color:	
	Length:		• • •	Top:	Fines:		Moisture:
		Sam	ple ID	Bottom:	Sand:		PID:
	% Recov:		•	Soil Class:	Gravel:		Line Type:
		•		Trace:		Impacts:	
				Notes:			1
	Top:	Time:	Depth:	Soil Type:		Color:	
	Length:			Top:	Fines:		Moisture:
	Type:	Sam	ple ID	Bottom:	Sand:		PID:
	% Recov:		•	Soil Class:	Gravel:		Line Type:
				Trace:		Impacts:	
				Notes:			1
Borehole	9						
Notes:	-						

## ATTACHMENT B FIELD SAMPLING DATA SHEET FORMS



## Maul Foster & Alongi, Inc.

7223 NE Hazel Dell Avenue, Suite B, Vancouver, WA 98665 (360) 694-2691 Fax. (360) 906-1958

### Soil Field Sampling Data Sheet

Client Name	Sample Location	
Project Number	Sampler	
Project Name	Sampling Date	
Sampling Event	Sample Name	
Sub Area	Sample Depth	
FSDS QA:	Easting	Northing TOC

### **Sample Information**

Sampling Method	Sample Type	Sample Category	PID/FID	Sampling Time	<b>Container Code</b>	#
(1) Backhoe	Liquid	Composite			2 oz. soil	
					4 oz. soil	
					8 oz. soil	
					Other	
					Total Containers	0
	_					

Sample Description:	
l	
Concerci Comming Comments	
General Sampling Comments	

#### Sampling Method Code:

(1) Backhoe, (2) Hand Auger, (3) Drill Bit Cutting Head, (4) Geoprobe, (5) Split Spoon, (6) Shelbey Tube, (7) Grab, (8) Other (Specify)

Signature

## Maul Foster & Alongi, Inc.

7223 NE Hazel Dell Avenue, Suite B, Vancouver, WA 98665 (360) 694-2691 Fax. (360) 906-1958

### Water Field Sampling Data Sheet

Client Name	Sample Location	
Project #	Sampler	
Project Name	Sampling Date	
Sampling Event	Sample Name	
Sub Area	Sample Depth	
FSDS QA:	Easting	Northing TOC

#### Hydrology/Level Measurements

1					(Product Thickness)	(Water Column)	(Gallons/ft x Water Column)
Date	Time	DT-Bottom	DT-Product	DT-Water	DTP-DTW	DTB-DTW	Pore Volume
4		-					

(0.75" = 0.023 gal/ft) (1" = 0.041 gal/ft) (1.5" = 0.092 gal/ft) (2" = 0.163 gal/ft) (3" = 0.367 gal/ft) (4" = 0.653 gal/ft) (6" = 1.469 gal/ft) (8" = 2.611 gal/ft) (2" = 0.163 gal/ft) (3" = 0.367 gal/ft) (4" = 0.653 gal/ft) (6" = 1.469 gal/ft) (8" = 2.611 gal/ft) (3" = 0.653 gal/ft) (4" = 0.653 gal/ft) (6" = 1.469 gal/ft) (8" = 2.611 gal/ft) (3" = 0.653 gal/ft) (4" = 0.653 gal/ft) (5" = 0.653 gal/ft) (6" = 1.469 gal/ft) (8" = 2.611 gal/ft) (3" = 0.653 gal/ft) (6" = 1.469 gal/ft) (8" = 2.611 gal/ft) (3" = 0.653 gal/ft)

#### Water Quality Data

Purge Method	Time	Purge Vol (gal)	Flowrate l/min	pH	Temp (C)	E Cond (uS/cm)	DO (mg/L)	EH	Turbidity
			1	1					
			I	1					
			I	1					
			1	1					
Í			1	1					
Ĩ			1						
Final Field Parameters									

Methods: (1) Submersible Pump (2) Peristaltic Pump (3) Disposable Bailer (4) Vacuum Pump (5) Dedicated Bailer (6) Inertia Pump (7) Other (specify)

### Water Quality Observations:

#### **Sample Information**

Sampling Method	Sample Type	Sampling Time	Container Code/Preservative	#	Filtered
	Groundwater		VOA-Glass		
			Amber Glass		
			White Poly		
			Yellow Poly		
			Green Poly		
			Red Total Poly		
			Red Dissolved Poly		
			Total Bottles	0	

#### **General Sampling Comments**

Signature

## **APPENDIX D** QUALITY ASSURANCE PROJECT PLAN

## QUALITY ASSURANCE PROJECT PLAN

TRUCK CITY SITE MOUNT VERNON, WASHINGTON

> Prepared for SKAGIT COUNTY MOUNT VERNON, WASHINGTON November 11, 2014 Project No. 0714.02.02

Prepared by Maul Foster & Alongi, Inc. 1329 N State Street, Suite 301, Bellingham WA 98225



### CONTENTS

TABLES	AND ILLUSTRATIONS	IV
ACRO	NYMS AND ABBREVIATIONS	V
1	INTRODUCTION	1
2	PROJECT ORGANIZATION AND RESPONSIBILITIES	2
3	<ul> <li>QUALITY ASSURANCE OBJECTIVES FOR DATA MEASUREMENT</li> <li>3.1 CHEMICALS OF POTENTIAL CONCERN</li> <li>3.2 LABORATORY TEST METHODS AND DETECTION LIMITS</li> <li>3.3 PARCC DEFINITIONS AND OBJECTIVES</li> <li>3.4 QUALITY ASSURANCE SAMPLES</li> </ul>	3 3 4 7
4	<ul> <li>FIELD SAMPLING QUALITY ASSURANCE PROCEDURES</li> <li>4.1 WORK DOCUMENTATION</li> <li>4.2 SAMPLE CONTAINERS, PRESERVATION, AND HANDLING</li> </ul>	8 9 10
5	SAMPLE CUSTODY PROCEDURES5.1SAMPLE LABELING5.2SAMPLE CUSTODY	10 10 11
6	<ul><li>EQUIPMENT CALIBRATION AND MAINTENANCE PROCEDURES</li><li>6.1 FIELD INSTRUMENTATION</li><li>6.2 LABORATORY INSTRUMENTATION</li></ul>	12 12 13
7	<ul><li>LABORATORY QUALITY CONTROL PROCEDURES</li><li>7.1 INTERNAL QUALITY ASSURANCE/QUALITY CONTROL CHECKS</li><li>7.2 QUALITY CONTROL PROCEDURES</li></ul>	14 14 15
8	<ul><li>DATA REDUCTION, VALIDATION, AND REPORTING</li><li>8.1 LABORATORY EVALUATION</li><li>8.2 MFA EVALUATION</li></ul>	15 15 16
9	<ul> <li>INTERNAL QUALITY CONTROL</li> <li>9.1 FIELD CHECKS</li> <li>9.2 LABORATORY CHECKS</li> <li>9.3 DATA REDUCTION CHECKS</li> </ul>	18 18 18 18
10	PERFORMANCE AND SYSTEM AUDITS 10.1 FIELD PERFORMANCE 10.2 LABORATORY PERFORMANCE AND SYSTEM AUDITS	18 18 18
11	PREVENTIVE MAINTENANCE	19
12	DATA MEASUREMENT ASSESSMENT PROCEDURES	19
13	CORRECTIVE ACTION	19
14	QUALITY ASSURANCE REPORTS TO MANAGEMENT	20

### CONTENTS (CONTINUED)

LIMITATIONS

REFERENCES

TABLES

### TABLES AND ILLUSTRATIONS

FOLLOWING PLAN:

TABLES

- 1 OBJECTIVES FOR MEASUREMENT
- 2 COMPARISON OF MRL GOALS WITH STATE CLEANUP STANDARDS—RECOMMENDED MRLS

ARAR	applicable or relevant and appropriate requirement
BTEX	benzene, toluene, ethylbenzene, and total xylenes
CAP	Cleanup Action Plan
COC	chain of custody
the County	Skagit County, Washington
FSDS	field sampling data sheet
LCS/LCSD	laboratory control sample and laboratory control sample duplicate
MFA	Maul Foster & Alongi, Inc.
MRL	method reporting limit
MS/MSD	matrix spike and matrix spike duplicate
PARCC	precision, accuracy, representativeness, completeness, and comparability
PID	photoionization detector
QA	quality assurance
QAPP	Quality Assurance Plan
QC	quality control
RPD	relative percent difference
SAP	Sampling and Analysis Plan
The Site	Truck City Site, Skagit County parcel P29546
The Property	The proposed jail property
TPH	total petroleum hydrocarbons
USEPA	U.S. Environmental Protection Agency
VOC	volatile organic compounds

## INTRODUCTION

On behalf of Skagit County, Washington (the County), Maul Foster & Alongi, Inc. (MFA) has prepared this Quality Assurance Project Plan (QAPP) to guide the collection of soil and groundwater samples during remedial action for the Truck City site ("Site") (Facility Site ID: 2673, Cleanup Site ID: 5176). The Site is located at 3216 Old Highway 99 South, Mount Vernon in Skagit County, Washington (Figure 1). The Site, in combination with other adjacent parcels, is proposed for construction of the Skagit County jail. The proposed jail property (Property) comprises the following five parcels: Skagit County parcels P29546 (Truck City parcel) and four adjoining undeveloped parcels to the south, P119262, P119263, P119265, and P119267 (Figure 2). The parcels are owned by various parties, and Skagit County (the "County") has executed purchase and sale agreement(s) for the parcels. The Truck City parcel comprises the entire Site based on data available at this time. As part of that effort, the County is pursuing a Prospective Purchaser Consent Decree with the Washington State Department of Ecology (Ecology). This QAPP is to be used only in conjunction with the Cleanup Action Plan (CAP) and its Sampling and Analysis Plan (SAP). Figure 1 of the CAP presents a layout of the Site.

This QAPP was written to fulfill the requirements in Washington Administrative Code 173-340-410(3)(a).

The purpose of this QAPP is to describe the procedures that will be used to direct the remedial action process so that the following conditions are met:

- Data collected are high-quality, representative, and verifiable.
- Use of resources is cost-effective.
- Data can be used by the County and Ecology to support objectives stated in the CAP.

This document includes quality assurance (QA) procedures for field activities, as well as QA and quality control (QC) procedures for sampling. The QAPP provides a consistent set of QA/QC procedures that will be used throughout the various work phases identified in the CAP. This QAPP supports other documents (e.g., the SAP by forming the basis for data acquisition and analysis) and therefore is not expected to change significantly between phases of work. Through work plans or other documents, the scopes of work for the various activities outlined in this CAP will reference relevant parts of the QAPP for specifics. Because of this, the QAPP lists all currently foreseen analytical methods that may be used for analyzing soil and groundwater, even though a phase of monitoring may target only a specific suite of indicator compounds.

## 2 PROJECT ORGANIZATION AND RESPONSIBILITIES

The County, through its environmental consultant, MFA, will be responsible for seeing that the procedures and guidelines described in the QAPP are followed. MFA personnel responsibilities for quality assurance activities are summarized below.

### Senior Project Director—Jim Darling

Coordinate with project task leaders and communicate with County and agency personnel, as needed. Allocate MFA's resources to the project and ensure that the objectives of the remedial action and the CAP are met. Assist task leaders with technical issues.

### Senior Project Engineer—Justin Clary

Review data, reports, and other project-related documents prepared by MFA before their submittal to the County or to Ecology. Assist project staff with technical issues.

### Project Manager—Yen-Vy Van

Oversee project performance to ensure compliance. Implement necessary action and adjustments to accomplish program objectives. Monitor field investigations. Coordinate field and laboratory sample tracking. Review all data and prepare reports and other project-related documents. Provide technical QA assistance. Monitor field investigations. Coordinate field and laboratory sample tracking. Arrange for other external procurement packages for QA needs. Coordinate corrective actions. Review analytical data and data validation reports. Act as liaison between the County or Ecology and contract personnel.

#### Analytical QA Officer—Brian Fauth

Ensure that the contract laboratory instruments are calibrated and maintained as specified, internal QC measures are performed and analytical methods are applied, the project QA coordinator is notified when problems occur and corrective action is taken, laboratory evaluation is complete and reported in the required deliverables.

#### Project QC Officer-Mary Benzinger

Ensure that sample collection, preservation, storage, transport, and chain-of-custody (COC) procedures are followed. Track field and laboratory samples. Perform corrective actions. Validate analytical data. Inform project QA coordinator when problems occur, and communicate and document corrective actions taken.

### 3 QUALITY ASSURANCE OBJECTIVES FOR DATA MEASUREMENT

The overall QA objective is to collect acceptable data of known and usable quality. The general data quality objective is to provide data on soil and groundwater of sufficient accuracy and precision to identify impacts on the Site. This objective will be achieved and documented using the procedures and criteria set forth in the QAPP. For each measurement made to obtain quantitative data, a set of quality objectives will be used to aid in collecting usable data.

### 3.1 Chemicals of Potential Concern

The following chemicals of interest have been detected in soil/or and groundwater at the Site:

- Gasoline-range total petroleum hydrocarbons (TPH)
- Diesel-range TPH
- Petroleum-fuel-associated volatile organic compounds (VOCs), including benzene, toluene, ethylbenzene, and total xylenes (BTEX)

### 3.2 Laboratory Test Methods and Detection Limits

In accordance with the QA/QC requirements set forth in this QAPP, the analyses of soil and groundwater listed in Tables 1 and 2 of the SAP will be performed by the laboratory, using the following laboratory methods:

- Gasoline-range TPH by Northwest Method NWTPH-Gx
- Diesel-range TPH and residual-range TPH by Northwest Method NWTPH-Dx Extended
- VOCs associated with petroleum fuel, specifically BTEX, by U.S. Environmental Protection Agency (USEPA) 8021B

To permit the evaluation of risk to human health and the environment, routine detection limits for samples collected as part of this investigation should be below applicable or relevant and appropriate requirements (ARARs).

State and federal laws that contain ARARs that apply to the cleanup action at the Site are presented in Table 6 of the CAP. Local laws, which may be more stringent than specified state and federal laws, will govern where applicable.

### 3.3 PARCC Definitions and Objectives

Typically, quality objectives are categorized under precision, accuracy, representativeness, completeness, and comparability (PARCC) parameters. Routine analytical procedures to be used for measuring precision and accuracy include use of duplicate analyses, standard reference materials, surrogate spikes, matrix spikes (MSs), method blanks, and laboratory control samples (LCSs). Surrogate spikes, MSs, method blanks, and LCSs (blank spikes) will be analyzed by at the minimum frequencies specified below. Additional spikes and duplicate analyses may be performed. For the purposes of laboratory analysis, a sample "batch" is considered to be 20 or fewer samples of a single matrix that are extracted or prepared together or are received in the same shipment.

- Surrogate spikes: every sample analyzed for organic compounds will be spiked with selected nontarget analytes and analyzed to evaluate laboratory performance on individual samples.
- MSs and MS duplicates (MSDs): MS samples are analyzed to assess the matrix effects on the accuracy of analytical measurements. MS/MSD samples will be prepared by spiking investigative samples with known amounts of analytes before extraction and preparation and analysis. The recoveries for the MS/MSD samples will be used to assess the accuracy and precision in the analytical method by measuring how well the analytical method recovers the target compounds in the investigative matrices. For each matrix type, at least one set of MS/MSD samples will be analyzed for each batch of samples of 20 (or fewer) samples received.
- Method blank: Method blanks are prepared using analyte-free (reagent) water and are processed with the same methodology (e.g., extraction, digestion) as the associated investigative samples. Method blanks are used to document contamination resulting in the laboratory from the analytical process. A method blank shall be prepared and analyzed in every analytical batch. The method blank results are used to verify that reagents and preparation do not impart unacceptable bias to the investigative sample results. The presence of analytes in the method blank sample will be evaluated against method-specific thresholds. If analytes are present in the method blank above the method-specific threshold, corrective action will be taken to eliminate the source of contamination before proceeding with analysis. Investigative samples of an analytical batch associated with method blank results outside acceptance limits will be appropriately qualified by the data validation contractor.

• LCSs and LCS duplicates (LCSDs): LCSs are prepared by spiking laboratory-certified, reagent-grade water with the analytes of interest or a certified reference material that has been prepared and analyzed. The result for percent recovery of the LCS is a data quality indicator of the accuracy of the analytical method and laboratory performance. LDSs are prepared by the laboratory by splitting an investigative sample into two separate aliquots and performing separate sample preparation and analysis on each aliquot. The results for relative percent difference (RPD) of the primary investigative sample and the respective LDSs are used to measure precision in the analytical method and laboratory performance. For nonaqueous matrices, sample heterogeneity may affect the measured precision for the LDSs.

The precision, accuracy, and completeness criteria to be used for analytical data are summarized in Table 1. Method reporting limit (MRL) goals are listed in Table 2.

PARCC parameters used for field measurements are not generally well defined in the guidelines and literature. These parameters have been defined using the best available guidelines to establish field measurement QA objectives, and will be followed as closely as possible.

### 3.3.1 Precision

Precision is the degree of agreement between replicate measurements of the same source or sample. Duplicate measurements can be made on the same sample or on two samples from the same source. Precision is generally assessed by duplicate measurements of a subset of samples (laboratory or field duplicate samples). The chemical analysis methods define the portion of the samples being analyzed for which precision must be assessed. The precision of physical measurements, such as groundwater level measurements, and of field measurements, such as pH and specific conductance, will be based on the general body of data for the instruments and methods, but will not be calculated specifically.

When detected concentrations in either a sample or a duplicate are less than five times the MRL or the method detection limit, data quality objectives for precision suggest that sample and duplicate results should be within plus or minus the MRL of each other. When detected concentrations in the sample and duplicate are both greater than five times the MRL, data quality objectives for precision suggest that the RPD between the results should be less than or equal to 20 percent.

The RPD can be calculated as follows:

$$RPD = \frac{\left(c_1 - c_2\right) \times 100}{c}$$

where

RPD = relative percent difference

 $c_1$  = concentration of an analyte in a sample

 $c_2 = \text{concentration of an analyte in a duplicate sample}$ 

 $c = (c_1 + c_2)/2$ 

Acceptable precision limits are based on historical databases, as defined by the USEPA. Laboratory duplicate measurements will be obtained for each set of samples submitted, and will be tested for inorganic analytes only (USEPA, 1994). Field duplicates will be evaluated similarly.

### 3.3.2 Accuracy

Accuracy measures the level of bias exhibited by an analytical method or measurement. To measure accuracy, a substance with a known value is analyzed or measured, and the result is compared with the known value.

The accuracy of laboratory analysis is assessed by measuring standard reference materials (instrument calibration) and spiked samples (surrogate recoveries, MSs, and LCSs). Standard reference materials are used to calibrate laboratory instruments. The analytical method specifies the frequency and accuracy required for a spiked sample analysis.

Spike recovery is determined by splitting a sample into two portions, spiking one portion with a known quantity of a constituent of interest, and analyzing both portions. Spike recovery is expressed as percent recovery:

Percent Recovery = 
$$(\underline{MC - KC}) \ge 100$$
  
KC

where

MC = known concentration of an analyte

KC = measured concentration of an analyte

Acceptable MS recovery limits are based on historical data sets, as defined by the USEPA methods. Acceptable surrogate recoveries for organic analyses are based on limits calculated by the laboratory, as described in the analytical method.

The accuracy of field measurements is inherent in the instrument and procedure used.

### 3.3.3 Representativeness

Representativeness is the degree to which data accurately and precisely represent a characteristic of the population, the natural variation at a sampling point, or an environmental condition. There is no standard method or formula for evaluating representativeness. Specific SAPs are designed to allow collection of representative samples. Representativeness is achieved by selecting sampling locations that are appropriate for the objective of the specific sampling task, and by collecting an adequate number of samples. The representativeness of the data will be evaluated and used to identify data gaps that can be addressed during or following completion of the specific investigation.

### 3.3.4 Completeness

Completeness is commonly expressed as a percentage of measurements that are valid and usable relative to the total number of related measurements. Completeness criteria between 80 and 85 percent are identified in the guidance (USEPA, 1987); these will be used to determine the adequacy of the results. The percent completeness is defined by the following equation.

Percent completeness = 
$$\frac{N \times 100}{N_t}$$

where

- N = Number of samples that meet data quality goals
- $N_t$  = Total number of samples analyzed

### 3.3.5 Comparability

Comparability is a qualitative parameter expressing the confidence with which one data set can be compared with another. The use of standard techniques for both sample collection and laboratory analysis should make the data collected comparable to both internal and other data generated.

### 3.4 Quality Assurance Samples

QA samples will be collected in the field, as specified in the specific SAPs. Samples include field equipment rinsate blanks, trip blanks, and field duplicates. QA samples will be blind-labeled and preserved as if they were typical samples. QA samples will be clearly identified on the field sampling data sheets (FSDSs). Analytical results from the blanks and duplicates will facilitate data QC checks. Field and trip blank results may indicate possible contamination introduced by field or laboratory procedures, and field duplicates indicate overall precision in both field and laboratory procedures. Results will be evaluated by applying the PARCC criteria, and the evaluation will be discussed in the data validation report.

### 3.4.1 Trip Blanks

A trip blank monitors the potential for sample contamination during sample collection and transport. A trip blank consists of reagent-grade water in a new sample container, which is prepared at the same time as the primary sample containers. The trip blank will accompany the samples throughout collection, shipment, and storage. At least one trip blank should be included with each cooler in which samples for VOC analyses are stored.

### 3.4.2 Equipment Rinsate Blanks

To ensure that decontamination procedures are sufficient, an equipment rinsate blank will be collected when nondedicated, nondisposable equipment is used. At least one equipment rinsate blank will be collected for every 20 samples collected. If more than 20 samples are collected with the same equipment, or if high concentrations of contaminants are encountered, additional equipment rinsate blanks may be collected. Equipment rinsate blanks will be collected by passing laboratory deionized/distilled water through or over nondisposable sampling equipment.

### 3.4.3 Field Duplicates

Field duplicates are collected to measure sampling and laboratory precision. At least one duplicate sample will be collected for every 20 samples.

### 4 FIELD SAMPLING QUALITY ASSURANCE PROCEDURES

This section describes how samples will be documented, handled, preserved, and shipped, and also discusses equipment decontamination. The SAP outlines the data needs identified for this work and the specific procedures used to obtain representative samples to fulfill these data needs. Specific procedures addressed in the SAP include:

- Techniques used to select sampling sites
- Sampling procedures to be used
- Decontamination procedures for the preparation of sampling equipment and containers
- Time considerations for shipping samples promptly to the laboratory

If deviations are necessary, they will be discussed ahead of time in an addendum to this QAPP. In the case of a field modification, changes will be documented in field notes. Reference to this QAPP will provide field personnel and data reviewers with quantitation goals and other relevant parameters needed for data evaluation.

The information provided in this QAPP outlines the data documentation procedures that will be followed to generate technically defensible data. Any alterations to the field sampling documentation procedures described below will be described on the soil and groundwater FSDSs and in a memorandum written to Ecology.

### 4.1 Work Documentation

The following data forms will be used for documenting specific field observations and conditions:

- Soil FSDS
- Groundwater FSDS
- Log of exploratory boring

The following information will be recorded on the FSDS for each soil or sediment sample collected:

- Facility name
- Sample number
- Sampler's name
- Sample location (well, boring, or sample number)
- Sampling depth
- Sampling date and time
- Sampling method
- Composite or discrete sample
- Sample container size and material
- Sample preservative
- Climatic or other noteworthy conditions (e.g., nearby activities)
- Problems encountered with equipment or methods
- Decontamination methods
- Number of sample bottles filled
- Laboratory used

The sampler will record the following information on the FSDS for each groundwater sample collected:

- Facility name
- Sampler's name
- Sample number
- Well/boring/surface site number and location
- Well/boring condition, well depth, depth to groundwater, and date and time of measurement
- Well/boring purging method, volume, depth, date, and time
- Sampling method, depth, date, and time
- Type of sample container and preservative

- Climatic or other noteworthy conditions (e.g., nearby activities)
- Problems encountered with equipment or methods
- Decontamination methods
- Field measurements (pH, specific conductance, temperature, etc.)
- Number of sample bottles filled
- Laboratory to use

General field observations will be recorded in a field notebook.

### 4.2 Sample Containers, Preservation, and Handling

### 4.2.1 Preservation

Soil and groundwater sample containers and methods of preservation for each analysis are listed in the laboratory quality assurance manual. A summary is provided in Tables 1 and 2 of the SAP. Sample containers will be supplied by the laboratory for each sampling event and will include the appropriate preservatives.

### 4.2.2 Sample Packaging and Shipping

To ensure that the laboratory has ample time to complete all analyses within holding time requirements, and to reduce the potential for field degradation of samples, the samples will be shipped from the field to the laboratory at a minimum of every two days. Holding times for specific analytical methods are included in Tables 1 and 2 of the SAP. Samples will be stored at 4° Celsius (as measured with a thermometer) in iced shipping containers or a refrigerator designated for samples, and then transported by courier to the laboratory in iced shipping containers with a custody seal affixed.

## 5 SAMPLE CUSTODY PROCEDURES

This section provides information about sample labeling and custody procedures.

### 5.1 Sample Labeling

Sample container labels will clearly indicate:

- Sample locations
- Sample number
- Depth at which sample was collected
- Date and time of sample collection

- Sampler's initials
- Any pertinent comments such as specifics of filtration or preservation

Labels will be filled out at the time of sampling. Sample labeling information will also be recorded on the FSDS and in a field notebook.

Samples that will be collected on a regular basis (e.g., groundwater samples collected from monitoring wells) will be assigned blind sample numbers to prevent laboratory bias and tampering. Each sample label may contain the following information:

- Sample number
- Sampler identification (person's initials)
- Date and time of sampling
- Place of collection

Blind sample numbers and actual sample locations will be recorded on the FSDSs. The FSDSs will not be sent to the laboratory.

### 5.2 Sample Custody

Sample custody will be tracked from point of origin through final analysis and disposal, using a COC form, which will be filled out with the appropriate sample/analytical information as soon as possible after samples are collected. For purposes of this work, custody will be defined as follows:

- In plain view of an MFA field representative
- Inside a cooler that is in plain view of an MFA field representative
- Inside any locked space such as a cooler, locker, car, or truck to which the MFA field representative has the only available key(s)

The following items will be recorded on the COC form:

- Project name
- Project number
- MFA project manager
- Sampler's name
- Sample number, date and time collected, medium, number of bottles submitted
- Requested analyses for each sample
- Shipment method
- Type of data package required (Tier II<sup>1</sup>/<sub>2</sub> in most cases)

- Turnaround requirements
- Signature, printed name, and organization name for all persons having custody of samples; date and time of transfer
- Additional instructions or considerations that would affect analysis (nonaqueous layers, archiving, etc.)

Persons in possession of the samples will be required to sign and date the COC form whenever samples are transferred between individuals or organizations. The COC will be included in the shipping containers with the samples, and the containers will be sealed with a laboratory custody seal. The laboratory will implement its in-house custody procedures, which begin when sample custody is transferred to laboratory personnel.

If samples are shipped via air or ground transportation (by a third party), the following custody procedures will be followed. Samples will be packed in shipping containers, and a custody seal will be placed on the container to reduce the potential for tampering. Proper shipping insurance will be requested, and the top two copies of the COC form will accompany the samples. The person shipping the samples will retain a third copy of the COC and shipping forms to allow sample tracking. The COC form will accompany the samples from point of origin in the field to the laboratory.

At the laboratory, a designated sample custodian will accept custody of the received samples, and will verify that the COC form matches the samples received. The shipping container or set of containers is given a laboratory identification number, and each sample is assigned a unique, sequential identification number that includes the original shipping container identification number.

### 6 EQUIPMENT CALIBRATION AND MAINTENANCE PROCEDURES

### 6.1 Field Instrumentation

The investigations will include the use of field instruments. The following field equipment will require calibration before use and periodically during sampling activities:

- pH meter
- Conductivity meter
- Dissolved-oxygen meter
- Photoionization detector (PID)

Field instrument calibration and preventive maintenance will follow the manufacturers' guidelines, and any deviation from the established guidelines will be documented. Generally, field instruments will be calibrated daily before work begins. Field personnel may decide to calibrate more than once a

day if inconsistent or unusual readings occur, or if conditions warrant more frequent calibration. Calibration activities will be recorded in field logbooks.

### 6.1.1 Field Calibration

Calibration procedures, calibration frequency, and standards for measurement will be conducted according to manufacturer's guidelines. To ensure that field instruments are properly calibrated and remain operable, the following procedures will be used, at a minimum:

- Operation, maintenance, and calibration will be performed in accordance with the instrument manufacturers' specifications.
- All standards used to calibrate field instruments will meet the minimum requirements for source and purity recommended in the equipment operation manual. Standards will be used before any expiration dates that may be printed on the bottle.
- Acceptable criteria for calibration will be based on the limits set in the operations manual.
- All users of the equipment will be trained in the proper calibration and operation of the instrument.
- Operation and maintenance manuals for each field instrument will be brought to the Site.
- Field instruments will be inspected before they are taken to the Site.
- If used, PID and flame-ionization detector field instruments will be calibrated at the start and end of each work period. Meters will be recalibrated, as necessary, during the work period.
- Conductivity and pH meters will be calibrated at the start of each workday and, if deemed necessary, recalibrated during the workday.
- Calibration procedures (including time, standards used, and calibration results) will be recorded in a field logbook. Although not reviewed during routine QA/QC checks, the data will be available if problems are encountered.

### 6.1.2 Preventive Maintenance

Preventive maintenance of field instruments and equipment will follow the operations manuals. A schedule of preventive maintenance activities will be followed to minimize downtime and ensure the accuracy of measurement systems. Maintenance will be documented in the field logbook.

### 6.2 Laboratory Instrumentation

Specific laboratory instrument calibration procedures, frequency of calibration, and preparation of calibration standards will be according to the method requirements as developed by the USEPA, following procedures presented in SW-846 (USEPA, 1986).

### 6.2.1 Laboratory Calibration and Preventive Maintenance

The laboratory calibration ranges specified in SW-846 (USEPA, 1986) will be followed.

Preventive maintenance of laboratory equipment will be the responsibility of the laboratory personnel and analysts. This maintenance includes routine care and cleaning of instruments and inspection and monitoring of carrier gases, solvents, and glassware used in analyses. The preventive maintenance approach for specific equipment will follow the manufacturers' specifications and good laboratory practices. Maintenance will be documented in the instrument logbooks.

Precision and accuracy data will be examined for trends and excursions beyond control limits to determine evidence of instrument malfunction. Maintenance will be performed when an instrument begins to change as indicated by the degradation of peak resolution, shift in calibration curves, decrease in sensitivity, or failure to meet one or more of the QC criteria.

### LABORATORY QUALITY CONTROL PROCEDURES

Samples will be analyzed by a laboratory that is qualified to perform the analyses using standard, documented laboratory procedures. The laboratory will have QA/QC plans and standard operation procedures that provide data quality procedures according to the protocols for the analytical method and cleanup steps. The data quality procedures will be at a level sufficient to meet the sampling program's data quality objectives. The laboratory will perform, document, and report laboratory procedures.

The analytical methods and references for analyses that may be used during project implementation are summarized in Tables 1 and 2 of the SAP. Procedural details not specified in this QAPP will follow the protocols described in SW-846 (USEPA, 1986).

### 7.1 Internal Quality Assurance/Quality Control Checks

The laboratory will demonstrate its ability to produce acceptable results, using the recommended methods or their equivalent. The following criteria will be used internally by the laboratory to evaluate the data (as appropriate for inorganic or organic chemical analyses):

- Performance on test methods
  - MS
  - Gas chromatograph (tailing factors)
  - Blanks
  - Precision of calibration and samples
- Percentage recovery of surrogates (organics)

- Adequacy of detection limits
- Precision of replicate sample analyses
- Comparison of percentage of missing or undetected substances between replicate samples

Laboratory records of standard calibration curves and all other pertinent data will be held for possible inspection at the laboratory, and will be made available on request.

### 7.2 Quality Control Procedures

The laboratory QC procedures will consist of the following:

- Instrument calibration and standards as defined in the SW-846 manual for organic and inorganic analyses (USEPA, 1986)
- Laboratory blank measurements at a minimum of 5 percent or one per 20 frequency
- Data reports including appropriate QA/QC documentation

## 8 data reduction, validation, and reporting

The laboratory performing sample analyses will be required to submit analytical data supported by sufficient QA information to permit independent and conclusive determination of data quality. Data quality will be determined by MFA, using the data validation procedures described in this section. The results of the MFA evaluation will be used to determine if the project data quality objectives have been met.

MFA uses a database (EQuIS<sup>TM</sup>) to manage laboratory data. The laboratory will provide the analytical results in electronic, EQuIS-compatible format. Following data evaluation, data qualifiers will be entered into the database.

### 8.1 Laboratory Evaluation

Initial data reduction, evaluation, and reporting at the analytical laboratory will be carried out as described in USEPA SW-846 manuals for analyses (USEPA, 1986), as appropriate. Additional laboratory data qualifiers may be defined and reported to further explain the laboratory's QC concerns about a particular sample result. Additional data qualifiers will be defined in the laboratory's case narrative reports.

### 8.2 MFA Evaluation

### 8.2.1 Validation

After MFA receives the analytical data, the data will be validated under the supervision of the project analytical QA manager. MFA will examine the data for precision, completeness, accuracy, and adherence to standard operating procedures. The laboratory will perform internal QC checks and MFA will validate laboratory analytical data, as described in the following sections. QC checks will be performed on laboratory information, using the sample log-in reports electronically transferred to MFA after samples are entered into the laboratory information management system. The reports will be assessed early in the process, which will allow QC checks to begin before sample holding times have expired or before errors are incorporated in the laboratory reports.

Validation procedures: MFA will evaluate the laboratory data for precision, completeness, accuracy, and compliance with the analytical method. MFA will review data according to applicable sections of USEPA organics and inorganics procedures (USEPA, 2008, 2010), as well as appropriate laboratory method-specific guidelines (USEPA, 1986).

Data qualifiers, as defined by the USEPA, are used to classify sample data according to their conformance to QC requirements. Common qualifiers are listed below:

- J—Estimate, qualitatively correct but quantitatively suspect.
- R—Reject, data not suitable for any purpose.
- U—Not detected at a specified reporting limit.

Poor surrogate recovery, blank contamination, or calibration problems, among other things, can require qualification of the sample data. The reasons for qualification of sample data should be stated in the data evaluation report.

QC criteria not defined in the guidelines for evaluating analytical data are adopted, where appropriate, from the analytical method.

The following information will be reviewed during data evaluation, as applicable:

- Sampling locations and blind sample numbers
- Sampling dates
- Requested analysis
- COC documentation
- Sample preservation
- Holding times
- Method blanks
- Surrogate recoveries
- MS/MSD results
- Laboratory duplicates (if analyzed)

- Field duplicates
- Field blanks
- LCSs
- MRLs above requested levels
- Additional comments or difficulties reported by the laboratory
- Overall assessment

The results of the data evaluation review will be summarized for each data package. Data qualifiers will be assigned to sample results on the basis of USEPA guidelines, as applicable.

### 8.2.2 Reduction

MFA uses a database EQuIS) to manage laboratory data. The laboratory will provide the analytical results in electronic, EQuIS-compatible format. Following data evaluation, data qualifiers will be entered into the database.

Data may be reduced to summarize particular data sets and to aid interpretation of the results. Statistical analyses may also be applied to results. Data-reduction QC checks will be performed on hand-entered data, calculations, and data graphically displayed. Data may be further reduced and managed using one or more of the following computer software applications:

- Microsoft Excel (spreadsheet)
- EQuIS (database)
- Microsoft Access (database)
- AutoCad and/or Arc GIS (graphics)
- USEPA ProUCL (statistical software)

### 8.2.3 Reporting

After completion of data collection, validation, and reduction, the data will be used in reports. Copies of the reports will be kept in the main project file, submitted to the County for review, and then submitted to Ecology. The original copy of any document that MFA produces will remain in the main project file.

Ecology has requested that the County provide electronic copies of data for input into Ecology's Environmental Information Management system. MFA and the County will work with Ecology's Toxic Cleanup Program to make this possible.

### 9.1 Field Checks

Daily internal QC checks will be performed for field activities. Checks will consist of reviewing field notes and field activity memoranda to determine whether the specified measurements, calibrations, and procedures are being followed. The need for and content of corrective action will be assessed on an ongoing basis, in consultation with the project manager.

### 9.2 Laboratory Checks

The laboratory will document the completion and evaluation of internal QC checks and any corrective actions or reanalyses that result.

### 9.3 Data Reduction Checks

Data reduction QC checks will be performed on all entered, calculated, and graphic data produced by MFA. Data entry will be compared with data generated during field activities and recorded in notebooks or on field data forms. Analytical data entry will be reviewed against laboratory reports and data validation reports.

## 10 PERFORMANCE AND SYSTEM AUDITS

MFA's project manager will monitor the performance of the field and laboratory QA program. Proper communication between field staff, project management, and the laboratory will be maintained so that consistent and appropriate methods and techniques are used throughout the project.

### 10.1 Field Performance

Field performance will be monitored through daily review of sample collection documentation, sample handling records (COC forms), field notebooks, field measurements, and periodic field inspections. All field and sampling procedures will be checked for compliance with relevant work plans.

### 10.2 Laboratory Performance and System Audits

The laboratory will audit in-house performance and systems under their in-house QA/QC guidelines. Two types of audits will be used at the facility: system audits to qualitatively evaluate the operational details of the QA program, and performance audits analyzing performance evaluation samples to quantitatively evaluate the outputs of the various measurement systems. Such audits will be made

available for review on request. While samples for this investigation are analyzed, the project QA coordinator will be in contact with the analytical laboratory to assess progress toward obtaining the data quality objectives, and to take corrective measures as problems arise.

## 11 PREVENTIVE MAINTENANCE

Field equipment will be checked daily to detect any malfunctions. Steps will be taken to repair or replace any equipment that appears unreliable. Repairs will be made according to the manufacturers' guidelines, or by qualified repair technicians. Equipment will also be periodically serviced, according to the manufacturers' recommendations. Preventive maintenance procedures for field equipment as well as for analytical equipment are outlined in Section 6.

### 12 DATA MEASUREMENT ASSESSMENT PROCEDURES

Procedures to assess data precision, accuracy, and completeness will be completed routinely, through data validation reports. Precision and accuracy will be based on laboratory documentation. Completeness will be based on the usability of the data collected, relative to the data needs of an investigative task or the amount of data scheduled for collection. Completeness will be quantified when appropriate, but will be qualitatively evaluated with respect to the representativeness of the data when detection, or lack thereof, is the objective. The criteria that will be used for analytical data are summarized in Table 2. The laboratory is responsible for ensuring that the precision and accuracy limits for each laboratory analytical method and parameter are consistently met or exceeded.

## 13 CORRECTIVE ACTION

The need for corrective action will be evaluated on an ongoing basis, depending on the results of internal and laboratory QC checks.

Corrective action measures will generally result from either instrument failure or nonconformance or noncompliance with QA requirements by the laboratory or field personnel. The MFA project manager will be notified as soon as practical if a field or laboratory QA problem arises that could jeopardize the use of collected data. All project personnel are responsible for reporting lapses in QA procedures.

During field operation and sampling procedures, field personnel will be responsible for reporting any changes to specified sampling procedures. A description of any such change will be entered in the daily field logbook and on FSDSs.

If QC audits result in detection of unacceptable conditions or data, the project manager, in conjunction with the project quality assurance coordinator, will be responsible for implementing corrective action. Specific corrective actions are outlined in each SW-846 method and include, but are not limited to:

- Identifying the source of the violation
- Reanalyzing samples if holding time criteria permit
- Evaluating and amending sampling and analytical procedures
- Accepting data and flagging to indicate the level of uncertainty

Ecology and the County shall be notified of each field, laboratory, or project corrective action.

# 14 QUALITY ASSURANCE REPORTS TO MANAGEMENT

Reporting on the quality of data gathering will include regularly transmitting field and laboratory documentation to the project manager and summarizing the information. These reports will consist of field activity memoranda and reports and data validation reports, and will provide a means for management to evaluate accomplishment of the established QA/QC objectives.

After a complete data package is received from the laboratory and MFA has completed the data quality evaluation in accordance with this QAPP, a summary report will be prepared and presented concurrent with laboratory results. The data quality evaluation will summarize the overall quality of the chemical results in terms of the specific data quality goals identified in this QAPP, and will identify chemical results qualified by MFA.

Results of sample analyses will be transmitted to Ecology with a full data validation report that indicates the usability of each reported value. Reports will be maintained in the project files and will include results of performance and system audits; periodic assessment of measurement data accuracy, precision, and completeness; significant QA/QC problems and recommended solutions; and resolutions of previously identified problems.

The services undertaken in completing this plan were performed consistent with generally accepted professional consulting principles and practices. No other warranty, express or implied, is made. These services were performed consistent with our agreement with our client. This plan is solely for the use and information of our client unless otherwise noted. Any reliance on this plan by a third party is at such party's sole risk.

Opinions and recommendations contained in this plan apply to conditions existing when services were performed and are intended only for the client, purposes, locations, time frames, and project parameters indicated. We are not responsible for the impacts of any changes in environmental standards, practices, or regulations subsequent to performance of services. We do not warrant the accuracy of information supplied by others, or the use of segregated portions of this plan.
USEPA. 1986. Test methods for evaluating solid waste: physical/chemical methods. EPA-530/SW-846. U.S. Environmental Protection Agency, Office of Solid Waste and Emergency Response. September (revision 6, February 2007).

USEPA. 1987. Data quality objectives for remedial response activities, development process. U.S. Environmental Protection Agency.

USEPA. 2008. USEPA contract laboratory program, national functional guidelines for organics data review. EPA 540/R-08/01. U.S. Environmental Protection Agency, Office of Emergency and Remedial Response. June.

USEPA. 2010. USEPA contract laboratory program national functional guidelines for inorganic superfund data review. EPA 540/R-10/011. U.S. Environmental Protection Agency, Office of Superfund Remediation and Technology Innovation. January.

## TABLES



## Table 1Objectives for MeasurementTruck City Site

Analysis	Matrix	Accuracy (%)	Precision (%)	Completeness (%)	Method	Reference	Maximum Holding Time		
Total Petroleum Hydrocarbons									
Method 8015B	Soils	63–133	40	85	GC	Ecology	14 days		
	Water	51–143	30	85	GC	Ecology	14 days		
Volatile Organic Compounds									
Method 8260B	Soils	69–134	40	85	Purge+Trap GC/MS	SW-846	14 days		
	Water	64–145	30	85	Purge+Trap GC/MS	SW-846	14 days		
NOTES:									
Ecology = Washington State Department of Ecology.									
GC = gas chromatography.									
MS = mass spectrometry.									

## Table 2Comparison of MRL Goals with State Cleanup StandardsRecommended MRLsTruck City Site

Analysis	(	Soil mg/kg)	Water (ug/L)					
(method)	Quantitation Limit	MTCA Method A Cleanup Level	Quantitation Limit	MTCA Method A Cleanup Level				
Gasoline-range TPH*	50	100	100	800				
Diesel-range TPH	15	2,000	80	500				
Benzene	0.025	0.03	0.3	5				
Toluene	0.1	7	0.5	1,000				
Ethylbenzene	0.1	6	0.5	700				
Total Xylenes	0.3	9	1.5	1,000				
NOTES:								
mg/kg = milligrams per kilogram.								
MRL = method reporting limit.								
MTCA = Model Toxics Control Act.								
TPH = total petroleum hydrocarbons.								
ug/L = micrograms per liter.								
*with presence of benzene.								